




G586SPB AIO

Rev. A+
System Board
User's Manual





FCC Statement on Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

Notice:

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables must be used in order to comply with the emission limits.

The manufacturer makes no warranties with respect to this documentation and disclaims any implied warranties of merchantability, quality, or fitness for any particular purpose. The information in this document is subject to change without notice. The manufacturer reserves the right to make revisions to this publication and to make changes to any and/or all parts of its content, at any time, without obligation to notify any person or entity of such changes. Further, the manufacturer assumes no responsibility for any errors that may appear in this document.





Table of Contents

Chapter 1: Introduction	5
Features and Specifications	6
Package Checklist	8
Chapter 2: Hardware Installation	9
Preparing the Area	9
Handling the System Board	9
Installing the System Board	10
Board Layout	12
System Memory	13
Installing a SIM Module	15
Cache Memory	15
Installing the Cache Module	16
Jumper Settings for Cache	16
Cacheable Memory	17
CPU Installation	17
Jumper Settings for CPUs	18
Installing Upgrade CPUs	20
Jumper Settings for Password Clear	23
Jumper Settings for Display Type	23
Jumper Settings for PS/2 Mouse	24
Jumper Settings for Internal/External Battery	24
Built-in Ports	25
Serial Ports	25
PS/2 Mouse Port	26
Parallel Port	26
Floppy Disk Drive Controller	27
IDE Hard Disk Interface	27
VGA Port	29
Installing Expansion Cards	29
Chapter 3: Software Installation	30
Award BIOS CMOS Setup Utility	30
Standard CMOS Setup	31
BIOS Features Setup	35
Chipset Features Setup	39
Power Management Setup	41
PNP/PCI Configuration	44



Load BIOS Defaults	46
Load Setup Defaults	46
Integrated Peripherals	46
Supervisor Password	49
User Password	49
IDE HDD Auto Detection	50
HDD Low Level Format	52
Save & Exit Setup	53
Exit Without Saving	53
System Error Report	54
Driver Installation	55
Chapter 4: Troubleshooting Checklist	56
Appendix A: Types of Modules	60
Appendix B: Memory and I/O Maps	61
Appendix C: Connectors	63





Chapter 1 Introduction

The G586SPB AIO, equipped with a 321-pin Zero Insertion Force (ZIF) CPU socket, is a Pentium processor-class system board supporting Intel Pentium CPUs running at 75MHz, 90MHz, 100MHz, 120MHz, 133MHz, 150MHz, 166MHz and 200MHz frequencies. The G586SPB AIO also supports future Pentium OverDrive processors and AMD-K5 PR75/PR90/PR100 CPUs.

The G586SPB AIO can support 8MB to 256MB of system memory. It is equipped with 4 SIMM sockets using EDO or fast page mode x32 DRAM. This system board also supports pipeline burst SRAM and provides easy cache upgrades using a 256KB cache module.

The G586SPB AIO comes with a built-in video accelerator. The VGA controller can display graphic resolutions up to 1024x768, 256 colors with 1MB DRAM and up to 1280x1024, 256 colors with 2MB DRAM. The built-in VGA function also supports VESA DDC1 and DDC2B Plug and Play monitors.

The G586SPB AIO design is based on the Peripheral Component Interconnect (PCI) local bus and Industry Standard Architecture (ISA) standards. It is equipped with 3 dedicated PCI slots and 4 dedicated 16-bit ISA slots.

The G586SPB AIO board has two bus master PCI IDE connectors. Bus mastering reduces CPU use during disk transfer. This system board is also equipped with two NS16C550A-compatible serial ports, an SPP/ECP/EPP parallel port, a floppy disk drive controller, one PS/2 mouse port, one PS/2 or AT keyboard connector and one IrDA connector for wireless connectivity between your computer and peripheral devices.



Features and Specifications

PROCESSOR

- Intel Pentium 75/90/100/120/133/150/166/200MHz
- Future Pentium OverDrive processor
- AMD-K5 PR75/PR90/PR100 and future AMD-K5 CPUs

CHIPSET

- SiS 5596: PCI, memory and VGA controller
- SiS 5513: PCI system I/O

CACHE MEMORY

- Supports 256KB or 512KB pipeline burst, direct map write-back cache installed on the system board
- One 160-pin cache module slot, COAST 2.x standard
- Onboard 256KB: upgradeable with a 256KB cache module for a maximum of 512KB cache

SYSTEM MEMORY

- 8MB to 256MB memory
- Four 72-pin SIMM sockets
- Unified Memory Architecture: 64-bit main memory is shared between the CPU and the graphics controller
- Uses EDO or fast page mode x32 DRAM (60ns or 70ns)

BIOS


- Award BIOS, Windows 95 Plug and Play compatible
- Flash EPROM for easy BIOS upgrades

ENERGY EFFICIENT DESIGN

- System power management supported
- CPU stopped clock control
- Hardware supports SMI green mode
- Microsoft/Intel APM compliant

GRAPHICS ACCELERATOR

- Accelerated 64-bit graphics controller
- Built-in video accelerator
- Supports VESA DDC1 and DDC2B



- Graphics resolutions
 - 1MB: 640x480, 16M colors, 60Hz, NI
800x600, 64K colors, 60Hz, NI
1024x768, 256 colors, up to 75Hz, NI
 - 2MB: 640x480, 16M colors, 75Hz, NI
800x600, 16M colors, 75Hz, NI
1024x768, 64K colors, 75Hz, NI
1280x1024, 256 colors, 60Hz, NI
- VGA drivers and utilities
 - Power management utility
 - VESA Video BIOS Extensions (VBE)
 - Windows 95 - supports DirectDraw
 - Windows 3.1- supports DCI
 - Windows NT (optional)
 - OS/2 2.x/Warp (optional)

PCI IDE INTERFACE

- Supports fast Mode 3 and Mode 4 Enhanced IDE
- DMA Mode 2 Bus Master IDE
- Two IDE connectors to control four drives (e.g. two HDDs, one tape drive and one CD-ROM)
- Bus mastering reduces CPU use during disk transfer
- ATAPI IDE CD-ROM supported

INTEGRATED IO


- Two NS16C550A-compatible enhanced serial ports
- One SPP/ECP/EPP parallel port
- Supports 360KB, 720KB, 1.2MB, 1.44MB and 2.88MB floppy drives
- One IrDA TX/RX header
- Two USB connectors supported in future revision

CPU SOCKET

- 321-pin ZIF socket (Intel Socket 7)

CONNECTORS

- 1 IrDA TX/RX connector
- 2 serial ports
- 1 parallel port
- 2 IDE connectors
- 1 floppy connector



- 1 analog VGA port
- 1 VGA feature connector
- 1 PS/2 mouse port
- 1 PS/2 or AT keyboard connector

EXPANSION SLOTS

- 3 dedicated PCI slots
- 4 dedicated 16-bit ISA slots

PCB


- 4 layers
- 26cm (10.24") x 22cm (8.66")

Package Checklist

The G586SPB AIO package contains the following items:

- The G586SPB AIO system board
- The G586SPB AIO user's manual
- One 40-pin IDE hard disk cable
- One 34-pin floppy disk drive cable
- One 25-pin printer port cable for chassis mounting
- One card-edge bracket with serial and mouse port cables
- One card-edge bracket with an analog VGA port cable
- One IDE driver diskette
- One set of VGA driver diskettes
- Cache module (optional)

If any of these items are missing or damaged, please contact your dealer or sales representative for assistance.



Chapter 2 Hardware Installation

This chapter summarizes the steps to install the G586SPB AIO system board into your system unit. It also includes a description of the area in which you must work and directions for memory installation. Before installing the system board, obtain the memory you plan to install. Please refer to the information on pages 13 and 14 for the number and type of memory modules needed for the amount of memory you require.

Preparing the Area


Before unpacking the system board, make sure the location you have selected is relatively free of dust and static electricity. Excessive exposure to dust, static electricity, direct sunlight, excessive humidity, extreme cold, and water can damage the operational capabilities of your system board. Avoid placing the unit on surfaces such as carpeted floors. These areas also attract static electricity which can damage some circuits on your system board.

Make sure the power source has a properly grounded, three-pronged socket. It is essential that the power connection be properly grounded for correct functioning of your system board. For further protection, we recommend that you use a surge suppressor. This will protect the system board from damage that may result from a power surge on the electrical line.

Move items that generate magnetic fields away from your system board since magnetic fields can also damage your system board. Once you have selected the ideal location, unpack the G586SPB AIO system board carefully.

Handling the System Board

It is quite easy to inadvertently damage your system board even before installing it in your system unit. Static electrical discharge can damage computer components without causing any signs of physical damage. You must take extra care in handling the system board to ensure against electrostatic build-up.



Static Electricity Precautions

1. To prevent electrostatic build-up, leave the board in its anti-static bag until you are ready to install it.
2. Wear an antistatic wrist strap.
3. Do all preparation work on a static-free surface with the system board components facing up.
4. Hold the system board only by its edges. Be careful not to touch any of the components, contacts or connections, especially gold contacts, on the board.
5. Avoid touching the pins or contacts on all modules and connectors. Hold modules and connectors by their ends.

Warning:


Electrostatic discharge (ESD) can damage your processor, disk drives, add-in boards, and other components. Perform the upgrade instruction procedures described at an ESD workstation only. If such a station is not available, you can provide some ESD protection by wearing an anti-static wrist strap and attaching it to a metal part of the system chassis. If a wrist strap is unavailable, establish and maintain contact with the system chassis throughout any procedures requiring ESD protection.

Installing the System Board


If you are installing the G586SPB AIO system board, the following outlines the basic installation steps. Before installing the system board into your system unit, you should prepare the tools you will need.

You will need:


- One medium size, flat-bladed screwdriver
- One medium Phillips screwdriver
- One needle-nosed pliers
- One small nutdriver



1. Unlock your system unit. Turn off the power and disconnect all power cords and cables.
2. Remove the system unit cover. Refer to the manufacturer's instructions if necessary.
3. Detach all connectors from the old system board and remove expansion cards seated in any expansion slots.
4. Loosen the screws holding the original system board and remove the board from the system. Save the screws.
5. Remove the G586SPB AIO from its original packing box. Be careful to avoid touching all connectors and pins on the board. Please refer to the handling instructions on pages 9-10 for proper handling techniques.
6. Insert the memory modules into the memory banks on the G586SPB AIO. The quantity and location of the memory modules depends on the memory configuration and type of modules you intend to use.
7. Insert the cache module, if any, into the cache module slot on the G586SPB AIO. Refer to the Cache Memory section for upgrading your cache memory.
8. Install the CPU. Be sure pin 1 of the CPU is aligned with pin 1 of the socket.
9. Set the corresponding jumpers.
10. Install the prepared G586SPB AIO system board into the case and replace the screws.
11. Reinstall all cards and connectors and replace the system unit cover. Reconnect all power cords and cables.



Board Layout



■ square denotes pin 1

System Memory

The SIMM (Single In-line Memory Module) sockets are divided into two banks on the system board, Bank 0 and Bank 1. Each bank consists of 2 SIMM sockets. Refer to page 12 for the locations of the SIMM sockets.


You will need either 2 or 4 pieces of SIM modules, depending on the amount of memory you intend to install. Make sure you insert the same type of SIMMs in one bank. You can install SIMMs in either of the banks, Bank 0 or Bank 1, but you must populate one bank first before going to the next bank.

The G586SPB AIO system board can support 8MB to 256MB of memory using 1MBx32, 2MBx32, 4MBx32, 8MBx32, or 16MBx32 72-pin SIMMs. The table below shows the supported SIM modules and their corresponding memory sizes.

SIMMs	Memory Size
1MBx32	4MB
2MBx32	8MB
4MBx32	16MB
8MBx32	32MB
16MBx32	64MB

The table below summarizes the bank locations and modules needed for the corresponding memory sizes.


Memory Size	Bank0		Bank1	
	SIMM3	SIMM4	SIMM1	SIMM2
8MB	1MBx32	1MBx32	—	—
8MB	—	—	1MBx32	1MBx32
16MB	2MBx32	2MBx32	—	—
16MB	—	—	2MBx32	2MBx32
16MB	1MBx32	1MBx32	1MBx32	1MBx32
24MB	1MBx32	1MBx32	2MBx32	2MBx32
24MB	2MBx32	2MBx32	1MBx32	1MBx32



Memory Size	Bank0		Bank1	
	SIMM3	SIMM4	SIMM1	SIMM2
32MB	4MBx32	4MBx32	—	—
32MB	—	—	4MBx32	4MBx32
32MB	2MBx32	2MBx32	2MBx32	2MBx32
40MB	1MBx32	1MBx32	4MBx32	4MBx32
40MB	4MBx32	4MBx32	1MBx32	1MBx32
48MB	2MBx32	2MBx32	4MBx32	4MBx32
48MB	4MBx32	4MBx32	2MBx32	2MBx32
64MB	8MBx32	8MBx32	—	—
64MB	—	—	8MBx32	8MBx32
64MB	4MBx32	4MBx32	4MBx32	4MBx32
72MB	1MBx32	1MBx32	8MBx32	8MBx32
72MB	8MBx32	8MBx32	1MBx32	1MBx32
80MB	2MBx32	2MBx32	8MBx32	8MBx32
80MB	8MBx32	8MBx32	2MBx32	2MBx32
96MB	4MBx32	4MBx32	8MBx32	8MBx32
96MB	8MBx32	8MBx32	4MBx32	4MBx32
128MB	16MBx32	16MBx32	—	—
128MB	—	—	16MBx32	16MBx32
128MB	8MBx32	8MBx32	8MBx32	8MBx32
136MB	1MBx32	1MBx32	16MBx32	16MBx32
136MB	16MBx32	16MBx32	1MBx32	1MBx32
144MB	2MBx32	2MBx32	16MBx32	16MBx32
144MB	16MBx32	16MBx32	2MBx32	2MBx32
160MB	4MBx32	4MBx32	16MBx32	16MBx32
160MB	16MBx32	16MBx32	4MBx32	4MBx32
192MB	8MBx32	8MBx32	16MBx32	16MBx32
192MB	16MBx32	16MBx32	8MBx32	8MBx32
256MB	16MBx32	16MBx32	16MBx32	16MBx32

Installing a SIM Module

A SIM module simply snaps into a socket on the system board. Pin 1 of the SIM module must correspond with Pin 1 of the socket.



1. Position the SIMM above the socket with the “notch” in the module aligned with the “key” on the socket.
2. Seat the module at a 45° angle into the bank. Make sure it is completely seated. Tilt the module upright until it locks in place in the socket.

Cache Memory


The G586SPB AIO system board can support 256KB or 512KB pipeline burst, direct map write-back cache SRAM. Your system board may come with 256KB or 512KB cache mounted at locations U4 and U6 of the system board. If your system board is mounted with 256KB cache, you may upgrade your cache memory to 512KB by installing a 256KB cache module in the 160-pin cache module slot (KM1). Regardless of the amount of cache memory installed, one SRAM is mounted on location U8 for tag RAM to store the cacheable addresses. Refer to page 12 for the locations of the cache module slot (KM1), U4 and U6.

Warning:

We highly recommend that you use the T2BSM32-256 cache module. If you are using a cache module other than the one recommended above, make sure your cache module meets the Intel COAST 2.x specification. Severe damage might occur on the cache module or system board if you insert modules other than the one specified above.

Installing the Cache Module


Locate the 160-pin cache module slot on the system board (KM1). Position the cache module above the slot. Make sure pin 1 of the cache module is aligned with pin 1 of the slot. Carefully slide the module into the slot. Press firmly on the top of it to seat it properly.




Jumper Settings for Cache

Jumpers JP2, JP4 and JP5
Cache Size Select

Cache Size	Onboard Cache	Upgradeable Cache Module	JP2	JP4	JP5
256KB	256KB	0KB	1-2 On	1-2 On	1-2 On
512KB	256KB	256KB	2-3 On	1-2 On	2-3 On
512KB	512KB	NA	1-2 On	1-2 On	2-3 On



1-2 On



2-3 On



Cacheable Memory

Cache Size	Cacheable Range	
	8-bits Tag	7-bits Tag 1 Dirty Bit
256KB	64MB	32MB
512KB	128MB	64MB


The “L2 (WB) Tag Bit Length” category in the Chipset Features Setup of the Award BIOS Setup utility allows you to set the “Tag Bit Length” to “7-bits” or “8-bits”. The default setting is “7-bits”. This setting will increase the performance of your system but the cacheable memory will be smaller than that of an “8-bits” setting.

CPU Installation

The G586SPB AIO allows for easy installation of CPUs. Make sure all jumpers are set correctly before applying power or you may damage the CPU or system board. Please see the jumper settings on the following pages. Use the needle-nosed pliers to move the jumpers if necessary.

Warning:


The default setting of JP10, JP11 and JP12 is 3.3V (VR/STD). If the voltage of your CPU is not 3.3V, JP12 make sure you set JP10, JP11 and JP12 according to the voltage of your CPU, otherwise, your system will hang.



CPU Internal/External (Freq.) Speed	JP14	JP13	JP14
75/50, 90/60, 100/66 (1.5x)	Off	2-3	On
120/60, 133/66 (2x)	Off	1-2	On
150/60, 166/66 (2.5x)	On	1-2	On
200/66 (3x) reserved	On	2-3	On

CPU Voltage	JP10	JP11	JP12
2.7V	1-2 On	1-2 On	1-2 On
2.8V	3-4 On	1-2 On	1-2 On
2.9V	5-6 On	1-2 On	1-2 On
3.3V* (VR/STD)	All Off	3-4 On, 5-6 On, 7-8 On	1-2 On
3.5V (VRE)	All Off	3-4 On, 5-6 On, 7-8 On	3-4 On

* Default



CPU Speed	System Bus Clock	PCI CLK Pins	JP6 Pins	JP1 Pins
75MHz	50MHz	25MHz	1-2 Off	3-4 Off, 5-6 Off
90/120/150MHz	60MHz	30MHz	1-2 On	3-4 Off, 5-6 Off
100/133/166/200MHz	66.6MHz	33.3MHz	1-2 Off	3-4 Off, 5-6 Off

Jumper Settings for CPUs

Intel CPUs



AMD-K5 CPUs

Warning:


The default setting of JP10, JP11 and JP12 is 3.3V. If the voltage of your CPU is not 3.3V, make sure you set JP10, JP11 and JP12 according to the voltage of your CPU, otherwise, your system will hang.

CPU Voltage	JP10	JP11	JP12
2.7V	1-2 On	1-2 On	1-2 On
2.8V	3-4 On	1-2 On	1-2 On
2.9V	5-6 On	1-2 On	1-2 On
3.3V*	All Off	3-4 On, 5-6 On, 7-8 On	1-2 On
3.5V	All Off	3-4 On, 5-6 On, 7-8 On	3-4 On


* Default



CPU P-Rate/Internal/External Freq. Speed	JP13	JP14
75/75/50, 90/90/60, 100/100/66 (Clock) 2-3 On	Off	1-2 On
2x for future CPUs		



P-Rating	CPU Speed	System Bus Clock	PCI CLK Pins	JP6		JP1
				Pins	Pins	
PR75	75MHz	50MHz	25MHz	1-2 Off	3-4 On	5-6 Off
PR90	90MHz	60MHz	30MHz	1-2 On	3-4 Off	5-6 Off
PR100	100MHz	66.6MHz	33.3MHz	1-2 Off	3-4 Off	5-6 Off




Installing Upgrade CPUs

The G586SPB AIO is equipped with a 321-pin Zero Insertion Force (ZIF) socket at location U14 of the system board. Refer to page 12 for the location of the ZIF socket. This socket is designed for easy removal of an old CPU and easy insertion of an upgrade CPU. The ZIF socket allows you to carefully place the new CPU into its position. If you need to apply excessive force to insert the CPU, you are not installing the CPU correctly.

Warning:

Open the socket only if you are actually installing a CPU. The warranty on the original CPU will be voided if the S/N seal is broken. Before proceeding with the upgrade, take note of the following. The microprocessor and heatsink may be hot if the system has been running. To avoid the possibility of a burn, power the system off and let the processor and heatsink cool for 20 minutes.


The 321-pin ZIF socket consists of five rows of pin holes on each side. To prevent improper CPU installation, the ZIF socket has a Plug/Keying mechanism. Several holes in the socket are plugged so that the CPU will go in only one way. If you cannot easily insert the CPU, verify that pin 1 of the CPU is aligned with pin 1 of the socket.




Zero Insertion Force (ZIF) Socket

To install an upgrade CPU, do the following.

1. Make sure the handle on the side of the ZIF socket is up. To raise the handle, push it down, slightly pull it out to the side, then raise it as far as it will go. It may be necessary to initially apply a small




amount of sideways force to free the handle from its retaining “tab”. Once clear of the “tab”, the handle will open relatively easily. The top plate will slide back. Do not use screwdrivers or other tools to open the socket, or you may damage the system or socket.





Lifting the Handle

2. Once the lever is completely up, remove the old CPU carefully by lifting it straight out of the socket. You are now ready to insert the new CPU.



3. Position the CPU above the ZIF socket. Make sure pin 1 of the CPU is aligned with pin 1 of the socket. Lower the chip until the pins are inserted properly in their corresponding holes. Remember that very little force is needed to install the CPU. If the CPU is not easily inserted, verify whether or not pin 1 of the CPU is aligned with pin 1 of the socket. Applying too much pressure can damage the CPU or the socket.



Positioning the CPU Above the ZIF Socket

4. Push the handle down until the handle locks into place. The top plate will slide forward. You will feel some resistance as the pressure starts to secure the CPU in the socket. This is normal and will not damage the CPU. However, if the handle is not completely closed, damage to the CPU and/or system board may result.

Clearance Requirements

Your CPU comes with a heatsink mounted on top. To maintain proper airflow once the upgrade is installed on the system board, the CPU and heatsink require certain space clearances.

The clearance above the CPU's fan/heatsink must be at least 0.4 inches. The clearance on at least 3 of 4 sides of the processor and heatsink must be at least 0.2 inches. All cables (for floppy drive, hard drive, CD-ROM, etc.) must be routed clear of the CPU and its airspace.

Fan Exhaust


The CPU must be kept cool by using a fan with heatsink. The temperature of the air entering the fan/heatsink cannot exceed 45°C (113°F). The ambient or room temperature must be below 37°C (99°F).

Jumper Settings for Password Clear


Jumper JP9

Password Clear

If you set a password in the "Password Setting" option and forget your password, power off your system and set jumper JP9 pins 2 and 3 to On. Then power on your system for 5 seconds and turn it off again. This will clear the password stored in your CMOS. Set JP9 back to its default setting, pins 1 and 2 On.



1-2 On: Normal (default)



2-3 On: Password Clear

Jumper Settings for Display Type

Jumper JP15

Display Type Select

Jumper JP15 sets the display adapter to color or mono. This jumper must match the type of display adapter installed. If you changed your video adapter, make sure this jumper is changed accordingly.



On: Color
(default)



Off: Mono

Jumper Settings for PS/2 Mouse

Jumper JP16 PS/2 Mouse

The G586SPB AIO package includes a card-edge bracket with two serial ports and a mouse port. By default, the PS/2 mouse port is enabled. The PS/2 mouse port uses IRQ12, but when the PS/2 mouse port is disabled, IRQ12 is available to other devices.



On: PS/2 Mouse Enabled
(default)



Off: PS/2 Mouse
Disabled

Jumper Settings for Internal/External Battery

Jumper JP17 Internal/External Battery Select


The G586SPB AIO system board comes with a lithium battery. The default setting of JP17 is Off for battery conservation during shipment of the board. Before installing the system board onto your system unit, set JP17 to On to use the lithium battery. If you are connecting an external battery to connector J19, you must set JP17 to Off.



On: Internal Battery




Off: External Battery
(default)



Built-in Ports

The G586SPB AIO system board is equipped with two serial ports, one parallel printer port, one FDD connector, two IDE hard disk shrouded headers, one PS/2 mouse connector and one VGA port. Refer to page 12 for the locations of the built-in connectors and pin 1 of those connectors.



Serial Ports

The built-in serial ports are RS-232C asynchronous communication ports with 16C550A-compatible UARTs that can be used with modems, serial printers, remote display terminals, and other serial devices. They use the following system I/O addresses:

Port Configuration	COM1	COM2	COM3	COM4
Serial Port 1	3F8h*	2F8h	3E8h	2E8h
Serial Port 2	3F8h	2F8h*	3E8h	2E8h

* Default



Connecting the Serial Ports

Two DB-9 serial port cables are provided with the system board. They are mounted on a card-edge bracket along with the PS/2 mouse cable. The upper serial port cable should be used for the COM 1 primary serial port; connect it to connector J14 on the system board. The lower serial port cable should be used for the COM 2 secondary serial port; connect it to connector J7 on the system board. Make sure the colored stripes on the ribbon cables are aligned with pin 1 of connectors J7 and J14. Mount the card-edge bracket to the system chassis.

PS/2 Mouse Port

The PS/2 mouse port is a 6-pin connector on the system board. Attach the 6-pin mouse port cable, which is mounted on the card-edge bracket, to connector J15. Make sure the brown wire on the PS/2 mouse connector is aligned with pin 1 of connector J15.

Parallel Port

The G586SPB AIO system board has a standard connector for interfacing your PC to a parallel printer. The parallel port on your system board can be set to any of the following system I/O addresses:

I/O Address	3BC-3BE Hex
	378-37A Hex (default)
	278-27A Hex

Connecting the Parallel Printer Port

Attach the DB-25 printer cable, which came with the system board, to connector J8 on the G586SPB AIO system board. Make sure the colored stripe on the ribbon aligns with pin 1 of connector J8. Use a small nutdriver to mount the cable into a DB-25 cutout in the system chassis.






Floppy Disk Drive Controller

The G586SPB AIO system board has a built-in floppy disk controller that supports two standard floppy disk drives. You can install any 360KB, 720KB, 1.2MB, 1.44MB, or 2.88MB floppy disk drives.


Connecting the Floppy Disk Cable

1. Install the 34-pin header connector into the floppy disk connector (J1) on the system board. The colored edge of the ribbon should be aligned with pin 1 of connector J1.
2. Install the other 34-pin header connector(s) into the disk drive(s). Align the colored edge of the daisy chained ribbon cable with pin 1 of the drive edge connector(s). The end-most connector should be attached to the drive you want to designate as Drive A.

IDE Hard Disk Interface



The G586SPB AIO system board is equipped with two PCI IDE shrouded headers that will interface four Enhanced IDE (Integrated Drive Electronics) hard disk drives.





Note:

Only Enhanced IDE hard drives or ATAPI CD-ROMs can be connected to the IDE interface.

Connecting the IDE Hard Disk Interface

To prevent improper IDE cable installation, each PCI IDE shrouded header has a keying mechanism. The 40-pin connector on the IDE cable can be placed into the header only if pin 1 of the connector is aligned with pin 1 of the header.



Note:

An IDE cable with a standard 40-pin connector (without the keying mechanism) can be installed in the PCI IDE shrouded header. Be extremely careful to match the colored edge of the ribbon with pin 1 of the header.

Connecting the Hard Disk Cable

1. If you are connecting two hard drives, install the 40-pin connector of the IDE cable into the primary IDE shrouded header (connector CON2). If you are adding a third or fourth IDE device, install the 40-pin connector of the other IDE cable into the secondary IDE shrouded header (connector CON1).
2. Install the other 40-pin header connector(s) into the device with the colored edge of the ribbon cable aligned with pin 1 of the drive edge connector(s).


Note:

Refer to your disk drive user's manual for information about selecting proper drive switch settings.

Adding a Second IDE Hard Drive

When using two IDE drives, one must be set as the master and the other as the slave. Follow the instructions provided by the drive manufacturer for setting the jumpers and/or switches on the drives.

We recommend that the Enhanced IDE hard drives be from the same manufacturer. In a few cases, drives from two different manufacturers will not function properly when used together. The problem lies in the hard drives, not the G586SPB AIO system board.



Preparing an IDE Drive for Use

IDE disk drives are already low-level formatted, with any bad-track errors entered, when shipped by the drive manufacturer. Do not attempt to do a low-level format or you may cause serious damage to the drive. To use an IDE drive, you need to enter the drive type (this information is provided by the drive manufacturer) into the system's CMOS setup table. Then run FDISK and FORMAT provided with DOS. You may also use the IDE HDD Auto Detection function which will allow the BIOS to auto detect your hard drive type. Refer to the IDE HDD Auto Detection section for details.

Warning:

Do not run FDISK and FORMAT programs on a drive that has already been formatted or you will lose all programs and data stored on the drive.

VGA Port

One card-edge bracket mounted with an analog VGA port cable is provided with the system board. Connect the VGA port cable to connector J3 on the system board. Make sure the colored stripes on the ribbon cable is aligned with pin 1 of connector J3. Mount the card-edge bracket to the system chassis.

Installing Expansion Cards

The G586SPB AIO system board is equipped with 3 dedicated PCI slots and 4 dedicated 16-bit ISA slots. All PCI slots are bus masters. Refer to page 12 for the locations of the expansion slots.

Due to the size of the CPU with its accompanying fan/heatsink component, the length of the add-in cards in PCI slot 3, ISA slot 1 and 2 is limited to 18cm (7.07", measured from the bracket of the card). With the cache module installed in the cache module slot, the components on the solder side of the add-in card in PCI Slot 2 and the components on the component side of the add-in card in PCI Slot 1 must not protrude more than 5mm.



Chapter 3 Software Installation

After you power up your system, the BIOS message appears on your screen and the memory count begins.

After the memory test, the following message will appear on the screen:

Press DEL to enter setup


If the message disappears before you respond, restart your system or press the “Reset” button located on the front panel of your computer. You may also restart the system by pressing the <Ctrl> <Alt> and keys simultaneously.

If you have set a password and selected “System” in the Security Option of the BIOS Features Setup menu, you will be prompted for the password every time the system is rebooted or any time you try to enter Setup. Type in the correct password and press <Enter>.

If you selected “Setup” in the Security Option, you will be prompted for the password only when you try to enter Setup. Refer to the “BIOS Features Setup” section for more information.

Award CMOS Setup Utility

Press <Ctrl> <Alt> <Esc> simultaneously or to enter the Setup utility. A screen similar to the one on the next page will appear.



ROM PCI/ISA BIOS
CMOS SETUP UTILITY
AWARD SOFTWARE, INC.

STANDARD CMOS SETUP BIOS FEATURES SETUP CHIPSET FEATURES SETUP POWER MANAGEMENT SETUP PNP/PCI CONFIGURATION LOAD BIOS DEFAULTS LOAD SETUP DEFAULTS	INTEGRATED PERIPHERALS SUPERVISOR PASSWORD USER PASSWORD IDE HDD AUTO DETECTION HDD LOW LEVEL FORMAT SAVE & EXIT SETUP EXIT WITHOUT SAVING
ESC :Quit F10 :Sve & Exit Setup	↑↓→← :Select Item (Shift) F2 :Change Color
Time, Date, Hard Disk Type...	

Use the arrow keys to highlight the option you want and press <Enter>. The following describes each of these options.

Note:


The settings of the BIOS setup screens on the following pages are for reference only. Some of the settings will vary according to your system's configuration and should not be referred to as the standard default setting.

Standard CMOS Setup

Use the arrow keys to highlight "Standard CMOS Setup" and press <Enter>. A screen similar to the one below will appear.

ROM PCI/ISA BIOS
STANDARD CMOS SETUP
AWARD SOFTWARE, INC.

Date (mm:dd:yy) : Wed, Jul 24 1996								
Time (hh:mm:ss) : 14 : 44 : 57								
HARD DISKS	TYPE	SIZE	CYLS	HEAD	PRECOMP	LANDZ	SECTOR	MODE
Primary Master	:Auto	0	0	0	0	0	0	AUTO
Primary Slave	:Auto	0	0	0	0	0	0	AUTO
Secondary Master	:Auto	0	0	0	0	0	0	AUTO
Secondary Slave	:Auto	0	0	0	0	0	0	AUTO
DriveA	:1.44M,3.5in.							
DriveB	:None							
Video	:EGA/VGA							
Halt on	:All Errors							
						Base Memory : 640K		
						Extended Memory : 30720K		
						Other Memory : 384K		
						Total Memory : 31744K		
ESC	:Quit	↑↓→←		:Select Item		PU/PD/+/- : Modify		
F1	:Help	(Shift)F2		:Change				



Date

The date format is <day>, <month>, <date>, <year>.

Day	Displays a day, from Sunday to Saturday
Month	Displays the month, from January to December
Date	Displays the date, from 1 to 31
Year	Displays the year, from 1900 to 2099

Time

The time format is <hour>, <minute>, <second>. The time is based on the 24-hour military-time clock. For example, 1 p.m. is 13:00:00.


Hour	Displays hours from 00 to 23
Minute	Displays minutes from 00 to 59
Second	Displays seconds from 00 to 59

Primary Master, Primary Slave, Secondary Master and Secondary Slave

These categories allow you to enter the appropriate specifications for the type of hard disk drive(s) installed in your system. There are 45 predefined types and 4 user definable types for hard drives. Type 1 to Type 45 are predefined. Type User is user-definable.

Press <PgUp> or <PgDn> to select a numbered hard disk type or type the number and press <Enter>. The hard disk will not work properly if you enter improper information for this category. You can use Type "User" to define your own drive type manually.

If you select Type "User", you will need to know the information listed below. Enter the information and press <Enter>. This information should be included in the documentation from your hard disk vendor or the system manufacturer.



If the controller of the HDD interface is ESDI, you must select "Type 1".

If the controller of the HDD interface is SCSI, you must select "None".

If you select Type "Auto", the BIOS will auto-detect the HDD & CD-ROM drive at the POST stage and show the ID for the HDD & CD-ROM drive.

Type	Drive type
Cyls	Number of cylinders
Heads	Number of heads
Precomp	Write precomp
Landzone	Landing zone
Sectors	Number of sectors
Mode	Mode type

If a hard disk has not been installed, select None and press <Enter>.


Drive A and Drive B

These categories identify the types of floppy disk drives installed. The following are the options for drives A and B.

None	No floppy drive is installed
360K, 5.25 in.	5-1/4 inch PC-type standard drive; 360 kilobyte capacity
1.2M, 5.25 in.	5-1/4 inch AT-type high-density drive; 1.2 megabyte capacity
720K, 3.5 in.	3-1/2 inch double-sided drive; 720 kilobyte capacity
1.44M, 3.5 in.	3-1/2 inch double-sided drive; 1.44 megabyte capacity
2.88M, 3.5 in.	3-1/2 inch double-sided drive; 2.88 megabyte capacity

Note:

Choosing an incorrect type might cause your system to format the floppy disk improperly and you cannot access your data.



Video

This category selects the type of video adapter used for the primary system monitor. Although secondary monitors are supported, you do not have to select the type in Setup. The default setting is EGA/VGA (BIOS default, Setup default).

EGAVGA	Enhanced Graphics Adapter/Video Graphics Array. For EGA, VGA, SEGA, SVGA and PGA monitor adapters.
CGA 40	Color Graphics Adapter. Power up in 40-column mode.
CGA 80	Color Graphics Adapter. Power up in 80-column mode.
Mono	Monochrome adapter. Includes high resolution monochrome adapters.


Halt On

This category determines whether the system will stop if an error is detected during power up. The default setting is All Errors (BIOS default, Setup default).

No Errors	The system boot will not stop for any errors detected.
All Errors	The system boot will stop whenever the BIOS detects a non-fatal error.
All, But Keyboard	The system boot will not stop for a keyboard error; it will stop for all other errors.
All, But Diskette	The system boot will not stop for a disk error; it will stop for all other errors.
All, But Disk/Key	The system boot will not stop for a disk or keyboard error; it will stop for all other errors.

Memory

The base memory size, extended memory size and the other memory size cannot be altered; your computer automatically detects and displays them.



Base Memory	This refers to the amount of base or conventional memory installed on the system board.
Extended Memory	This is the amount of memory located above 1MB in the memory address map of the CPU.
Other Memory	This memory size refers to the memory located in the address space between 640K and 1024K. DOS uses this area to load device drivers to keep base memory free for application programs. The most appropriate use of this area is for Shadow RAM.

BIOS Features Setup


The BIOS Features Setup allows you to configure your system for basic operation. Some entries are defaults required by the system board, while others, if enabled, will improve the performance of your system or let you set some features according to your preference.

ROM PCI/ISA BIOS
BIOS FEATURES SETUP
AWARD SOFTWARE, INC.

Virus Warning	: Disabled	Video BIOS Shadow	: Enabled
CPU Internal Cache	: Enabled	C8000-CBFFF Shadow	: Disabled
External Cache	: Enabled	CC000-CFFFF Shadow	: Disabled
Quick Power On Self Test	: Enabled	D0000-D3FFF Shadow	: Disabled
Boot Sequence	: A, C	D4000-D7FFF Shadow	: Disabled
Swap Floppy Drive	: Disabled	D8000-DBFFF Shadow	: Disabled
Boot Up Floppy Seek	: Enabled	DC000-DFFFF Shadow	: Disabled
Boot Up NumLock Status	: On		
Typeomatic Rate Setting	: Disabled		
Typeomatic Rate (Char/Sec)	: 6		
Typeomatic Delay (Msec)	: 250		
Security Option	: Setup	ESC :Quit	↑↓←→ :Select Item
PCI/VGA Palette Snoop	: Disabled	F1 :Help	PU/PD/+/- :Modify
OS Select For DRAM>64MB	: Non-OS2	F5 :Old Values (Shift) F2	:Color
		F6 :Load BIOS Defaults	
		F7 :Load Setup Defaults	

Virus Warning

This category protects the boot sector and partition table of your hard disk drive. When this item is enabled, the Award BIOS will monitor the boot sector and partition table of the hard disk drive. If an attempt is made to write to the boot sector or partition table of the hard disk drive, the BIOS will halt the system and the following error message will appear.



! WARNING !
 Disk boot sector is to be modified
 Type "Y" to accept write or "N" to abort write
 Award Software, Inc.

After seeing this message, if necessary, you will be able to run an anti-virus program to locate and remove the problem before any damage is done.

Many disk diagnostic programs which attempt to access the boot sector table will cause the warning message to appear. If you are running such a program, we recommend that you first disable this category. Also, disable this category if you are installing or running certain operating systems like Windows 95 or the operating system may not install nor work.

Enabled	BIOS issues a warning when any program or virus sends a Disk Format command or attempts to write to the boot sector of the hard disk drive.
Disabled	No warning message will appear when the hard disk drive is accessed.

CPU Internal Cache and External Cache


These categories speed up the memory access. However, it depends on the CPU/chipset design. The default value is enabled. Enable the External Cache for better performance.

Enabled	Enables the internal/external cache.
Disabled	Disables the internal/external cache.

Quick Power On Self Test

This category speeds up Power On Self Test (POST) after you power on your system. If it is set to Enabled, the BIOS will shorten or skip some check items during POST.

Enabled	Enables quick POST.
Disabled	Normal POST.



Boot Sequence

This category determines which drive to search first for the disk operating system (i.e. DOS). The default is A, C.

A, C	The system will first search for a floppy drive and then a hard disk drive.
C, A	The system will first search for a hard disk drive and then a floppy drive.
CDROM, C, A	The system will first search for a CD-ROM drive, then a hard disk drive and then a floppy drive.
C, CDROM, A	The system will first search for a hard disk drive, then a CD-ROM drive, and then a floppy drive.

Swap Floppy Drive

Enabled	When this option is enabled and the system is booting from the floppy drive, the system will boot from drive B instead of drive A.
Disabled	When this option is disabled and the system is booting from the floppy drive, the system will boot from drive A.

Boot Up Floppy Seek

During POST, the BIOS will determine if the floppy disk drive installed is 40 or 80 tracks. 360K type is 40 tracks while 760K, 1.2M and 1.44M are all 80 tracks.

Enabled	The BIOS will check whether the floppy disk drive installed is 40 or 80 tracks. Note that the BIOS cannot distinguish between 720K, 1.2M or 1.44M drive types as they are all 80 tracks.
Disabled	The BIOS will not search for the type of floppy disk drive by track number. Note that there will not be any warning message if the drive installed is 360KB.



Boot Up NumLock Status

This allows you to determine the default state of the numeric keypad. By default, the system boots up with NumLock on.

On	The function of the numeric keypad is the number keys.
Off	The function of the numeric keypad is the arrow keys.

Security Option

This category allows you to limit access to your system and Setup, or just to Setup.

System	The system will not boot and access to Setup will be denied if the correct password is not entered at the prompt.
Setup	The system will boot, but access to Setup will be denied if the correct password is not entered at the prompt.

PCI/VGA Palette Snoop

This is used to select whether to allow MPEG ISA/VESA VGA cards to work with PCI/VGA or not.

Enabled	PCI/VGA working with MPEG ISA/VESA VGA cards.
Disabled	PCI/VGA not working with MPEG ISA/VESA VGA cards.

OS Select for DRAM > 64MB

This item allows you to access the memory that is over 64MB in OS/2. The options are: Non-OS2 and OS2.



Video BIOS Shadow

Determines whether video BIOS will be copied to RAM. Video Shadow will increase the video speed. Note that some graphics boards require that this option be disabled.

Enabled	Video shadow is enabled.
Disabled	Video shadow is disabled.

C8000-CBFFF Shadow to DC000-DFFFF Shadow

These categories determine whether option ROMs will be copied to RAM

Enabled	Optional shadow is enabled.
Disabled	Optional shadow is disabled.

Chipset Features Setup

This section allows you to configure the system based on the specific features of the chipset. This chipset manages bus speeds and access to system memory resources such as DRAM and external cache. It also coordinates communications between the conventional ISA bus and the PCI bus. These items should not be altered unless necessary. Depending on your add-in boards, you may not or should not enable some of those features. The default settings have been chosen because they provide the best operating conditions for your system. The only time you might consider making any changes would be if you discovered that data was being lost while using your system. The Chipset Features Setup screen is shown on the next page.

ROM PCI/ISA BIOS
CHIPSET FEATURES SETUP
AWARD SOFTWARE, INC.

Auto Configuration	: Enabled	System BIOS Cacheable	: Enabled
L2 Cache Update Mode	: WB	Video BIOS Cacheable	: Enabled
L2 (WB) Tag Bit Length	: 7 bits	Memory Hole At 15M-16M	: Disabled
SRAM Leadoff Timing	: 3 CK	CPU-PCI Post Write Rate	: 3 CK
DRAM Leadoff Timing	: 5 CK	Latency for CPU-PCI	: 1 CK
MDLE Delay Timing (ns)	: 5	CPU-PCI Burst Mem Write	: Enabled
DRAM RAS to CAS delay	: 3 CK	CPU-PCI Post Mem Write	: Enabled
RAS Active When Refresh	: 5 CK	VGA Shared Memory Size	: 1 MB
FP DRAM CAS Prec. Timing	: 1 CK	VGA Memory Clock (MHz)	: 55
FP DRAM RAS Prec. Timing	: 4 CK		
EDO CAS Pulse Width	: R1 W2 CK	ESC :Quit	↑↓←→ :Select Item
EDO CAS Precharge Time	: 1 CK	F1 :Help	PU/PD/+/- :Modify
EDO RAS Precharge Time	: 3 CK	F5 :Old Values (Shift) F2	:Color
ISA Bus Clock Frequency	: PCICLK/4	F6 :Load BIOS Defaults	
		F7 :Load Setup Defaults	

Auto Configuration

Enabled	The system will set the "DRAM RAS to CAS delay" to the "ISA Bus Clock Frequency" categories automatically.
Disabled	This allows you to set the "DRAM RAS to CAS delay" to the "ISA Bus Clock Frequency" categories manually.

ISA Bus Clock Frequency

PCICLK/4	ISA bus clock frequency is equal to the PCICLK of your CPU divided by 4.
PCICLK/3	ISA bus clock frequency is equal to the PCICLK of your CPU divided by 3.
7.159MHz	Regardless of the type of CPU you are using, the ISA bus clock frequency is 7.159MHz.

Note:

Refer to the "Jumper Settings for CPUs" section for the PCICLK of your CPU.

VGA Shared Memory Size

This is used to select the memory size of the onboard VGA. You may set the memory size to 0.5MB, 1MB, 1.5MB or 2MB.

Power Management Setup

The Power Management Setup allows you to configure your system to most effectively save energy.

ROM PCI/ISA BIOS
POWER MANAGEMENT SETUP
AWARD SOFTWARE, INC.

Power Management : User Define	VGA Activity : Disable
PM Control by APM : Yes	IRQ3 (COM 2) : Enable
Video Off Option : Suspend -> Off	IRQ4 (COM 1) : Enable
Video Off Method : V/H SYNC+Blank	IRQ5 (LPT 2) : Enable
Suspend Switch : Enable	IRQ6 (Floppy Disk) : Enable
Doze Speed (div by) : 2	IRQ7 (LPT 1) : Enable
Standby Speed (div by) : 3	IRQ8 (RTC Alarm) : Disable
Modem Use IRQ : 3	IRQ9 (IRQ2 Redir) : Enable
	IRQ10 (Reserved) : Enable
	IRQ11 (Reserved) : Enable
	IRQ12 (PS2 Mouse) : Enable
	IRQ13 (Coprocessor) : Enable
	IRQ14 (Hard Disk) : Enable
	IRQ15 (Reserved) : Disable
** PM Timers **	
HDD Off After : Disable	ESC :Quit ↑↓←→ :Select Item
Doze Mode : Disable	F1 :Help PU/PD/+/- :Modify
Standby Mode : Disable	F5 :Old Values (Shift) F2 :Color
Suspend Mode : Disable	F6 :Load BIOS Defaults
	F7 :Load Setup Defaults
** PM Events **	
COM Ports Activity : Enable	
LPT Ports Activity : Enable	
HDD Ports Activity : Disable	
PCI/ISA Master Act. : Enable	
IRQ 1-15 Activity : Enable	


Power Management

This category allows you to select the type (or degree) of power saving by changing the length of idle time that elapses before each of the following modes are activated: Doze Mode, Standby Mode, and Suspend Mode.

Disable (default)	No power management. Disables the Doze, Standby and Suspend modes.
Min. Power Saving	Minimum power management. Doze Mode = 40 min., Standby Mode = 40 min., and Suspend Mode = 40 min.
Max. Power Saving	Maximum power management. Doze Mode = 20 sec., Standby Mode = 20 sec., and Suspend Mode = 20 sec.
User Defined	Allows you to set each mode individually. When enabled, each option ranges from 20 sec. to 40 min.

PM Control by APM

Yes	An Advanced Power Management device will be activated to enhance the Max. Power Saving mode and stop the CPU's internal clock. (default)
Nb	The system BIOS will ignore APM when initiating the Power Management mode.



Video Off Option

Always On	The system BIOS will never turn off the screen.
Suspend -> Off	The screen is off when the system is in the Suspend mode.
Susp, Stby -> Off	The screen is off when the system is in the Standby or Suspend mode.
All Modes -> Off	The screen is off when the system is in the Doze, Standby or Suspend mode.

Video Off Method

This determines the manner in which the monitor is blanked.

V/H SYNC+ Blank	This selection will cause the system to turn off the vertical and horizontal synchronization ports and write blanks to the video buffer.
Blank Screen	This option only writes blanks to the video buffer.
DPMS	Initializes display power management signaling.


Suspend Switch

Enable	Enables the Green switch connector (J13). To use the Green switch connector, make sure to set this category to Enable.
Disable	Disables the Green switch connector (J13).

Doze Speed (div by) and Standby Speed (div by)

This is used to set the CPU speed of your system when it is in the Doze or Standby mode.

1-8	Doze or Standby speed is equal to your CPU speed divided by the number you have selected in this category. For example, if you selected "2" and your CPU speed is 66MHz, then your Doze or Standby speed is 33MHz.
-----	--



MODEM Use IRQ

This category is used to set an IRQ channel (IRQ 3, 4, 5, 7, 9, 10 or 11) for the modem installed in your system.

PM Timers


These Green PC power saving categories are user configurable only when the Power Management category is set to User Defined.

Doze Mode	When enabled and after the set time of system inactivity, the CPU clock will run according to the Doze speed that was set in the "Doze Speed (div by)" category. All other devices still operate at full speed.
Standby Mode	When enabled and after the set time of system inactivity, the CPU clock will run according to the Standby speed that was set in the "Standby Speed (div by)" category. All other devices still operate at full speed.
Suspend Mode	When enabled and after the set time of system inactivity, all devices except the CPU will be shut off.
HDD Off After	It is used to define the continuous HDD idle time that elapses before the HDD enters the power saving mode (motor off). When enabled and after the set time of system inactivity, the hard disk drive will be powered down while all other devices remain active.

PM Events and IRQ3-IRQ15

These are I/O events whose occurrence can prevent the system from entering a power saving mode or can awaken the system from such a mode. In effect, the system remains alert for anything which occurs to a device which is configured as enabled, even when the system is in a power saving mode.

When an I/O device wants to gain the attention of the operating system, it signals this by causing an IRQ to occur. When the operating system is ready to respond to the request, it interrupts itself and performs the service. When set to Enable, the activity will neither prevent the system from going into a power saving mode nor awaken it.



PNP/PCI Configuration

This section describes configuring the PCI bus system. It covers some very technical items and it is strongly recommended that only experienced users should make any changes to the default settings.

ROM PCI/ISA BIOS
PNP/PCI CONFIGURATION
AWARD SOFTWARE, INC.

Resources Control By	:Auto	PCI IRQ Active By	: Level
Reset Configuration Data	:Disabled	PCI IDE 2nd Channel	: Disabled
		PCI IDE IRQ Map To	: PCI-AUTO
		Primary IDE INT#	: A
		Secondary IDE INT#	: B
		PCI Spec. Ver 2.1	: Enabled
		ESC	:Quit
		F1	:Help
		F5	:Old Values (Shift)
		F6	:Load BIOS Defaults
		F7	:Load Setup Defaults
		↑↓←→	:Select Item
		PU/PD/+/-	:Modify
			:Color

Resources Controlled By

The Award Plug and Play BIOS has the capacity to automatically configure all of the boot and Plug and Play compatible devices. However, this capability means absolutely nothing unless you are using a Plug and Play operating system such as Windows® 95.

Auto	The system will automatically detect the settings for you. The categories that follow will not be shown on the PNP/PCI Configuration screen.
Manual	This allows you to set the IRQ/DMA (you have assigned your add-in card) to Legacy ISA or PCI/ISA PnP. For non-PnP ISA cards, select Legacy ISA. For PnP ISA or PCI cards, select PCI/ISA PnP.

Reset Configuration Data

Enabled	The BIOS will reset the configuration data automatically.
Disabled	The BIOS will not reset the configuration data.



PCI IRQ Active By

This category is used to set the method by which the PCI bus recognizes that an IRQ service is being requested by a device. Under all circumstances, you should retain the default configuration unless a different setting is needed.

PCI IDE 2nd Channel

This allows you to designate an IDE controller card inserted into one of the PCI slots as your secondary IDE controller.

Enabled	The IDE controller card is designated as the secondary IDE controller.
Disabled	No IDE controller card occupying any of the PCI slots.


PCI IDE IRQ Map To

This category is used to configure your system to the type of IDE disk controller in use.

ISA	Designates the ISA slot that is installed with an IDE controller card; that is, if you are using an IDE controller card.
PCI-Auto	The system will scan and determine the PCI slot that is installed with an IDE controller card.

Primary IDE INT# and Secondary IDE INT#

The Primary and Secondary IDE INT# categories are used to select the PCI interrupt (A, B, C, or D) that is associated with the connected hard drives.



Load BIOS Defaults

The “Load BIOS Defaults” option loads the troubleshooting default values permanently stored in the ROM chips. These settings are not optimal and turn off all high performance features. You should use these values only if you have hardware problems. Highlight this option on the main menu and press <Enter>. The message below will appear.

Load BIOS Defaults (Y/N)? N

If you want to proceed, type <Y> and press <Enter>. The default settings will be loaded.

Load Setup Defaults

The “Load Setup Defaults” option loads optimized settings from the BIOS ROM. Use the Setup default values as standard values for your system.

Highlight this option on the main menu and press <Enter>. The message below will appear.

Load Setup Defaults (Y/N)? N

Type <Y> and press <Enter> to load the Setup default values.

Integrated Peripherals

ROM PCI/ISA BIOS
INTEGRATED PERIPHERALS
AWARD SOFTWARE, INC.

Internal PCI/IDE	: Both	Onboard Serial Port 1	: 3F8/IRQ4
IDE Primary Master PIO	: AUTO	Onboard Serial Port 2	: 2F8/IRQ3
IDE Primary Slave PIO	: AUTO	UART 2 Mode	: Standard
IDE Secondary Master PIO	: AUTO		
IDE Secondary Slave PIO	: AUTO		
IDE HDD Block Mode	: Enabled		
Onboard FDD Controller	: Enabled		
Onboard Parallel Port	: 378H/IRQ7		
Onboard Parallel Mode	: SPP		
		ESC	:Quit
		F1	:Help
		F5	:Old Values (Shift) F2
		F6	:Load BIOS Defaults
		F7	:Load Setup Defaults
		↑↓←→	:Select Item
		PU/PD/+/-	:Modify
			:Color

Internal PC/IDE

Both	Enables the primary and secondary IDE controller.
Primary	Enables the primary IDE controller.
Secondary	Enables the secondary IDE controller.

IDE Primary Master/Slave PIO and IDE Secondary Master/Slave PIO

Your system supports five modes, 0 (default) to 4, which primarily differ in timing. When Auto is selected, the BIOS will select the best available mode after checking your hard drive.

Auto	The BIOS will automatically set the system according to your hard disk drive's timing.
0-4	You can select a mode that matches your hard disk drive's timing.

IDE HDD Block Mode


Enabled	The IDE HDD uses the block mode. The system BIOS will check the hard disk drive for the maximum block size the system can transfer. The block size will depend on the type of hard disk drive.
Disabled	The IDE HDD uses the standard mode.

Onboard FDD Controller

Enabled	Enables the onboard floppy disk controller.
Disabled	Disables the onboard floppy disk controller.

Onboard Parallel Port

378-IRQ7 3BC-IRQ7 278-IRQ5	Selects the I/O address and IRQ for the onboard parallel port.
Disabled	Disables the onboard parallel port.



Onboard Parallel Mode

SPP EPP/SPP ECP ECP/EPP	Selects the parallel port mode according to the type of printer device connected to your onboard parallel port.
----------------------------------	---

Onboard Serial Port 1 and Onboard Serial Port 2

3F8/IRQ4 2F8/IRQ3 3E8/IRQ4 2E8/IRQ3	Selects an address for the onboard serial port 1 and serial port 2.
Disabled	Disables the onboard serial port 1 and serial port 2.

UART 2 Mode

The G586SPB AIO system board supports IrDA function for wireless connectivity between your computer and peripheral devices. To use the IrDA function, follow the steps below.

1. Connect your IrDA cable to connector J11 of the G586SPB AIO system board. Refer to page 12 for the location of connector J11.
2. Set "UART 2 Mode" to the type of IrDA standard supported by your computer.

You may not use IrDA (J11) and the COM 2 serial port (J7) at the same time. If you are using the COM 2 serial port, set "UART 2 Mode" to Standard.

Standard	Uses the COM 2 serial port.
HPSIR	HP mode IrDA.
ASKIR	SHARP mode IrDA.



Supervisor Password

If you want to protect your system and setup from unauthorized entry, set a supervisor's password with the "System" option selected in the BIOS Features Setup.

If you want to protect access to setup only, but not your system, set a supervisor's password with the "Setup" option selected in the BIOS Features Setup. You will not be prompted for a password when you cold boot the system.

Use the arrow keys to highlight the "Supervisor Password" option and press <Enter>. The message below will appear.

Enter Password:

Type in the password. You are limited to eight characters. When done, the message below will appear:

Confirm Password:

You are asked to verify the password. Type in exactly the same password. If you type in a wrong password, you will be prompted to enter the correct password again.


To delete or disable the password function, highlight "Supervisor Password" and press <Enter>, instead of typing in a new password. Press the <Esc> key to return to the main menu.

If you forget your password, you should clear any previously set password by setting Jumper JP9 pins 2 and 3 to On. Refer to page 23 for more information.

User Password

If you want another user to have access only to your system but not to setup, set a user's password with the "System" option selected in the BIOS Features Setup.

If you want a user to enter a password when trying to access setup, set a user's password with the "Setup" option selected in the BIOS Fea-



tures Setup. Using a user's password to enter Setup allows a user to access only the "User Password" option that appears on the main screen. Access to all other options is denied.

To set, confirm, verify, disable or delete a user's password, follow the procedures described in the section "Supervisor Password". If you forget your password, refer to the procedure described in the same section.

IDE HDD Auto Detection

This option detects the hard disk parameters for the hard disk drives installed in your system. Highlight this option and press <Enter>. A screen similar to the one below will appear.

ROM PCI/ISA BIOS
CMOS SETUP UTILITY
AWARD SOFTWARE, INC.

HARD DISKS	TYPE	SIZE	CYLS	HEAD	PRECOMP	LANDZ	SECTOR	MODE
Primary Master:								
Select Primary Master Option (N=Skip): N								
OPTIONS	SIZE	CYLS	HEAD	PRECOMP	LANDZ	SECTOR	MODE	
1 (Y)	345	790	15	65535	789	57	NORMAL	

Note: Some OSes (like SCO-UNIX) must use "NORMAL" for installation

ESC: Skip

Enter your choice, and press <Enter> to accept the parameters or press <Esc> to abort. The parameters of the hard disk will be displayed in the Standard CMOS Setup.

Hard Drive Mode

The system board supports three HDD modes: Normal, LBA and Large. If your hard disk drive does not support LBA mode, the "LBA" option will not be displayed. If your HDD has 1024 or fewer cylinders, the "Large" option will not be displayed. If your hard drive is larger than 2.1GB, be sure that your operating system supports it or you may need to create separate partitions.



Normal Mode

The Normal mode is the generic access mode in which neither the BIOS nor the IDE controller will make any transformations during hard-drive access.

The maximum number of cylinders, heads and sectors for Normal mode are 1024, 16 and 63, respectively.

no. Cylinders	(1024)
x no. Heads	(16)
x no. Sectors	(63)
x bytes per sector	(512)

528 megabytes

If you set your HDD to Normal mode, the maximum accessible HDD will be 528 megabytes even though the physical size of the HDD may be greater than that.

LBA (Logical Block Addressing) Mode


The LBA mode is a HDD accessing method to overcome the 528 megabyte limitation. The number of cylinders, heads and sectors shown on the screen may not be the actual number for the HDD.

During HDD accessing, the IDE controller will transform the logical address described by the sector, head and cylinder number into its own physical address inside the HDD.

The maximum HDD size supported by the LBA mode is 8.4 gigabytes. It is obtained by the following formula.

no. Cylinders	(1024)
x no. Heads	(255)
x no. Sectors	(63)
x bytes per sector	(512)

8.4 gigabytes



Large Mode

Large mode is the extended HDD access mode supported by the system board. Some IDE HDDs have more than 1024 cylinders without LBA support (in some cases, you may not want the LBA mode). This system board provides another alternative to support these kinds of HDDs.

The BIOS tells the operating system that the number of cylinders is half the actual number and that the number of heads is double the actual number. During disk access, the reverse conversion is done by the INT13h routine.

Maximum HDD size:

	no. Cylinders	(1024)
x	no. Heads	(32)
x	no. Sectors	(63)
x	bytes per sector	(512)



1 gigabyte

Note:

To support LBA or Large mode, address translation software is included in the Award BIOS HDD Service Routine (INT13h). If you are running an operating system that bypasses the BIOS Int13 Service Routine, LBA and Large Mode may fail.

HDD Low Level Format

The Low Level Format utility is designed as a tool to save you time formatting your hard disk. It automatically looks for the necessary information of the drive you selected. This utility also searches for bad tracks and lists them for your reference. Highlight this option and press <Enter>. A screen similar to the one on the next page will appear.



Save & Exit Setup

When all the changes have been made, highlight “Save & Exit Setup” and press <Enter>. The message below will appear:

Save to CMOS and Exit (Y/N)? N

Type “Y” and press <Enter>. The following message will appear:

Reboot System (Y/N)? N

Type “Y” and press <Enter>. The modifications you have made will be written into the CMOS memory, and the system will reboot. You will once again see the initial diagnostics on the screen. If you wish to make additional changes to the setup, press <Ctrl> <Alt> <Esc> simultaneously or after memory testing is done.

Exit Without Saving

When you do not want to save the changes you have made, highlight “Exit Without Saving” and press <Enter>. The message below will appear:

Quit Without Saving (Y/N)? N

Type “Y” and press <Enter>. The system will reboot and you will once again see the initial diagnostics on the screen. If you wish to make any changes to the setup, press <Ctrl> <Alt> <Esc> simultaneously or after memory testing is done.




System Error Report

When the BIOS encounters an error that requires the user to correct something, either a beep code will sound or a message will be displayed in a box in the middle of the screen and the message **PRESS F1 TO CONTINUE, CTRL-ALT-ESC or DEL TO ENTER SETUP**, will be shown in the information box at the bottom. Enter Setup to correct the error.

POST Beep

There are two kinds of beep codes in the BIOS. One code indicates that a video error has occurred and the BIOS cannot initialize the video screen to display any additional information. This beep code consists of a single long beep followed by three short beeps. The other code indicates that a DRAM error has occurred. This beep code consists of a single long beep.

Error Messages



One or more of the following messages may be displayed if the BIOS detects an error during the POST. This list indicates the error messages for all Awards BIOSes:

CMOS BATTERY HAS FAILED


The CMOS battery is no longer functional. It should be replaced.

CMOS CHECKSUM ERROR

Checksum of CMOS is incorrect. This can indicate that CMOS has become corrupt. This error may have been caused by a weak battery. Check the battery and replace if necessary.

DISPLAY SWITCH IS SET INCORRECTLY

The display switch on the motherboard can be set to either monochrome or color. This indicates the switch is set to a different setting than indicated in Setup. Determine which setting is correct, then either turn off the system and change the jumper or enter Setup and change the VIDEO selection.



FLOPPY DISK(S) fail (80) → Unable to reset floppy subsystem.

FLOPPY DISK(S) fail (40) → Floppy type mismatch.

Hard Disk(s) fail (80) → HDD reset failed.

Hard Disk(s) fail (40) → HDD controller diagnostics failed.

Hard Disk(s) fail (20) → HDD initialization error.

Hard Disk(s) fail (10) → Unable to recalibrate fixed disk.

Hard Disk(s) fail (08) → Sector Verify failed.

Keyboard is locked out - Unlock the key

The BIOS detects that the keyboard is locked. Keyboard controller is pulled low.

Keyboard error or no keyboard present

Cannot initialize the keyboard. Make sure the keyboard is attached correctly and no keys are being pressed during the boot.

Manufacturing POST loop

System will repeat POST procedure infinitely while the keyboard controller is pull low. This is also used for M/B burn in test at the factory.

BIOS ROM checksum error - System halted


The checksum of ROM address F0000H-FFFFFFH is bad.

Memory test fail

BIOS reports memory test fail if the memory has error(s).

Driver Installation

To install the IDE and/or VGA drivers supported by the G586SPB AIO system board, please refer to the "Readme" file contained in the provided diskettes.



Chapter 4 Troubleshooting Checklist

This chapter of the manual is designed to help you with problems that you may encounter with your personal computer. To efficiently troubleshoot your system, treat each problem individually. This is to ensure accuracy on the problem detected in case a problem has multiple causes.


Some of the most common things to check when you encounter problems while using your system are listed below.

1. The power switch of each peripheral devices are turned on.
2. All cables and power cords are tightly connected.
3. The electrical outlet to which your peripheral devices are connected is working.
4. Test the outlet by plugging in a lamp or other electrical device.
5. The monitor is turned on.
6. The display's brightness and contrast controls are adjusted properly.
7. All add-in boards in the expansion slots are seated securely.
8. Any add-in boards you have installed is designed for your system and is set up correctly.

Monitor/Display

The display screen remains dark after the system is turned on.

1. Make sure that the monitor's power switch is on.
2. Check that one end of the monitor's power cord is properly attached to the monitor and the other end plugged into a working AC outlet. If necessary, try another outlet.
3. Check that the video input cable is properly attached to the monitor and the system's display adapter.
4. Adjust the brightness of the display by turning the monitor's brightness control knob.



The picture seems to be constantly moving.

1. The monitor has lost its vertical sync. Adjust the monitor's vertical sync.
2. Move away any objects, such as another monitor or fan, that may be creating a magnetic field around the display.

The screen seems to be constantly wavering.

1. If the monitor is close to another monitor, the adjacent monitor may need to be turned off. Fluorescent lights adjacent to the monitor may also cause screen wavering.

Power Supply


When the computer is turned on, nothing happens.

1. Check that one end of the AC power cord is plugged into a live outlet and the other end properly plugged into the back of the system.
2. Make sure that the voltage selection switch on the back panel is set for the correct type of voltage you are using.
3. The power cord may have a "short". Inspect the cord and install a new one if necessary.

Floppy Drive

The computer cannot access the floppy drive.

1. The floppy diskette may not be formatted. Format the diskette and try again.
2. The diskette may be write-protected. Use a diskette that is not write-protected.
3. You may be writing to a wrong drive. Check the path statement whether you are writing to the targeted drive.
4. There is not enough space left on the diskette. Use another diskette with adequate storage space.



Hard Drive

Hard disk failure.

1. Make sure the correct drive type for the hard disk drive has been entered in the BIOS.
2. If the system is configured with two hard drives, make sure the bootable (first) hard drive is configured as Master and the second hard drive configured as Slave.

Excessively long formatting period.

1. If your hard drive takes an excessively long period of time to format, it is likely a problem of the cable connection.

Parallel Port


The parallel printer doesn't respond when you try to print.

1. Make sure that the power of your printer is turned on and that the printer is on-line.
2. Make sure your software is configured for the right type of printer attached.
3. Verify that the onboard LPT port's I/O address and IRQ settings are configured correctly.
4. Verify that the attached device works by attaching it to a parallel port that is working and configured correctly. If it works, the printer can be assumed to be in good condition. If the printer remains inoperative, replace the printer cable and try again.

Serial Port

The serial device (modem, printer) doesn't output anything or is outputting garbled characters.

1. Make sure that the serial device's power is turned on and that the device is on-line.
2. Verify that the device is plugged into the correct serial port on the rear side of the computer.



3. Verify that the attached serial device works by attaching it to a serial port that is working and configured correctly. If the serial device does not work, either the cable or the serial device has a problem. If the serial device works, the problem may be due to the onboard I/O or the address setting.
4. Make sure the COM settings and I/O address are configured correctly.


Keyboard

Nothing happens when a key on the keyboard was pressed.

1. Make sure the keyboard is properly connected.
2. Make sure there are no objects resting on the keyboard and that no keys are pressed during the booting process.

System Board


1. Make sure the add-in card is seated securely in the expansion slot. If the add-in card is loose, power off the system, re-install the card and power up the system.
2. Check the jumper settings to ensure that the jumpers are properly set.
3. Verify that all SIMMs are seated securely into the SIMM sockets.
4. Make sure the SIMMs are in the correct locations.
5. If the board fails to function, place the board on a flat surface and seat all socketed components. Gently press each component into the socket.
6. If you made changes to the BIOS settings, re-enter setup and load the BIOS defaults.



Appendix A Types of Modules

The following modules have been tested with this board. Most untested brands will work but a few may fail to do so.

SIMM	Brand	Chip Number
1MBx32	Fujitsu	81C1000A-70
	OKI	M51440A-70
2MBx32	OKI	M511000B-70
	NEC	424400-60
	Micron	40447-60
	TI	TMS4400DJ-70
	Micron	MT4C4007-70 (EDO)
	Micron	MT4C4007-60 (EDO)
	NEC	4218165-60 (EDO)
4MBx32	Hitachi	7400AS-70
	Fujitsu	8117400-70
	Mitsubishi	422A06-70
	Hitachi	5117400AS-70
	NEC	4217400-60
	NEC	4217405-70 (EDO)
8MBx32	NEC	4217405-60 (EDO)
16MBx32	LGS	GM71C16100AT-60



Appendix B Memory and I/O Maps

Memory Address Map


Address	Name	Function
0000000 to 009FFFF	640KB System Board RAM	System Board Memory
00A0000 to 00BFFFF	128KB Video Display Memory	Reserved for Graphics Display Memory
00C0000 to 00E7FFF	160KB I/O Expansion ROM	Reserved for ROM on I/O Adapter Card
00E8000 to 00FFFFFF	96KB ROM on the System Board	System Board BIOS
0100000 to FFFFFFFF	Maximum Memory 256MB	System Board Memory

I/O Address Map

I/O Address	Function
00000-0001F	DMA Controller 1, 8237A-5
00020-0003F	Interrupt Controller 1, 8259A, Master
00040-0005F	Timer, 8254-2
00060-0006F	8742 (Keyboard Controller)
00070-0007F	Real-time Clock, NMI (Non-maskable Interrupt) Mask
00080-0009F	DMA Page Memory, 74LS612
000A0-000BF	Interrupt Controller 2, 8259A
000C0-000DF	DMA Controller 2, 8237A-5
000E8	Shadow RAM and Cache Control Bit
000F0	Clear Numeric Processor Extension Busy
000F1	Reset Numeric Processor Extension
000F8-000FF	Numeric Processor Extension
001F0-001F8	Fixed Disk
00200-00207	Game I/O
00278-0027F	Parallel Printer Port 2
002F8-002FF	Serial Port 2
00300-0031F	Prototype Card
00360-0036F	Reserved
00378-0037F	Parallel Printer Port 1
00380-0038F	SDLC, Bisynchronous 2
003A0-003AF	Bisynchronous 1
003E0-003BF	Monochrome Display and Printer Adapter
003C0-003CF	Reserved
003D0-003DF	Color/Graphics Monitor Adapter
003F0-003F7	Diskette Controller
003F8-003FF	Serial Port 1

Note:


The I/O address hex 0000 to 00FF are reserved for the system board I/O. Hex 0100 to 03FF are available on the I/O channels.



Appendix C Connectors

Connectors

J1	Floppy disk drive connector
J2	Feature connector
J3	Analog VGA connector
J4	Green LED connector
J5	HD LED connector
J6	Turbo LED connector
J7	Secondary serial connector
J8	Parallel printer port
J11	IrDA connector
J12	Turbo button connector
J13	Green switch connector
J14	Primary serial connector
J15	PS/2 mouse connector
J16	Reset switch connector
J17	Speaker connector
J18	Power LED/Keylock
J19	External battery connector
CON1	Secondary IDE hard disk drive connector
CON2	Primary IDE hard disk drive connector
KB1	PS/2 keyboard connector
KB2	AT keyboard connector
PL1	Power connector
KV1	Cache module slot



Pin Assignment

J4 - Green LED connector

Pin	Function
1	LED Power
2	Signal

J5 - HD LED connector

Pin	Function
1	LED Power
2	Signal

J6 - Turbo LED connector

Pin	Function
1	LED Power
2	Signal

J12 - Turbo button connector

Pin	Function
1	Ground
2	Signal

J13 - Green switch connector

Pin	Function
1	Signal
2	Ground

J16 - Reset switch connector

Pin	Function
1	Ground
2	Reset

J11 - IrDA connector

Pin	Function
1	IrTX
2	Ground
3	IrRX
4	N.C.
5	VCC

J18 - Power LED/Keylock


Pin	Function
1	Power LED
2	Reserved
3	Ground
4	Keylock Signal
5	Ground

J17 - Speaker connector

Pin	Function
1	Signal
2	Reserved
3	Ground
4	+5V

J19 - External battery connector

Pin	Function
1	External battery "+"
2	Key
3	N. C.
4	Ground



J2 - Feature connector

Pin	Function
1	PD0
2	PD1
3	PD2
4	PD3
5	PD4
6	PD5
7	PD6
8	PD7
9	Pdk
10	Blank
11	HSync
12	VSycn
13	Not Used
14	Ground
15	Ground
16	Ground
17	Video
18	Sync
19	Dck
20	Not Used
21	Ground
22	Ground
23	Ground
24	Ground
25	Not Used
26	Not Used

J15 - PS/2 mouse connector

Pin	Function
1	Mouse Data
2	Reserved
3	Ground
4	+5V
5	Mouse Clock
6	Reserved