


UMC U5S/U5SLV



* A regulator board may be needed when using these CPUs. Please refer to page 2-7 for its installation.

→ **NOTE :** Users are not encouraged to change the jumper settings not listed in this manual. Changing the jumper settings improperly may adversely affect system performance.

CPU Clock Jumper JK1-JK4

	50 MHz DX50	40 MHz DX40 DX2-80	33.3 MHz (Default) SX 33 DX 33 DX2-66 DX4-100	25 MHz SX 25 DX 25 SX2-50 DX2-50 DX4-75
JK1				
JK2				
JK3				
JK4				