


- Carefully apply enough pressure to partially seat the chip into the socket.

Ensure that all pins are properly aligned with the connectors and that there are no bent pins. If there are any bent pins, remove the chip, straighten the pin and repeat the process.

- Press the chip completely into the socket so that the pins are properly seated.

Cache SRAM Specifications and Settings

64K Cache SRAM



128K Cache SRAM

