



## Intel 486DX/SL-Series/DX2/DX4/DX4 OVERDRIVE



\* A regulator board may be needed when using this CPUs. Please refer to page 2-8 for its installation.

## Intel P24CT/P24D



\* A regulator board may be needed when using this CPUs. Please refer to page 2-8 for its installation.