

FR33

MAINBOARD MANUAL

DOC No.: M00301

Rev. : A0

Date : 12, 2000

Part No. : 25-11505-20

Chapter 1 Overview

Package Checklist	1-1
The FR33 Mainboard	1-2
Main Features	1-3
ACPI Ready	1-4

Chapter 2 Installation Procedures

Quick Reference (from Page 2-2 to 2-4)	2-2
Mainboard Layout	2-2
1). Clear CMOS Enable	2-3
2). Front Panel Block Cable Connection	2-3
3). CPU Fan Installation	2-4
1). Set System Jumpers	2-5
Clear CMOS: CLR_CMOS	2-6
2). Install Memory Modules	2-6
3). Install the CPU	2-7
4). Install Expansion Cards	2-8
5). Connect Devices	2-10
Floppy Diskette Drive Connector: FDD1	2-10
IDE HDD Device Connectors: PRIMARY, ISECONDARY	2-11
Infrared Connector: IR	2-11
ATX Power Connector: ATX	2-12
CPU Fan Connector: JFAN1	2-12
System Case Fan Connector: JFAN2	2-13
Wake-On-LAN Connector: WOL1	2-13
Wake-On-Ring Connector: WOR1	2-14
CD Audio-In Connector: CD_IN, CD_IN1	2-14
Front Panel Block Connector: J3	2-15
PS/2 Keyboard and Mouse Connector: KB, MS	2-16
Universal Serial Bus Connectors: Rear USBs and Front USBs	2-16
Serial Port Connectors: COM1, COM2	2-17
Video Graphics Accelerator Connectors: VGA	2-17

Printer Connector: LPT	2-18
Audio I/O Jacks: LINE_OUT, LINE_IN, MIC_IN, FNT_AUDIO	2-18
GAME/MIDI Connector: GAME	2-19

Chapter 3 BIOS Setup

CMOS Setup Utility	3-1
Standard CMOS Setup	3-2
Advanced BIOS Features	3-4
Advanced Chipset Features	3-8
Integrated Peripherals	3-12
Power Management Setup	3-17
PnP/PCI Configurations	3-21
PC Health Status	3-23
Frequency/Voltage Control	3-24
Load Fail-Safe Defaults	3-25
Load Optimized Defaults	3-25
Supervisor/User Password	3-26
Save and Exit Setup	3-27
Exit without Saving	3-27

Quick Reference (German)	G-1
Quick Reference (French)	F-1
Quick Reference (Spanish)	S-1
Quick Reference (Japanese)	J-1
Quick Reference (Chinese)	C-1
Quick Reference (Simplified Chinese)	SC-1

Overview

The Micro ATX, Socket 370 1stMainboard FR33 supports both the latest generation Intel® and Cyrix processors. Intel's new Celeron™FC-PGA and super fast Pentium FC-PGA Pentium®III processors are supported with Front Side Bus speeds of 66 /100/133 MHz, while Cyrix III Processors are supported at Front Side Bus speeds of 100/133 MHz.

The 1stMainboard FR33 is built around the new VIA Apollo PLE (VT8601+686A) chipset supporting both DVD and AGP 1/2x, thus ensuring photo-realistic 3D. Onboard AC97 sound ensures high quality audio, while providing the option of being disabled through the BIOS. Support for the Ultra DMA/66 protocol ensures for high data transfer speeds especially for long sequential transfers required by audio/visual applications. With 2 DIMM there is up to 1 GB available SDRAM.

Expansion is provided by 1 AMR, 1 ISA and 2 PCIs. I/O connections include 2 serial ports, 1 parallel port, 1 VGA port, 1 PS/2 mouse and keyboard connector, 4 USB connectors and 1 media connector (Line-In, Line-Out, Mic-In, Game/Midi).


Package Checklist

If you discover any item below was damaged or lost, please contact your vendor.

- The mainboard
- This user manual
- One FDD cable
- One HDD cable
- One ATA/66 cable
- Two software CDs (CD Pro, CD Plus)

The FR33 Mainboard

Chapter 1
Overview



Main Features

■ Easy Installation

BIOS with support for Plug and Play, auto detection of IDE hard drives, LS-120 drives, IDE ZIP drives, Windows 95, Windows 98, Windows ME, Windows NT, Windows 2000, and OS/2.

■ Leading Edge Chipset

VIA Apollo PLE133 (VT8601+686A) chipset provides integrated DRAM controllers with new Dynamic Power Management Architecture (DPMA), concurrent PCI (2.1), AGP 1.0 compliant and USB. It offers integrated Trident graphics, DVD-capable multimedia (MPEG-2 & AC-3) accelerators

■ Advanced High Performance Memory Controller

Accepts up to 1GB DRAM using two DIMMs of 32, 64, 128, 256, 512MB with support for lightening-fast PC133 SDRAM. *Supports FP, EDO, SDRAM.*

■ Flexible Processor Support

Onboard CPU socket supports:

Intel® Celeron FC-PGA 533/566/600/633/667/700/733/766 MHz at 66 MHz FSB; Intel® Celeron FC-PGA 800 MHz at 100 MHz FSB

Intel® Pentium III FC-PGA 500/550/600/650/700/750/800/850 MHz at 100MHz FSB

Intel® Pentium III FC-PGA 533/600/667/733/800/866/933 MHz/1 GHz at 133MHz FSB

Cyrix® III 533-650 MHz and beyond* at 100/133 MHz FSB

(*: not yet test)

■ Enhanced IDE Controller with Ultra DMA/33 and Ultra DMA/66 Support

Enhanced IDE controller features two dual-channel connectors that up to four enhanced IDE devices, including CD-ROM and Tape Backup Drives, as well as Hard Disk Drives supporting the new Ultra DMA/66 protocol. Standard PIO Mode 3, PIO Mode 4, DMA Mode 2, DMA Mode 4 devices are also supported.

■ **AMR, ISA and PCI Expansion Slots**

One AMR (Audio Modem Riser), one ISA Bus expansion slot and two PCI Bus expansion slots provided the room to install a full range of add-on cards.

■ **Compact Onboard Audio Subsystem**

Embedded in VIA 686A, the audio processor offers mainly in the aspects of dual full-duplex Direct Sound channels, PCI master interface, standard AC97 (1.0/2.0) Codec interface, direct two game ports and one MIDI port interface, and complete software driver support for Windows 95/98/NT.

■ **Super Multi Input/Output (I/O) Support**

Embedded in 686A, the features that included are dual full-duplex Direct Sound channels between system memory and AC97 link; PCI master interface with bursting capability; standard AC97 Codec interface (1.0/2.0); hardware SoundBlaster Pro for Windows DOS box and real-mode DOS legacy compatibility; plug and play with 4 IRQ, 4 DMA, and 4 I/O space options for SoundBlaster Pro and MIDI hardware.

■ **Convenient Rear Panel USB Connection Support**

Two USB ports integrated in the rear I/O panel and two USB ports for front panel connection allow convenient and high-speed Plug and Play connections to the growing number of USB compliant peripheral devices on the market.

ACPI Ready

This mainboard fully implements the new ACPI (Advanced Configuration and Power Interface) 1.0 Hardware and BIOS requirement. If you install ACPI aware of operating system, such as Windows 98, you fully utilized the power saving under ACPI. (*Windows 2000/ME Professional supports ACPI functions.*)

Installation Procedures

The mainboard has several user-adjustable jumpers on the board that allow you to configure your system to suit your requirements. This chapter contains information on the various jumper settings on your mainboard.

To set up your computer, you must complete the following steps:

- Step 1 - Set system jumpers/switches
- Step 2 - Install memory modules
- Step 3 - Install the Central Processing Unit (CPU)
- Step 4 - Install expansion cards
- Step 5 - Connect ribbon cables, cabinet wires, and power supply
- Step 6 - Set up BIOS software
- Step 7 - Install supporting software tools




WARNING: Excessive torque may damage the mainboard. When using an electric screwdriver on the mainboard, make sure that the torque is set to the allowable range of 5.0 ~ 8.0kg/cm.

Mainboard components contain very delicate Integrated Circuit (IC) chips. To prevent static electricity from harming any of the mainboard's sensitive components, you should follow the following precautions whenever working on the computer:

1. Unplug the computer when working on the inside.
2. Hold components by the edges and try not to touch the IC chips, leads, or circuitry.
3. Wear an anti-static wrist strap which fits around the wrist.
4. Place components on a grounded anti-static pad or on the bag that came with the component whenever the components are separated from the system.


Quick Reference (from Page 2-2 to 2-4)

Mainboard Layout




1). Clear CMOS Enable

Clear CMOS: CLR_CMOS



Note: If the pin cap keeps staying at pin pair 2-3, the system can not boot up.

2). Front Panel Block Cable Connection





3). CPU Fan Installation

This connector is linked to the CPU fan. When the system is in power saving mode, the CPU fan will turn off; when it reverts back to full on mode, the fan will turn back on. Without sufficient air circulation, the CPU may overheat resulting in damage to both the CPU and the mainboard.

Damage may occur to the mainboard and/or the CPU fan if these pins are used incorrectly. These are not jumpers, do not place jumper caps over these pins.

1). Set System Jumpers



Jumpers are used to select the operation modes for your system. Some jumpers on the board have three metal pins with each pin representing a different function. A “1” is written besides pin 1 on jumpers with three pins. To **set** a jumper, a black cap containing metal contacts is placed over the jumper pin/s according to the required configuration. A jumper is said to be **shorted** when the black cap has been placed on one or two of its pins. The types of jumpers used in this manual are shown below:



NOTE: Users are not encouraged to change the jumper settings not listed in this manual. Changing the jumper settings improperly may adversely affect system performance.


Clear CMOS: CLR_CMOS


The CMOS RAM is powered by the onboard button cell battery. To clear the RTC data: (1). Turn off your computer, (2). Move the jumper to CLEAR, (3). Move the jumper back to NORMAL, (4). Turn on your computer, (5). Hold down the <Delete> key during bootup and enter BIOS Setup to re-enter user preferences. **However, if the pin cap keeps staying at pin pair 2-3, the system can not boot up.**



2). Install Memory Modules

1. Locate the DIMM slots on the mainboard.
2. Install the DIMM straight down into the DIMM slot using both hands.
3. The clip on both ends of the DIMM slot will close up to hold the DIMM in place when the DIMM reaches the slot's bottom.






Press the clips with both hands to remove the DIMM.

3). Install the CPU

The mainboard has built-in Switching Voltage Regulator to support CPU Vcore autodetection. That is, It has the ability to detect and recognize the CPU voltage, clock, ratio and enables users to set up the CPU frequency from the BIOS Setup Screen. Users can adjust the frequency through “Frequency / Voltage Control” of the BIOS Setup Screen.





CAUTION:


1. The heatsink and fan you installed must be approved by CPU manufactories.
2. The mainboard must be placed on a solid place to avoid shaking while install the heatsink and fan on the board.
3. The heatsink must be contact with the CPU top tightly.
4. Never run the processor without the heatsink properly and firmly attached. PERMANENT DAMAGE WILL RESULT!

To install the CPU, do the following:

1. Lift the lever on the side of the CPU socket.
2. Handle the chip by its edges and try not to touch any of the pins.
3. Place the CPU in the socket. The chip has two notches to correctly locate the chip. Align two notches of the processor with the two triangular marks on the socket. Do not force the chip. The CPU should slide easily into the socket.
4. Swing the lever to the down position to lock the CPU in place.
5. Install the cooling fan with heatsink on top of the installed CPU.
6. Place the mainboard (with the CPU, its cooling fan, and heatsink) into the system chassis and affix it with screws.

4). Install Expansion Cards

This section describes how to connect an expansion card to one of your system's expansion slots. Expansion cards are printed circuit boards that, when connected to the mainboard, increase the capabilities of your system. For example, expansion cards can provide video and sound capabilities. The mainboard features one AMR, one ISA, and two PCI bus expansion slots.



CAUTION: Make sure to unplug the power supply when adding or removing expansion cards or other system components. Failure to do so may cause severe damage to both the mainboard and expansioncards. Always observe static electricity precautions. Please read “Handling Precautions” at the start of this manual.

To install an expansion card, follow the steps below:


1. Remove the computer chassis cover and select an empty expansion slot.
2. Remove the corresponding slot cover from the computer chassis. Unscrew the mounting screw that secures the slot cover and pull the slot cover out from the computer chassis. Keep the slot cover mounting screw nearby.
3. Holding the edge of the peripheral card, carefully align the edge connector with the expansion slot.
4. Push the card firmly into the slot. Push down on one end of the expansion card, then the other. Use this “rocking” motion until the add-on card is firmly seated inside the expansion slot.

5. Secure the board with the mounting screw removed in Step 2. Make sure that the card has been placed evenly and completely into the expansion slot.
6. Replace the computer system's cover.
7. Setup the BIOS if necessary.
8. Install the necessary software drivers for the expansion card.

5). Connect Devices


Floppy Diskette Drive Connector: FDD1

This connector provides the connection with your floppy disk drive. The red stripe of the ribbon cable must be the same side with the Pin 1.



IDE Device Connectors: PRIMARY, SECONDARY


These two connectors are used for your IDE hard disk drives, CD drives, LS-120 drives, or IDE ZIP drives. The red stripe of the ribbon cable must be the same side with the Pin 1.



**Chapter 2
Installation
Procedures**


Infrared Connector: IR

This 5-pin connector is used to link with your IR device to allow transmission of data to another system that also supports the IR feature. This module mounts to a small opening on system cases that support it.



System Case Fan Connector: CHS_FAN


The 3-pin connector allows you to link with the cooling fan on the system case to lower the system temperature.



**Chapter 2
Installation
Procedures**



Wake-On-Lan Connector: WOL1

This 3-pin connector allows the remote servers to manage the system that installed this mainboard via your network adapter which also supports WOL. When you install such a LAN card, please read its installation guide for more information.





Wake-On-Modem Connector: WOM1

This 3-pin connector allows the modem ring call to wake up your computer system by connecting a wire between this connector and your modem card that installed on the AMR slot.




CD Audio-In Connectors: CD_IN, CD_IN1

The two connectors are used for different types for CD drive audio in port.



Front Panel Block Connector: J3

This block connector includes the connectors for linking with IDE LED, power LED, sleep LED, power button, sleep button, reset button and speaker on the front panel of the system case. Please identify polarities of plug wires for the case speaker and LEDs. Please ask vendor about this information when you buy them and install the system by yourself. The plug wires polarities of these buttons will not affect the function.



Reset Button is connected to the reset button. Push this switch to reboot the system instead of turning the power button off and on.

Power Button is connected with power button. Push this switch allows the system to be turned on and off rather than using the power supply button.

Power LED is connected with the system power indicator to indicate whether the system is on/off. It will blink when the system enters suspend mode.

Speaker is connected with the case speaker.



IDE LED is connected to the IDE device indicator. This LED will blink when the hard disk drives are activated.

Sleep LED is connected with sleep mode indicator.

Sleep Button is connected with sleep button. To enter the system into power saving mode, simply press this button when the system is in full-on mode.



PS/2 Keyboard and Mouse Connector: KB, MS

These two 6-pin female (PS/2 keyboard is purple color and PS/2 mouse is green color) connectors are used for your PS/2 keyboard and PS/2 mouse.




Universal Serial Bus Connectors: Rear USBs, Front USBs

These two black connectors integrated on the edge of the board are used for linking with USB peripheral devices. This board also provides a front USB connector for linking with the two USB sockets on the front panel of some system cases. Please note your operating system must support USB features, such as MS Windows 98, MS Windows 95 OSR2.5 with USB Supplement.




The figure below is the pin assignment of the front USB connector for two front panel USB connections.




Serial Port Connectors: COM1, COM2

COM1 (9-pin D-sub male connector with teal color) and COM2 (9-pin male connector) allow you to connect with your devices that use serial ports, such as a serial mouse or an external modem.




Video Graphics Accelerator Connector: VGA

This 15-pin female D-sub blue connector is connected to your display monitor.




Printer Connector: LPT

This 25-pin D-Sub female burgundy-colored connector is attached to your printer.




Audio I/O Jacks: LINE_OUT, LINE_IN, MIC_IN, FNT_AUDIO

LINE_OUT (lime) can be connected to headphones or preferably powered speakers. LINE_IN (light blue) allows tape players or other audio sources to be recorded by your computer or played through the LINE_OUT. MIC_IN (pink) allows microphones to be connected for voice input. The mainboard also provides you with a front panel audio port connector, FNT_AUDIO, when needed. Its pin definitions were presented below.



Game/MIDI Connector: GAME

This 15-pin female gold-colored connector allows you to connect game joysticks or game pads. Connect MIDI devices for playing or editing audio.




This Page Left Blank for Note

BIOS Setup

The mainboard comes with the chip that Award BIOS that contains the ROM Setup information of your system. (This chip serves as an interface between the processor and the rest of the mainboard's components.) This section explains the information contained in the Setup program and tells you how to modify the settings according to your system configuration.

CMOS Setup Utility



A Setup program, built into the system BIOS, is stored in the CMOS. This Setup utility program allows updates to the mainboard configuration settings. It is executed when the user changes system configuration; user changes system backup battery; or the system detects a configuration error and asks the user to run the Setup program. Use the arrow keys to select and press **Enter** to run the selected program.

Standard CMOS Setup

CMOS Setup Utility - Copyright (c) 1984-2000 Award Software		Standard CMOS Features	
Date (mm:dd:yy)	Tue, Oct 24 2000	Item Help	
Time (hh:mm:ss)	18 : 3 : 57		
▶ IDE Primary Master		Menu Level ▶	
▶ IDE Primary Slave		Change the day, month,	
▶ IDE Secondary Master		year and century	
▶ IDE Secondary Slave			
Drive A	1.44M, 3.5 in.		
Drive B	None		
Floppy 3 Mode Support	Disabled		
Video	EGA/VGA		
Halt On	All Errors		
Base Memory	640K		
Extended Memory	48128K		
Total Memory	49152K		
↑↓→ Move Enter : Select +/-/PU/PD:Value F10 : Save ESC : Exit F1 : General Help F5 : Previous Values F6 : Fail-Safe Defaults F7 : Optimized Defaults			

The Standard CMOS Setup screen is displayed above. Each item may have one or more option settings. The system BIOS automatically detects memory size, thus no changes are necessary. Use the arrow keys to highlight the item and then use **PgUp** or **PgDn** keys to select the value you want in each item.

Date

To set the date, highlight the *Date* field and then press **Page Up/Page Down** or +/- keys to set the current date. Follow the month, day and year format.

Time

To set the time, highlight the *Time* field and then press **Page Up/Page Down** or +/- keys to set the current time. Follow the hour, minute, and second format.

Hard Disks

This field records the specifications for all non-SCSI hard drives installed in the system. The onboard PCI IDE connectors provide Primary and Secondary channels for connecting up to four IDE hard disks or other IDE devices. Each channel can support up to two hard disks, the first of which is the *Master* and the second is the *Slave*.

Hard Disk Configurations

Capacity:	The hard disk size. The unit is Bytes.
Cylinder:	The cylinder number of the hard disk.
Head:	The read/write head number of hard disk.
Precomp:	The cylinder number at which the disk drive changes the write current.
Landing Zone:	The cylinder number that the disk drive heads (read/write) are seated when the disk drive is parked.
Sector:	The sector number of each track defined on the hard disk.

Drive A / Drive B

This field records the types of floppy drives installed in the system. To enter the configuration value for a particular drive, highlight its corresponding field and then select the drive type using the **left-** or **right-arrow** key.

Floppy 3 Mode Support

This is a Japanese standard floppy type drive. The standard stores 1.2MB in a 3.5 inch diskette.

Video

Set this field to the type of video display card installed in the system.

Halt On

This field determines which types of errors will cause the system to halt.

Advanced BIOS Features

CMOS Setup Utility - Copyright (c) 1984-2000 Award Software
Advanced BIOS Features

<table style="width: 100%; border-collapse: collapse;"> <tr><td>Anti-Virus Protection</td><td>Enabled</td></tr> <tr><td>CPU Internal Cache</td><td>Enabled</td></tr> <tr><td>External Cache</td><td>Enabled</td></tr> <tr><td>CPU L2 Cache ECC Checking</td><td>Enabled</td></tr> <tr><td>Processor Number Feature</td><td>Enabled</td></tr> <tr><td>Quick Power On Self Test</td><td>Enabled</td></tr> <tr><td>First Boot Device</td><td>Floppy</td></tr> <tr><td>Second Boot Device</td><td>HDD-0</td></tr> <tr><td>Third Boot Device</td><td>CDROM</td></tr> <tr><td>Boot Other Device</td><td>Enabled</td></tr> <tr><td>Swap Floppy Drive</td><td>Disabled</td></tr> <tr><td>Boot Up Floppy Seek</td><td>Enabled</td></tr> <tr><td>Boot Up NumLock Status</td><td>On</td></tr> <tr><td>Gate A20 Option</td><td>Fast</td></tr> <tr><td>Typeomatic Rate Setting</td><td>Disabled</td></tr> <tr><td>x Typeomatic Rate (Chars/Sec)</td><td>6</td></tr> <tr><td>x Typeomatic Delay (Msec)</td><td>250</td></tr> <tr><td>Security Option</td><td>Setup</td></tr> <tr><td>OS Select For DRAM > 64MB</td><td>Non-OS2</td></tr> </table>	Anti-Virus Protection	Enabled	CPU Internal Cache	Enabled	External Cache	Enabled	CPU L2 Cache ECC Checking	Enabled	Processor Number Feature	Enabled	Quick Power On Self Test	Enabled	First Boot Device	Floppy	Second Boot Device	HDD-0	Third Boot Device	CDROM	Boot Other Device	Enabled	Swap Floppy Drive	Disabled	Boot Up Floppy Seek	Enabled	Boot Up NumLock Status	On	Gate A20 Option	Fast	Typeomatic Rate Setting	Disabled	x Typeomatic Rate (Chars/Sec)	6	x Typeomatic Delay (Msec)	250	Security Option	Setup	OS Select For DRAM > 64MB	Non-OS2	<table style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">Item Help</td></tr> <tr><td colspan="2">Menu Level ▶</td></tr> <tr><td colspan="2">Allows you to choose feature for IDE Hard Disk boot sector protection, if this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep</td></tr> </table>	Item Help		Menu Level ▶		Allows you to choose feature for IDE Hard Disk boot sector protection, if this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep	
Anti-Virus Protection	Enabled																																												
CPU Internal Cache	Enabled																																												
External Cache	Enabled																																												
CPU L2 Cache ECC Checking	Enabled																																												
Processor Number Feature	Enabled																																												
Quick Power On Self Test	Enabled																																												
First Boot Device	Floppy																																												
Second Boot Device	HDD-0																																												
Third Boot Device	CDROM																																												
Boot Other Device	Enabled																																												
Swap Floppy Drive	Disabled																																												
Boot Up Floppy Seek	Enabled																																												
Boot Up NumLock Status	On																																												
Gate A20 Option	Fast																																												
Typeomatic Rate Setting	Disabled																																												
x Typeomatic Rate (Chars/Sec)	6																																												
x Typeomatic Delay (Msec)	250																																												
Security Option	Setup																																												
OS Select For DRAM > 64MB	Non-OS2																																												
Item Help																																													
Menu Level ▶																																													
Allows you to choose feature for IDE Hard Disk boot sector protection, if this function is enabled and someone attempt to write data into this area, BIOS will show a warning message on screen and alarm beep																																													

↑↓→ Move Enter : Select +/-/PU/PD:Value F10 : Save ESC : Exit F1 : General Help
 F5 : Previous Values F6 : Fall-Safe Defaults F7 : Optimized Defaults

CMOS Setup Utility - Copyright (c) 1984-2000 Award Software
Advanced BIOS Features

<table style="width: 100%; border-collapse: collapse;"> <tr><td>Third Boot Device</td><td>CDROM</td></tr> <tr><td>Boot Other Device</td><td>Enabled</td></tr> <tr><td>Swap Floppy Drive</td><td>Disabled</td></tr> <tr><td>Boot Up Floppy Seek</td><td>Enabled</td></tr> <tr><td>Boot Up NumLock Status</td><td>On</td></tr> <tr><td>Gate A20 Option</td><td>Fast</td></tr> <tr><td>Typeomatic Rate Setting</td><td>Disabled</td></tr> <tr><td>x Typeomatic Rate (Chars/Sec)</td><td>6</td></tr> <tr><td>x Typeomatic Delay (Msec)</td><td>250</td></tr> <tr><td>Security Option</td><td>Setup</td></tr> <tr><td>OS Select For DRAM > 64MB</td><td>Non-OS2</td></tr> <tr><td>HDD S.M.A.R.T. Capability</td><td>Disabled</td></tr> <tr><td>Video BIOS Shadow</td><td>Enabled</td></tr> <tr><td>C8000 - C8FFF Shadow</td><td>Disabled</td></tr> <tr><td>CC000 - CFFFF Shadow</td><td>Disabled</td></tr> <tr><td>D0000 - D3FFF Shadow</td><td>Disabled</td></tr> <tr><td>D4000 - D7FFF Shadow</td><td>Disabled</td></tr> <tr><td>D8000 - DBFFF Shadow</td><td>Disabled</td></tr> <tr><td>DC000 - DFFFF Shadow</td><td>Disabled</td></tr> </table>	Third Boot Device	CDROM	Boot Other Device	Enabled	Swap Floppy Drive	Disabled	Boot Up Floppy Seek	Enabled	Boot Up NumLock Status	On	Gate A20 Option	Fast	Typeomatic Rate Setting	Disabled	x Typeomatic Rate (Chars/Sec)	6	x Typeomatic Delay (Msec)	250	Security Option	Setup	OS Select For DRAM > 64MB	Non-OS2	HDD S.M.A.R.T. Capability	Disabled	Video BIOS Shadow	Enabled	C8000 - C8FFF Shadow	Disabled	CC000 - CFFFF Shadow	Disabled	D0000 - D3FFF Shadow	Disabled	D4000 - D7FFF Shadow	Disabled	D8000 - DBFFF Shadow	Disabled	DC000 - DFFFF Shadow	Disabled	<table style="width: 100%; border-collapse: collapse;"> <tr><td colspan="2" style="text-align: center;">Item Help</td></tr> <tr><td colspan="2">Menu Level ▶</td></tr> </table>	Item Help		Menu Level ▶	
Third Boot Device	CDROM																																										
Boot Other Device	Enabled																																										
Swap Floppy Drive	Disabled																																										
Boot Up Floppy Seek	Enabled																																										
Boot Up NumLock Status	On																																										
Gate A20 Option	Fast																																										
Typeomatic Rate Setting	Disabled																																										
x Typeomatic Rate (Chars/Sec)	6																																										
x Typeomatic Delay (Msec)	250																																										
Security Option	Setup																																										
OS Select For DRAM > 64MB	Non-OS2																																										
HDD S.M.A.R.T. Capability	Disabled																																										
Video BIOS Shadow	Enabled																																										
C8000 - C8FFF Shadow	Disabled																																										
CC000 - CFFFF Shadow	Disabled																																										
D0000 - D3FFF Shadow	Disabled																																										
D4000 - D7FFF Shadow	Disabled																																										
D8000 - DBFFF Shadow	Disabled																																										
DC000 - DFFFF Shadow	Disabled																																										
Item Help																																											
Menu Level ▶																																											

↑↓→ Move Enter : Select +/-/PU/PD:Value F10 : Save ESC : Exit F1 : General Help
 F5 : Previous Values F6 : Fall-Safe Defaults F7 : Optimized Defaults

Anti-Virus Protection

This feature starts the virus scan tool to detect if boot virus in boot sector of the first hard disk drive when booting up.

The options are: Enabled, Disabled.

CPU Internal Cache

When enabled, improves the system performance. Disable this item when testing or trouble-shooting. The options are: Enabled, Disabled.

External Cache

When enabled, supports an optional cache SRAM. This feature allows you to disable the cache function when the system performance is unstable to run some software. The options are: Enabled, Disabled.

Processor Number Feature

If a Pentium III processor is installed on this mainboard, the system BIOS will allow other utilities to access the Intel Pentium III serial number while this feature set at Enabled. The options are: Enabled, Disabled.

Quick Power On Self Test

When enabled, allows the BIOS to bypass the extensive memory test.

The options are: Enabled, Disabled.

First Boot Device

This feature allows user to select the boot device priority. The options are: Floppy, LS120, HDD-0, SCSI, CDROM, HDD-1, HDD-2, HDD-3, ZIP100, USB-FDD, USB-ZIP, USB-CDROM, USB-HDD, LAN, Disabled.

Second Boot Device

This feature allows user to select the boot device priority. The options are: Floppy, LS120, HDD-0, SCSI, CDROM, HDD-1, HDD-2, HDD-3, ZIP100, USB-FDD, USB-ZIP, USB-CDROM, USB-HDD, LAN, Disabled.

Third Boot Device

This feature allows user to select the boot device priority. The options are: Floppy, LS120, HDD-0, SCSI, CDROM, HDD-1, HDD-2, HDD-3, ZIP100, USB-FDD, USB-ZIP, USB-CDROM, USB-HDD, LAN, Disabled.

Boot Other Device

This feature allows user to select the boot device priority.
The options are: Enabled, Disabled.

Swap Floppy Drive

Allows you to switch the order in which the operating system accesses the floppy drives during boot up.
The options are: Enabled, Disabled.

Boot Up Floppy Seek

When enabled, assigns the BIOS to perform floppy diskette drive tests by issuing the time-consuming seek commands.
The options are: Enabled, Disabled.

Boot Up Numlock Status

When set to On, allows the BIOS to automatically enable the Num Lock Function when the system boots up. The options are: On, Off.

Gate A20 Option

When set at Fast, allows a faster access response under Protected mode.
The options are: Fast, Normal.

Typematic Rate Setting

The term typematic means that when a keyboard key is held down, the character is repeatedly entered until the key is released.
The options are: Disabled, Enabled.

Typematic Rate (Chars/Sec)

This feature is available only if the above item, Typematic Rate Setting, is set at Enabled. Sets the rate of a character repeat when the key is held down. The options are: 6, 8, 10, 12, 15, 20, 24, 30.

Typematic Delay (Msec)

This feature is available only if the item, Typematic Rate Setting, is set at Enabled. Sets the delay time before a character is repeated.
The options are: 250, 500, 750, 1000 millisecond.

Security Option

Allows you to set the security level of the system.
The options are: Setup, System.

OS Select For DRAM > 64MB

If your operating system (OS) is OS/2, select the option OS2. Otherwise, stay with the default setting Non-OS2.
The options are: Non-OS2, OS2.

HDD S.M.A.R.T. Capability

S.M.A.R.T. stands for Self-Monitoring and Analysis Reporting Technology which allows your hard disk drive to report any read/write errors and issues a warning with LDCM installed.
The options are: Disabled, Enabled.

Video BIOS Shadow

Allows the BIOS to copy the video ROM code of the add-on video card to the system memory for faster access.
The options are: Enabled, Disabled.

C8000-CBFFF to DC000-DFFFF Shadow

These fields are used for shadowing other expansion card ROMs. If you install other expansion cards with ROMs on them, you will need to know which addresses the ROMs use to shadow them specifically. Shadowing a ROM reduces the memory available between 640KB and 1024KB by the amount used for this purpose. The options are: Disabled, Enabled.

Advanced Chipset Features

CMOS Setup Utility - Copyright (c) 1984-2000 Award Software

Advanced Chipset Features

Bank 0/1 DRAM Timing	SDRAM 8/10ns	<p>Item Help</p> <hr/> <p>Menu Level ▶</p>
Bank2/3 DRAM Timing	SDRAM 8/10ns	
SDRAM Cycle Length	3	
DRAM Clock	Host CLK	
Memory Hole	Disabled	
P2C/C2P Concurrency	Enabled	
Fast R-W Turn Around	Enabled	
System BIOS Cacheable	Enabled	
Video RAM Cacheable	Disabled	
Frame Buffer Size	8M	
AGP Aperture Size	64M	
AGP-4X Mode	Enabled	
OnChip USB	Enabled	
USB Keyboard Support	Disabled	
OnChip Sound	Enable	
OnChip Modem	Disable	
CPU to PCI Write Buffer	Enabled	
PCI Dynamic Bursting	Enabled	
PCI Master 0 WS Write	Enabled	

↑↓ → Move Enter : Select +/-/PU/PD:Value F10 : Save ESC : Exit F1 : General Help
 F5 : Previous Values F6 : Fail-Safe Defaults F7 : Optimized Defaults

CMOS Setup Utility - Copyright (c) 1984-2000 Award Software

Advanced Chipset Features

P2C/C2P Concurrency	Enabled	<p>Item Help</p> <hr/> <p>Menu Level ▶</p> <p>Enabled adds a parity check to the boot-up memory tests. Select Enabled only if the system DRAM contains parity</p>
Fast R-W Turn Around	Enabled	
System BIOS Cacheable	Enabled	
Video RAM Cacheable	Disabled	
Frame Buffer Size	8M	
AGP Aperture Size	64M	
AGP-4X Mode	Enabled	
OnChip USB	Enabled	
USB Keyboard Support	Disabled	
OnChip Sound	Enable	
OnChip Modem	Disable	
CPU to PCI Write Buffer	Enabled	
PCI Dynamic Bursting	Enabled	
PCI Master 0 WS Write	Enabled	
PCI Delay Transaction	Enabled	
PCI#2 Access #1 Retry	Enabled	
AGP Master 1 WS Write	Disabled	
AGP Master 1 WS Read	Disabled	
Memory Parity/ECC Check	Disabled	

↑↓ → Move Enter : Select +/-/PU/PD:Value F10 : Save ESC : Exit F1 : General Help
 F5 : Previous Values F6 : Fail-Safe Defaults F7 : Optimized Defaults

Bank 0/1 DRAM Timing; Bank 2/3 DRAM Timing

This feature allows you to select the DRAM read/write speed.
The options are: SDRAM 8/10ns, Normal, Medium, Fast, Turbo

SDRAM Cycle Length

This item will function only when SDRAM DIMM/s are installed on the mainboard (BIOS auto detection). If the CAS latency of your SDRAM DIMM is 2, set it at 2 to enhance your system performance. If the CAS latency of your SDRAM DIMM is 3, stay with the default setting, 3.
The options are: Auto, 3, 2.

DRAM Clock

The feature allows users to select the DRAM clock.
The options are: Host CLK, HCLK-33M, HCLK+33M.

Memory Hole

When you install a Legacy ISA card, this feature allows you to select the memory hole's address range of the ISA cycle when the processor accesses the selected address area. Please read your card manual for detail information. When disabled, the memory hole at the 14MB (or 15MB) address will be treated as a DRAM cycle when the processor accesses the 15~16MB address area. The options are: Disabled, 15M - 16M.

P2C/C2P Concurrency

This feature allows users to set PCI/AGP Master-to-CPU/ CPU-to-PCI/ AGP Slave concurrent. The options are: Enabled, Disabled.

Fast R-W Turn Around

It allows users to set DRAM fast read-to-write turn around.
The options are: Enabled, Disabled.

System BIOS Cacheable

When enabled, allows the ROM area F000H-FFFFH to be cacheable when cache controller is activated. The options are: Enabled, Disabled.

Video RAM Cacheable

When set at Enabled, allows the system to use the video RAM from cache RAM, instead of the slower DRAMs or ROMs.

The options are Enabled, Disabled.

Frame Buffer Size

It allows user to select the frame buffer size of VGA share memory.

The options are 2M, 4M, 8M.

AGP Aperture Size

It allows you to select the main memory frame size for AGP use.

The options are 128M, 64M, 32M, 16M, 8M, 4M.

AGP-4X Mode

This feature allows user to select the AGP mode be to 2x or 4x when an AGP add-in card installed. However, when set at Enabled and the AGP card only support 1x mode, the system will fall back 1x mode automatically. The options are: Enabled, Disabled.

OnChip USB

When enabled, this feature allows you to use the onboard USB feature.

The options are: Enabled, Disabled.

USB Keyboard Support

This feature will appear only if the above item Onchip USB is set at Enabled. Set this feature to Enabled to use a USB keyboard with your system.

The options are: Disabled, Enabled.

OnChip Sound

This feature allows you to disable the onboard audio function if needed.

The options are: Enable, Disable.

OnChip Modem

This feature allows you to disable the embedded modem function if needed.

The options are: Enable, Disable.

CPU to PCI Write Buffer

When enabled, allows data and address access to the internal buffer of the system controller; so the processor can be released from the waiting state. The options are: Enabled, Disabled.

PCI Dynamic Bursting

When enabled, the PCI controller allows Bursting PCI transfer if the consecutive PCI cycles come with the address falling in same 1KB space. This improves the PCI bus throughput.

The options are: Enabled, Disabled.

PCI Master 0 WS Write

When enabled, allows a zero-wait-state-cycle delay when the PCI master drive writes data to DRAM. The options are: Enabled, Disabled.

PCI Delay Transaction

Enable this feature to abort the current CPI master cycle and to accept the new PCI master request, it reaccepts the original PCI master and returns the PCI data phase to the original PCI master.

The options are: Disabled, Enabled.

PCI#2 Access #1 Retry

When enabled, the AGP (PCI#2) access to PCI (PCI#1) will be retried until the maximum count. The options are: Disabled, Enabled.

AGP Master 1 WS Write

When enabled, the AGP bus master write access to DRAMs will add one wait-state cycle. The options are: Disabled, Enabled.

AGP Master 1 WS Read

When enabled, the AGP bus master read access to the DRAMs will add one wait-state cycle. The options are: Disabled, Enabled.

Memory Parity/ECC Check

This field enables BIOOS to perform automatic memory checking upon detection of ECC or parity DRAM. The options are: Disabled, Enabled.

Integrated Peripherals

CMOS Setup Utility - Copyright (c) 1984-2000 Award Software

Integrated Peripherals

OnChip IDE Channel0	Enabled	▲ ▼ Menu Level ►
OnChip IDE Channel1	Enabled	
IDE Prefetch Mode	Enabled	
Primary Master PIO	Auto	
Primary Slave PIO	Auto	
Secondary Master PIO	Auto	
Secondary Slave PIO	Auto	
Primary Master UDMA	Auto	
Primary Slave UDMA	Auto	
Secondary Master UDMA	Auto	
Secondary Slave UDMA	Auto	
Init Display First	PCI Slot	
IDE HDD Block Mode	Enabled	
Onboard FDD Controller	Enabled	
Onboard Serial Port 1	3F8/IRQ4	
Onboard Serial Port 2	2F8/IRQ3	
UART 2 Mode	Standard	
x IR Function Duplex	Half	
x TX, RX Inverting enable	No, Yes	

↑↓ → Move Enter ; Select +/-/PU/PD: Value F10 : Save ESC ; Exit F1 : General Help
 F5 : Previous Values F6 : Fall-Safe Defaults F7 : Optimized Defaults

CMOS Setup Utility - Copyright (c) 1984-2000 Award Software

Integrated Peripherals

IDE HDD Block Mode	Enabled	▲ ▼ Menu Level ►
Onboard FDD Controller	Enabled	
Onboard Serial Port 1	3F8/IRQ4	
Onboard Serial Port 2	2F8/IRQ3	
UART 2 Mode	Standard	
x IR Function Duplex	Half	
x TX, RX Inverting enable	No, Yes	
Onboard Parallel Port	378/IRQ7	
Onboard Parallel Mode	Normal	
ECP Mode Use DMA	3	
Parallel Port EPP Type	EPP1.7	
Onboard Legacy Audio	Enabled	
Sound Blaster	Disabled	
SB I/O Base Address	220H	
SB IRQ Select	IRQ 5	
SB DMA Select	DMA 1	
MPU-401	Disabled	
MPU-401 I/O Address	330-333H	
Game Port (200-207H)	Enabled	

↑↓ → Move Enter ; Select +/-/PU/PD: Value F10 : Save ESC ; Exit F1 : General Help
 F5 : Previous Values F6 : Fall-Safe Defaults F7 : Optimized Defaults

OnChip IDE Channel0

When enabled, allows you to use the onboard primary PCI IDE. If a hard disk controller card is used, set at Disabled.

The options are: Enabled, Disabled.

OnChip IDE Channel1

When enabled, allows you to use the onboard secondary PCI IDE. If a hard disk controller card is used, set at Disabled.

The options are: Enabled Disabled.

IDE Prefetch Mode

When set at Enabled, it allows data to be posted to and prefetched from the primary IDE data ports. Data prefetching is initiated when a data port read occurs. The read prefetch eliminates latency to the IDE data ports and allows them to be performed back to back for the highest possible PIO data transfer rates. The first data port read of a sector is called the demand read. Subsequent data port reads from the sector are called prefetch reads. The demand read and all prefetch reads must be of the same size (16 or 32 bits).

The options are: Enabled, Disabled.

Primary Master PIO

Allows an automatic or a manual configuration of the PCI primary IDE hard disk (master) mode. The options are: Auto, Mode 0, Mode 1, Mode 2, Mode 3, Mode 4.

Primary Slave PIO

Allows an automatic or a manual configuration of the PCI primary IDE hard disk (slave) mode. The options are: Auto, Mode 0, Mode 1, Mode 2, Mode 3, Mode 4.

Secondary Master PIO

Allows an automatic or a manual configuration of the PCI secondary IDE hard disk (master) mode. The options are: Auto, Mode 0, Mode 1, Mode 2, Mode 3, Mode 4.

Secondary Slave PIO

Allows an automatic or a manual configuration of the PCI secondary IDE hard disk (slave) mode. The options are: Auto, Mode 0, Mode 1, Mode 2, Mode 3, Mode 4.

Primary Master UDMA

Allows you to select the first PCI IDE channel of the first master hard disk mode or to detect it by the BIOS if the hard disk supports UDMA (Ultra DMA, faster than DMA). The options are: Auto, Disable.

IDE Primary Slave UDMA

Allows you to select the first PCI IDE channel of the first slave hard disk mode or to detect it by the BIOS if the hard disk supports UDMA (Ultra DMA, faster than DMA). The options are: Auto, Disable.

IDE Secondary Master UDMA

Allows you to select the second PCI IDE channel of the secondary master hard disk mode or to detect it by the BIOS if the hard disk supports UDMA (Ultra DMA, faster than DMA). The options are: Auto, Disable.

IDE Secondary Slave UDMA

Allows you to select the second PCI IDE channel of the secondary slave hard disk mode or to detect it by the BIOS if the hard disk supports UDMA (Ultra DMA, faster than DMA). The options are: Auto, Disable.

Init Display First

When you install an AGP VGA card and a PCI VGA card on the board, this feature allows you to select the first initiation of the monitor display from which card. The options are: PCI Slot, AGP.

IDE HDD Block Mode

When enabled, the system executes read/write requests to hard disk in block mode. The options are: Enabled, Disabled.

Onboard FDD Controller

When enabled, the floppy diskette drive (FDD) controller is activated. The options are: Enabled, Disabled.

Onboard Serial Port 1 / Onboard Serial Port 2

If the serial port 1/2 uses the onboard I/O controller, you can modify your serial port parameters. If an I/O card needs to be installed, COM3 and COM4 may be needed. The options are: Disabled, 3F8/IRQ4, 2F8/IRQ3, 3E8/IRQ4, 2E8/IRQ3, Auto.

UART 2 Mode

Select an operating mode for the second serial port. Set at Standard, if you use COM2 as the serial port as the serial port, instead as an IR port. The options are: Standard, ASK-IR, HPSIR.

IR Function Duplex

This feature is available only if the above item, UART2 Mode, is set at ASKIR or HPSIR. It allows you to select the infrared data transaction way. The options are: Half, Full.

TX, RX Inverting Enable

This feature is available only if the above item, UART2 Mode, is set at ASKIR or HPSIR. It allows you to select the active signals of the reception end and the transmission end. The options are: No, Yes; Yes, Yes; No, No; Yes, No.

Onboard Parallel Port

Allows you to select from a given set of parameters if the parallel port uses the onboard I/O controller. The options are: 378/IRQ7, 278/IRQ5, 3BC/IRQ7, Disabled.

Onboard Parallel Port Mode

Allows you to connect with an advanced printer. The options are: Normal, EPP, ECP, ECP/ ECP.

ECP Mode Use DMA

This feature allows you to select Direct Memory Access (DMA) channel if the ECP mode selected. The options are: 3, 1.

Parallel Port EPP Type

This feature allows you to select the EPP type for the parallel port.
The options are: EPP1.9, EPP1.7.

Onboard Legacy Audio

Allow use the audio function under DOS mode.
The options are: Enabled, Disabled.

Sound Blaster

This feature allows you to select the Sound Blaster, if the onboard Legacy audio chosen. The options are: Enabled, Disabled.

SB I/O Base Address

This feature allows you to select the SB I/O base address, if the onboard Legacy audio chosen. The options are: 220H, 240H, 260H, 280H.

SB IRQ Select

This feature allows you to select the SB IRQ, if the onboard Legacy audio chosen. The options are: IRQ 5, IRQ 7, IRQ 9, IRQ 10.

SB DMA Select

This feature allows you to select the SB DMA channel, if the onboard Legacy audio chosen.
The options are: DMA 1, DMA 2, DMA 3, DMA0.

MPU-401

This feature allows you to select MPU-401, if the onboard Legacy audio chosen. The options are: Disabled, Enabled.


MPU-401 I/O Address

This feature allows you to select the MPU-401 I/O address, if the onboard Legacy audio chosen.
The options are: 300-303H, 310-313H, 320-323H, 330-333H.

Game Port (200-207H)

This feature allows you to select the game port (200-207H), if the onboard Legacy audio chosen.
The options are: Enabled, Disabled.

Power Management Setup



ACPI function

This item allows user to select to report or not report ACPI function for operating system use. The options are: Enabled, Disabled.

Power Management

This item allows you to adjust the power management features.

Select User Define for configuring your own power management features. Min Saving initiates all predefined timers in their minimum values. Max Saving, on the other hand, initiates maximum values. The options are: User Define, Min Saving, Max Saving.

HDD Power Down

The option lets the BIOS turn the HDD motor off when system is in Suspend mode. Selecting 1 Min..15 Min allows you define the HDD idle time before the HDD enters the Power Saving Mode.

The options 1 Min..15 Min will not work concurrently. When HDD is in the Power Saving Mode, any access to the HDD will wake the HDD up.

The options are: Disable, 1 Min..15 Min.

Doze Mode

When disabled, the system will not enter Doze mode. The specified time option defines the idle time the system takes before it enters Doze mode. The options are: Disable, 1, 2, 4, 6, 8, 10, 20, 30, 40 Min, 1 Hour.

Suspend Mode

When disabled, the system will not enter Suspend mode. The specified time option defines the idle time the system takes before it enters Suspend mode. The options are: Disable, 1, 2, 4, 6, 8, 10, 20, 30, 40 Min, 1 Hour.

ACPI Suspend Type

This item allows you to select ACPI suspend types. The options are: S1(POS), S3 (STR).

PM Control by APM

The option No allows the APM (Advanced Power Management) specification be ignored. Selecting Yes will allow the BIOS wait for APM's prompt before it enters Doze mode, Standby mode, or Suspend mode. If the APM is installed, it will prompt the BIOS to set the system into power saving mode when all tasks are done. The options are: No, Yes.

Video Off Option

This feature provides the selections of the video display power saving mode. The option Suspend - Off allows the video display to go blank if the system enters Suspend mode. The option All Modes - Off allows the video display to go blank if the system enters Doze mode or Suspend mode. The option Always On allows the video display to stay in Standby mode even when the system enters Doze or Suspend mode.

The options are: Suspend - Off, All Modes -> Off, Always On.

Video Off Method

The option *V/H SYNC+Blank* allows the BIOS to blank off screen display by turning off the V-Sync and H-Sync signals sent from add-on VGA card. *DPMS Support* allows the BIOS to blank off screen display by your add-on VGA card which supports DPMS (Display Power Management Signaling function). *Blank Screen* allows the BIOS to blank off screen display by turning off the red-green-blue signals.

The options are: Blank Screen, V/H SYNC+Blank, DPMS Support.

MODEM Use IRQ

This feature allows you to select the IRQ# to meet your modem's IRQ#. The options are: NA, 3, 4, 5, 7, 9, 10, 11.

Soft-Off by PWR-BTTN

The selection Delay 4 Sec. will allow the system shut down after 4 seconds after the power button is pressed. The selection Instant-Off will allow the system shut down immediately once the power button is pressed. The settings are: Delay 4 Sec, Instant-Off.

State After Power Failure

The item allows you to select the state that your personal computer returns to after a power failure. If set at Off, the system will not boot after a power failure. If set On, the system will restart after power failure. The settings are: Auto, On, Off.

VGA

When set at On, any VGA activity will awake the system. The options are: OFF, ON.

LPT & COM

When LPT/COM is selected, any access of LPT and COM ports will awake the system. Likewise, either LPT or COM is chosen, the system will be awoken by any activity of LPT or COM port. The options are: LPT/COM, LPT, COM, NONE.

HDD & FDD

When it is set at ON, any access happened at hard drives and floppy drives will awake the system. The options are: OFF, ON.

PCI Master

To set this feature at ON activates that Power Management feature (PM) wake-up event for the PCI bus master card. The options are: OFF, ON.

PowerOn by PCI Card

When set at Enabled, any PCI-PM event awakes the system from a PCI-PM controlled state.

The options are Disabled, Enabled.

Modem Ring Resume

An input signal on the serial Ring Indicator (RI) line (in other words, an incoming call on the modem) awakens the system from a soft off state.

The options are: Enabled, Disabled.

RTC Alarm Resume

Enabled allows you to set the time the system will be turned on from the system power-off status. The options are: Enabled, Disabled.

Date (of Month)

This feature allows you to set the day of the alarm starts when the RTC Alarm Resume From Soft Off is set to be Enabled. The options are: 0, 1..31.

Resume Time (hh:mm:ss)

If an ATX power supply is installed and when RTC Alarm Resume is Enabled, this feature allows you to set the time of the alarm starts when the RTC Alarm Resume From Soft Off is set to be Enabled.

The options are: 7: 0: 0. hh (*hour*) - 0, 1, 2,..., 23; mm (*minute*) - 0, 1, 2,..., 59; ss (*second*) - 0, 1, 2,..., 59.

Primary INTR

If set at ON, the Primary interrupt (the Primary option in the feature of IRQ# Acitivity) will make the power management wake up the system.

The options are: ON, OFF.


IRQs Activity Monitoring

After the time period which you set, the system advances from doze mode to suspend mode in which the CPU clock stops and the screen display is off. At this moment, if the IRQ activity occurs, the system goes back to full-on mode directly.

If the IRQ activity which is defined as Non Primary takes place, the system remains off until the corresponding IRQ handler finishes.

The options of IRQ 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15 are: Enabled, Disabled.

PnP/PCI Configurations



PNP OS Installed

If your operating system is a Plug-and-Play one, such as Windows NT, Windows 95, select Yes. The options are: No, Yes.

Reset Configuration Data

Enabling it to reset the system Extended System Configuration Data (ESCD) when you exit Setup if you have installed a new add-on card and the system reconfiguration has caused such a serious conflict that the operating system can not boot. The options are: Disabled, Enabled.

Resources Controlled By

If set at Auto, the BIOS arranges all system resources. If there exists conflict, select Manual. The options are: Auto (ESCD), Manual.

If the manual options, after the feature IRQ Resources being pressed, of **IRQ- Assigned To** are: PCI Device, Reserved. When resources were controlled manually, assign each system interrupt a type, depending on each device type to use the interrupt.

PCI/VGA Palette Snoop

Set this feature to be enabled if any ISA adapter card installed in the system requires the VGA palette snoop function.

The options are: Disabled, Enabled.

Assign IRQ For VGA

If your PCI VGA card does not need an IRQ, select Disabled; therefore, an IRQ can be released for the system use.


The options are: Enabled, Disabled.

Assign IRQ For USB

If you do not use USB devices, select Disabled; therefore, an IRQ can be released for the system use.

The options are: Enabled, Disabled.


PC Health Status



[Current CPU Temp.](#) / [Current System Temp.](#) / [Current CPUFAN1 Speed](#)
/ [Current CPUFAN2 Speed](#) / [Vcore](#) / [2.5V](#) / [3.3V](#) / [5V](#) / [12V](#)

These items allow end users and technicians to monitor data provided by the BIOS on this mainboard. It is not user-configurable.

Frequency/Voltage Control



Auto Detect DIMM/PCI Clk

When enabled, BIOS will detect the PCI slot and DIMM slot. If no any device in, BIOS will auto disable its clock.

The options are: Enabled, Disabled.

Spread Spectrum


This feature is used to set the spread Spectrum to be center spread type or down spread type. The options are: Disabled, Enabled.

CPU Host Clock (CPU/PCI)

This feature allows you to set the CPU/PCI clock frequency. The default setting, Default, will detect your CPU/PCI clock frequency automatically. If you set a inappropriate option which leads to a booting problem, keep pressing the Insert key until the display appears will solve it.


The option list offered all combinations that supported by this mainboard.

Load Fail-Safe Defaults




This submenu is selected to diagnose the problem after the computer boots, if the computer will not boot. These settings do not give optimal performance.

Load Optimized Defaults



This submenu is selected for default settings which provide the best system performance.


Supervisor/User Password



To enable the Supervisor/User passwords, select the item from the Standard CMOS Setup. You will be prompted to create your own password. Type your password up to eight characters and press Enter. You will be asked to confirm the password. Type the password again and press Enter. To disable password, press Enter twice when you are prompted to enter a password. A message appears, confirming the password is disabled.

Under the BIOS Feature Setup, if *Setup* is selected under the Security Option field and the Supervisor/User Password is enabled, you will be prompted password every time you try to enter the CMOS Setup Utility. If *System* is selected and the Supervisor/User Password is enabled, you will be requested to enter the Password every time when you reboot the system or enter the CMOS Setup utility.

Save and Exit Setup



After you have made changes under Setup, press Esc to return to the main menu. Move cursor to Save and Exit Setup or press F10 and then press Y to change the CMOS Setup. If you did not change anything, press Esc again or move cursor to Exit Without Saving and press Y to retain the Setup settings. The following message will appear at the center of the screen to allow you to save data to CMOS and exit the setup utility: **SAVE to CMOS and EXIT (Y/N)?**

Exit without Saving

If you select this feature, the following message will appear at the center of the screen to allow you to exit the setup utility without saving CMOS modifications: **Quit Without Saving (Y/N)?**

This Page Left Blank for Note

Handling Precautions

Warning:

1. Static electricity may cause damage to the integrated circuits on the mainboard. Before handling any motherboard outside of its protective packaging, ensure that your body is not electrostatically charged.
2. There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or an equivalent type of battery as recommended by the manufacturer.
3. Discard used batteries according to the manufacturer's instructions.

Observe the following basic precautions when handling the motherboard or other computer components:

- Wear a static wrist strap which fits around your wrist and is connected to a natural earth ground.
- Touch a grounded or anti-static surface or a metal fixture such as a water pipe.
- Ensure add-on cards, mainboards, and models do not come into contact with the golden fingers connectors, plugged into the expansion slot.

The above methods prevent static build-up and allow it to be discharged properly.

Trademark

All trademarks mentioned in this manual are registered property of the respective owners.

Handling Precautions

This manual may not, in whole or in part, be photocopied, reproduced, transcribed, translated, or transmitted in whatever form without the written consent of the manufacturer, except for copies retained by the purchaser for personal archival purposes.
