



LPX54 PCI/ISA

Integrated System Board Manual

Document Number: 06-00216-01, Rev. 3A

May 1995

232 E Warren Ave., Fremont, CA 94539-7085

Copyright Notices

Micronics Computers, Inc.

The information contained in the LPX54 system board manual has been carefully checked and is believed to be accurate. Micronics assumes no responsibility for any inaccuracies that may be contained in this document. Micronics makes no commitments to update or to keep the information in this manual at a current level when changes are made to the product.

Micronics reserves the right to make improvements to this document and/or product at any time and without notice.

All Rights Reserved. No part of this document may be photocopied, reproduced, translated, or reduced to any medium or machine form without prior, written consent from Micronics.

COPYRIGHT (C) 1994, Micronics Computers, Inc.
232 E. Warren Ave., Fremont, California 94539-7085

Portions of the Manual

Portions of this manual were copied (with permission) from Phoenix Technologies, Ltd. and Micro Computer Systems, Inc. All rights reserved.


Trademarks

IBM is a registered trademark of International Business Machines. Microsoft, Microsoft Word, Windows are registered trademarks of Microsoft Corporation. Intel and PCI are registered trademarks of Intel Corporation. UNIX is a registered trademark of AT&T Corporation. Lotus 1-2-3 is a registered trademark of Lotus Development Corp. MCS is a trademark of Micro Computer Systems. All other product names mentioned herein are used for identification purposes only and may be the trademarks of their respective companies.

Micronics Quick Installation

We know that many experienced people prefer to read as little of the documentation as possible. If this sounds like you, here's the short form:

1. Make backup copies of your installation and configuration diskettes.
2. Ground yourself to prevent damaging static discharge, then remove the LPX54 from its packaging.
3. Configure and verify the system board's jumper settings. (See Jumper Settings in Chapter 2)
4. Install the CPU and the system memory (Chapter 3).
5. Install the motherboard into the system case and make all necessary case connections.
6. Install the riser card and any peripherals (Chapter 3).
7. Turn the computer on and press the <F2> key when you see the screen below:



PhoenixBIOS Version 4.04 LPX54-Pxx
Copyright 1985-1994 Phoenix Technologies Ltd., All Rights Reserved

CPU= Pentium xxMHz
XXXXXXXXK System RAM Passed
XXXXXXXXK Extended RAM Passed
XXXXXK Cache SRAM Passed
Intel Plug and Play BIOS Extensions - Release x.xx

Press <F2> to enter SETUP

8. Set the time and date. Adjust the BIOS settings to match your configuration. If installing an IDE drive, select the IDE device you wish to configure. Press <Enter> with Autotype Fixed Disk selected and the BIOS will automatically configure the drive for you. (See Chapter 4)
9. After you have configured the Main Setup menu, make any desired setting configurations in the Advanced and Security menu. When finished, go to the exit screen, select “Save Changes and Exit,” and you are finished with the BIOS configuration (Chapter 4).

Contents

- Introduction 1-1**
- Features 1-2
- Software Compatibility 1-2

- Configuring the LPX54 2-1**
- Static Electricity 2-1
- Office Environment 2-1
- LPX54 Components 2-2
- Jumper Settings 2-3

- Installing the LPX54, System Memory, CPUs and
Peripherals 3-1**
- Installation of the LPX54 3-2
 - Tools Required 3-2
 - Equipment Required 3-2
- System Memory 3-3
 - SIMMs Supported 3-3
 - Upgrading Rules 3-3
 - Common Memory Configurations 3-4
 - Installing the SIMMs 3-5
 - Removing SIMMs 3-5
- Installing a CPU 3-6
- Installing Cache Memory 3-7
- Installing a Riser Card 3-8
- Installing a PCI Peripheral Card 3-9
- Installing an ISA Peripheral Card 3-10

- The BIOS Setup Utility 4-1**
- Configuration 4-1
- Initial Boot Up 4-1
- Setup 4-2
- Running the Setup Procedure 4-3
- Setting the Main Screen 4-3
 - System Time and Date 4-3

Diskette A or B	4-4
IDE Devices (Hard Disk Setup)	4-4
Video System	4-5
Video BIOS	4-5
Boot Options Submenu	4-5
System Memory	4-6
Extended Memory	4-6
Setting the Advanced Screen	4-7
Integrated Peripherals Submenu	4-8
Large Disk Access Mode	4-9
Security Screen	4-9
Supervisor Password is	4-10
User Password is	4-10
Set Supervisor Password	4-10
Set User Password	4-11
Password on Boot	4-11
Diskette Access	4-11
Fixed Disk Boot Sector	4-11
Power Screen	4-12
APM	4-12
Power Management Mode	4-12
Standby Timeout	4-12
Suspend Timeout	4-13
Standby CPU Speed	4-13
Fixed Disk Timeout	4-13
CRT Standby	4-13
Exit Screen	4-14

Installing Graphics Accelerator Software 5-1

Preparation	5-1
Installation	5-2
Main Menu Options	5-2
System Information	5-3
Quick Setup	5-3
Drivers Installation	5-4
Utilities Installation	5-4
Diagnostics	5-5
Advanced Setup	5-5
Troubleshooting	5-7

Installing Video Drivers	6-1
Installation	6-1
De-Installation	6-1
Microsoft Windows 3.1	6-2
De-Installation Procedure	6-2
Installation Procedure	6-2
AutoCAD 386 R10/R11/R12	6-3
IBM OS/2 Presentation Manager 2.1	6-4
Installation Procedure	6-4
De-Installation Procedure	6-5
Intergraph MicroStation 4.0	6-6
Microsoft Windows NT	6-6
Installation Procedure	6-6
De-Installation Procedure	6-7
Microsoft Word (for DOS) 5.x, 6.0	6-7
WordPerfect (for DOS) 5.x, 6.0	6-8
WordPerfect Versions 5.0 and 5.1	6-8
WordPerfect Version 6.0	6-9
 POST Messages	 A-1
 Beep Codes	 B-1
 Hard Disk Drive Types	 C-1
 Specifications	 D-1
Environmental Specifications	D-2
Temperature Range	D-2
Relative Humidity	D-2
Battery Disposal	D-3
 FCC Warning Statement	 F-1
Glossary	G-1
Limited Warranty	W-1
Non-Warranty Service	W-2

List of Figures

Figure 2-1: LPX54 System Board	2-2
Figure 3-1: Installing a 72-Pin SIMM	3-5
Figure 3-2: Upgrading the External Cache	3-7
Figure 3-3: Installing a Riser Card	3-8
Figure 3-4: Installing a PCI Card	3-9
Figure 3-5: Installing an ISA Card	3-10
Figure 4-1: Power-Up Screen	4-2
Figure 4-2: CMOS Main Screen	4-3
Figure 4-3: IDE Device Submenu	4-4
Figure 4-4: Memory Cache Submenu	4-5
Figure 4-5: Memory Shadow Submenu	4-6
Figure 4-6: Boot Options Submenu	4-7
Figure 4-7: Keyboard Features Submenu	4-8
Figure 4-8: Advanced Screen	4-9
Figure 4-9: Integrated Peripherals Submenu	4-10
Figure 4-10: Security Setup Screen	4-11
Figure 4-11: Supervisor Password Screen	4-12
Figure 4-12: Exit Screen	4-14
Figure 5-1: Main Menu	5-2
Figure 5-2: Monitor Selection Menu	5-4
Figure 5-3: Set Power-Up Configuration Menu	5-6

List of Tables

Table 2-1: CPU Speed Selection	2-3
Table 2-2: Cache Size Selection	2-3
Table 2-3: Cache Type Selection	2-3
Table 2-4: Video Selection	2-3
Table 2-5: PS/2 Mouse Selection	2-4
Table 2-6: IDE IRQ Selection	2-4
Table 2-7: ISA IDE DMA Channel Selection	2-4
Table 2-8: Parallel Port DMA Channel Selection	2-5
Table 2-9: VGA Controller Disable	2-5
Table 2-10: BIOS Operation Selection	2-5
Table 2-11: BIOS Reset Jumper	2-6
Table 2-12: Reserved Jumper Settings	2-6
Table 2-13: Peripheral and Case Connections	2-7
Table 3-1: Common Memory Configurations	3-4
Table 5-1: Error Codes and Messages	5-1