

TI5VGA
Socket 7 MVP3
ATX Motherboard
User's Manual
Version 1.0A

Contents

| | |
|--|-----------|
| Chapter 1 Introduction..... | 1 |
| Chapter 2 Specifications | 2 |
| Chapter 3 Hardware Description | 5 |
| 3.1 Processor and CPU Voltage | 7 |
| 3.2 L2 Cache Memory | 7 |
| 3.3 Main Memory | 7 |
| 3.4 BIOS | 9 |
| 3.5 Onboard PCI EIDE..... | 9 |
| 3.6 Onboard Multi-I/O..... | 9 |
| 3.7 Onboard Hardware Monitoring | 10 |
| 3.8 I/O Port Address Map..... | 10 |
| 3.9 DMA Channels | 11 |
| 3.10 Interrupt Request Lines (IRQ)..... | 11 |
| 3.11 Accelerated Graphics Port (AGP) Slot..... | 11 |
| Chapter 4 Hardware Settings..... | 13 |
| 4.1 SW1(1-8): CPU Frequency Selector | 15 |
| 4.2 JP1: DRAM Operating Frequency | 18 |
| 4.3 JP3, SW2(1-4): CPU VCORE Voltage Selector | 18 |
| 4.4 JP5: Clear CMOS Selection | 20 |
| Chapter 5 Installation | 21 |
| 5.1 I/O Connectors..... | 23 |
| 5.2 J1: PS/2 Keyboard and PS/2 Mouse Connectors..... | 23 |
| 5.3 J2, J19: USB Connectors..... | 24 |
| 5.4 J3, J4 Serial Ports | 24 |
| 5.5 J5: Parallel Port Connector..... | 25 |
| 5.6 J9, J6, J7, J8: Game Port, Mic In/Line In/Line Out | 25 |
| 5.7 J10: ATX Power Supply Connector | 26 |
| 5.8 J11: CPU Fan Power Connector..... | 26 |
| 5.9 J12: Floppy Drive Connector | 27 |
| 5.10 J13, J14: CD In Connectors..... | 27 |
| 5.11 IDE1, IDE2: EIDE Connectors..... | 28 |

| | | |
|---|--|-----------|
| 5.12 | J16: AGP Fan Power Connector..... | 29 |
| 5.13 | J17: IrDA Connector | 29 |
| 5.14 | J18 Wake on LAN Connector | 29 |
| 5.15 | J20: Chassis Fan Power Connector | 29 |
| 5.16 | J21 Front Bezel Connector | 30 |
| Chapter 6 BIOS Configuration..... | | 33 |
| 6.1 | BIOS Introduction | 36 |
| 6.2 | BIOS Setup | 36 |
| 6.3 | Standard CMOS Setup..... | 38 |
| 6.4 | BIOS Features Setup | 41 |
| 6.5 | Chipset Features Setup | 44 |
| 6.6 | Power Management Setup | 47 |
| 6.7 | PNP/PCI Configuration | 50 |
| 6.8 | Load BIOS Defaults | 52 |
| 6.9 | Load Setup Defaults | 52 |
| 6.10 | CPU Features Setup..... | 53 |
| 6.11 | Integrated Peripherals | 54 |
| 6.12 | Supervisor / User Password..... | 56 |
| 6.13 | IDE HDD Auto Detection | 57 |
| 6.14 | Save & Exit Setup..... | 58 |
| 6.15 | Exit Without Saving | 58 |
| Chapter 7 VIA Drivers and DirectX Installation | | 59 |
| 7.1 | Windows 95 4-in-1 Driver Installation..... | 59 |
| 7.2 | Windows 95 Audio Driver Installation | 64 |
| 7.3 | Windows 98 4-in-1 Driver Installation..... | 65 |
| 7.4 | Windows 98/95 DirectX Installation..... | 68 |
| 7.5 | Windows 98 Audio Driver Installation | 70 |
| 7.6 | Windows 98SE 4-in-1 Driver Installation | 71 |
| 7.7 | Windows 98SE Audio Driver Installation..... | 73 |
| 7.8 | Windows NT 4.0 Audio Driver Installation | 74 |
| Chapter 8 System Monitor Installation..... | | 79 |
| Appendix | | 82 |
| A. | Additions & Errata..... | 82 |

Chapter 1 Introduction

This manual is designed to give you information on the TI5VGA Motherboard. It is divided into the following six sections:

- **Introduction**
- **Specifications**
- **Hardware Description**
- **Hardware Settings**
- **Installation**
- **BIOS Configuration**

Checklist

Please check that your package is complete and contains the items below. If you discover damaged or missing items, please contact your dealer.

- ✧ **The TI5VGA Motherboard**
- ✧ **This user's manual**
- ✧ **1 IDE ribbon cable**
- ✧ **1 floppy ribbon cable**
- ✧ **1 UDMA66 ribbon cable (optional)**
- ✧ **1 CD containing Bus Master IDE drivers, flash utility, and other drivers**

Note: The ATA-66 IDE cable that is used in conjunction with Ultra DMA/66 hard disks is optional. Refer to the figure below on how to connect the cable.



Chapter 2 Specifications

Based on VIA's MVP3 chipset, the TI5VGA is an ATX Socket 7 motherboard that supports all the features to make a Microsoft PC'97 compliant PCI system.

The TI5VGA comes with an Accelerated Graphics Port (AGP) slot, power management functionality that is compliant with ACPI (Advanced Configuration and Power Interface) and legacy APM requirements. In addition to standard PIO and DMA mode operation, it features Ultra DMA33/66 for improved disk I/O throughput. The main features of this motherboard are listed as follows:

Main Processor

- Intel Pentium 100/133/150/166/200
- Intel Pentium MMX (P55C) 100/133/166/200/233
- Cyrix 6x86/6x86L P166+/P200+
- Cyrix 6x86MX PR166/PR200/PR233/PR266
- Cyrix 6x86MII PR266/PR300/PR333/PR366
- AMD K5 PR100/PR133/PR166
- AMD K6 166/200/233/266/300
- AMD K6-2/300/333/350/366/380/400/450
- IDT WinChip C6 180/200/225MHz
- IDT WinChip2-3D 200/225/266MHz

L2 Cache

1MB Pipelined Burst Synchronous SRAM onboard, 2MB optional

Main Memory

- Three 168-pin DIMM sockets
- DIMMs:** EDO DRAM or SDRAM (Synchronous DRAM)
- DIMM Size:** 8MB, 16MB, 32MB, 64MB, 128MB

Chipset

VIA chipset (VT82C598MVP, VT82C686A)

Onboard I/O

VIA VT82C686A chip supports two serial, one parallel, one floppy drive interface and IrDA support

Onboard Bus Mastering EIDE

Two EIDE interfaces for up to four devices, support PIO Mode 3/4 or Ultra DMA33/66 IDE Hard Disk and ATAPI CD-ROM.

NOTE: A UDMA66 cable should be used for UDMA66 interface. Under Windows NT 4.0, you need to install Windows NT Service Pack 4.)

BIOS

Licensed BIOS with additional features:

- FLASH EEPROM (128KB) for BIOS update
- ISA Plug and Play (PnP) extension
- Power management

Hardware Monitoring IC

VT82C686A includes the hardware monitoring feature that monitors the system temperature, voltages and fan speed. With the use of a system management utility, the hardware status can be checked and warning message can be displayed when there is a problem.

Windows 95/98 Shut-Down

This allows the PC to power off via Windows 95/98 operating system.

PC97 Compliance

The TI5VGA implements BIOS and hardware designs that meet PC97 standards and is fully compatible with all Windows operating systems.

Year 2000 Compliant BIOS

The onboard Award BIOS is Year 2000 Compliant and will pass software applications that have the tendency to invoke INT1AH function 04H such as year2000.exe utility released by NSTL.

Expansion Slots

Six 32-bit PCI master slots
One AGP slot (Accelerated Graphics Port)

Form Factor

ATX, 12"x 7.48" (30.5cm x 19cm)

This page is intentionally left blank.

Chapter 3 Hardware Description

This chapter briefly describes each of the major features of the TI5VGA motherboard. The layout of the board is shown in Figure 1 which shows the locations of the key components. The topics covered in this chapter are as follows:

| | |
|--|----|
| 3.1 Processor and CPU Voltage | 7 |
| 3.2 L2 Cache Memory..... | 7 |
| 3.3 Main Memory..... | 7 |
| 3.4 BIOS | 9 |
| 3.5 Onboard PCI EIDE | 9 |
| 3.6 Onboard Multi-I/O | 9 |
| 3.7 Onboard Hardware Monitoring..... | 10 |
| 3.8 I/O Port Address Map | 10 |
| 3.9 DMA Channels..... | 11 |
| 3.10 Interrupt Request Lines (IRQ)..... | 11 |
| 3.11 Accelerated Graphics Port (AGP) Slot..... | 11 |




Figure 1: Layout of the TI5VGA Motherboard

3.1 Processor and CPU Voltage

The TI5VGA is designed to take a Socket 7-based processor with a bus speed of 66, 75, 83 and 100 MHz. The internal clock of the CPU can be multiples of 1.5, 2, 2.5, 3, 3.5, 4, 4.5, 5 and 5.5 of the bus clock, the CPU frequency can be 100 to 550MHz.

The onboard CPU voltage regulator provides support for CPUs Vcore which require voltage other than 3.3V such as 2.8V, and/or power consumption higher than 10 watts.

3.2 L2 Cache Memory

The TI5VGA supports 1MB P.B. (Pipelined Burst) Synchronous Cache. 2MB is optional. The P.B. Synchronous Cache boosts the system's performance, 10% higher than regular Asynchronous Cache.

3.3 Main Memory

The TI5VGA motherboard supports three 168-pin DIMMs (Dual In-line Memory Module) sockets. DIMM modules can be 8MB, 16MB, 32MB, 64MB and 128MB in EDO DRAM or SDRAM type. DIMM1, DIMM2 or DIMM3 bank can be populated first. Examples are shown in the following table on how to configure the memory size.

168-pin DIMM (3.3V) – SDRAM or EDO DRAM

| Bank0 (DIMM3) | Bank1 (DIMM2) | Bank2 (DIMM1) | Total Memory |
|------------------|------------------|------------------|--------------|
| 8MB | ----- | ----- | 8MB |
| 16MB | ----- | ----- | 16MB |
| 32MB | ----- | ----- | 32MB |
| 64MB | ----- | ----- | 64MB |
| 128MB | ----- | ----- | 128MB |
| 8MB | 8MB | ----- | 16MB |
| 16MB | 8MB | ----- | 24MB |
| 32MB | 8MB | ----- | 40MB |
| 64MB | 8MB | ----- | 72MB |
| 128MB | 8MB | ----- | 136MB |
| 8MB | 8MB | 8MB | 24MB |
| 16MB | 8MB | 8MB | 32MB |
| 32MB | 8MB | 8MB | 48MB |
| 64MB | 8MB | 8MB | 80MB |

168-pin DIMM (3.3V) – SDRAM or EDO DRAM

| Bank0 (DIMM3) | Bank1 (DIMM2) | Bank2 (DIMM1) | Total Memory |
|------------------|------------------|------------------|--------------|
| 128MB | 8MB | 8MB | 144MB |
| 16MB | 16MB | ----- | 32MB |
| 32MB | 16MB | ----- | 48MB |
| 64MB | 16MB | ----- | 80MB |
| 128MB | 16MB | ----- | 144MB |
| 16MB | 16MB | 8MB | 40MB |
| 32MB | 16MB | 8MB | 56MB |
| 64MB | 16MB | 8MB | 88MB |
| 128MB | 16MB | 8MB | 152MB |
| 16MB | 16MB | 16MB | 48MB |
| 32MB | 16MB | 16MB | 64MB |
| 64MB | 16MB | 16MB | 96MB |
| 128MB | 16MB | 16MB | 160MB |
| 32MB | 32MB | ----- | 64MB |
| 64MB | 32MB | ----- | 96MB |
| 128MB | 32MB | ----- | 160MB |
| 32MB | 32MB | 8MB | 72MB |
| 64MB | 32MB | 8MB | 104MB |
| 128MB | 32MB | 8MB | 168MB |
| 32MB | 32MB | 16MB | 80MB |
| 64MB | 32MB | 16MB | 112MB |
| 128MB | 32MB | 16MB | 176MB |
| 32MB | 32MB | 32MB | 96MB |
| 64MB | 32MB | 32MB | 128MB |
| 128MB | 32MB | 32MB | 192MB |
| 64MB | 64MB | ----- | 128MB |
| 128MB | 64MB | ----- | 192MB |
| 64MB | 64MB | 8MB | 136MB |
| 128MB | 64MB | 8MB | 200MB |
| 64MB | 64MB | 16MB | 144MB |
| 128MB | 64MB | 16MB | 208MB |
| 64MB | 64MB | 32MB | 160MB |
| 128MB | 64MB | 32MB | 224MB |
| 64MB | 64MB | 64MB | 192MB |
| 128MB | 64MB | 64MB | 256MB |
| 128MB | 128MB | 128MB | 384MB |

3.4 BIOS

The BIOS on the T15VGA motherboard provides the standard BIOS functions plus the following additional features:

1. DMI (Desktop Management Interface)

The motherboard supports DMI to enable computer system management in an enterprise.

2. ISA Plug and Play (PnP) Extension

Unlike PCI cards which are plug and play, ISA cards require setting jumpers to resolve hardware conflicts. To make a computer system PnP, an ISA PnP standard is established and supported by new OSes, such as Windows 95. Under Windows 95, the motherboard BIOS must have ISA PnP extension to support the new ISA PnP cards.

3. Power Management

The power management feature provides power savings by slowing down the CPU clock, turning off the monitor screen and stopping the HDD spindle motor.

3.5 Onboard PCI EIDE

The PCI EIDE controller is part of the VT82686A chipset. It supports PIO mode 3/4 and bus mastering. The peak transfer rate of PIO mode 3/4 can be as high as 17MB/sec. Using HDDs that support bus mastering, the peak transfer rate can reach 22MB/sec. There are two IDE connectors, primary IDE and secondary IDE. With two devices per connector, up to four IDE drives are supported. The VT82686A also supports UDMA33 and UDMA66, a new “synchronous DMA” protocol for faster data transfers.

3.6 Onboard Multi-I/O

The multi-I/O is integrated in the VIA chipset that supports two 16550 UART-compatible serial ports, one high speed EPP/ECP parallel port and one floppy controller. The floppy controller supports 2.88MB format. The I/O port addresses of the serial and parallel ports are programmable via BIOS set-up.

3.7 Onboard Hardware Monitoring

The hardware monitoring function is integrated in the VIA chipset. It monitors the system temperature, voltages and fan speeds. With the use of a system management utility, the hardware status can be checked and warning message can be displayed when there is a problem.

3.8 I/O Port Address Map

Each peripheral device in the system is assigned a set of I/O port addresses which also becomes the identity of the device. There are a total of 1K port address space available. The following table lists the I/O port addresses used on the motherboard.

| Address | Device Description |
|-------------|------------------------------------|
| 000h - 01Fh | DMA Controller #1 |
| 020h - 03Fh | Interrupt Controller #1 |
| 040h - 05Fh | Timer |
| 060h - 06Fh | Keyboard Controller |
| 070h - 07Fh | Real Time Clock, NMI |
| 080h - 09Fh | DMA Page Register |
| 0A0h - 0BFh | Interrupt Controller #2 |
| 0C0h - 0DFh | DMA Controller #2 |
| 0F0h | Clear Math Coprocessor Busy Signal |
| 0F1h | Reset Math Coprocessor |
| 1F0h - 1F7h | IDE Interface |
| 278 - 27F | Parallel Port #2 (LPT2) |
| 2F8h - 2FFh | Serial Port #2 (COM2) |
| 2B0 - 2DF | Graphics adapter Controller |
| 378h - 3FFh | Parallel Port #1(LPT1) |
| 360 - 36F | Network Ports |
| 3B0 - 3BF | Monochrome & Printer adapter |
| 3C0 - 3CF | EGA adapter |
| 3D0 - 3DF | CGA adapter |
| 3F0h - 3F7h | Floppy Disk Controller |
| 3F8h - 3FFh | Serial Port #1 (COM1) |

3.9 DMA Channels

There are seven DMA Channels available on the motherboard. Only DMA2 is used by the floppy controller. In the case that ECP mode on the parallel port is used, DMA1 or DMA3 will be used.

3.10 Interrupt Request Lines (IRQ)

There are a total of 15 IRQ lines available on the motherboard. Peripheral devices use interrupt request lines to notify the CPU for the service required. The following table shows the IRQ used by the devices on the motherboard.

| Level | Function |
|-------|--------------------------------|
| IRQ0 | System Timer Output |
| IRQ1 | Keyboard |
| IRQ2 | Interrupt Cascade |
| IRQ3 | Serial Port #2 |
| IRQ4 | Serial Port #1 |
| IRQ5 | Parallel Port #2 |
| IRQ6 | Floppy Disk Controller |
| IRQ7 | Parallel Port #1 |
| IRQ8 | Real Time Clock |
| IRQ9 | Software Redirected to Int 0Ah |
| IRQ10 | Reserved |
| IRQ11 | Reserved |
| IRQ12 | Reserved |
| IRQ13 | 80287 |
| IRQ14 | Primary IDE |
| IRQ15 | Secondary IDE |

3.11 Accelerated Graphics Port (AGP) Slot

The TI5VGA motherboard comes with an AGP slot for an AGP VGA card that supports 133MHz 2X mode for AD and SBA signaling to provide high-performance 3D graphic display.

This page was intentionally left blank.

Chapter 4 Hardware Settings

The following sections describe the necessary procedures and proper jumper settings to configure the TI5VGA motherboard.



- 4.1 SW1(1-8): CPU Frequency Selector 15
- 4.2 JP1: DRAM Operating Frequency 18
- 4.3 JP3, SW2(1-4): CPU Vcore Voltage Selector..... 18
- 4.4 JP5: Clear CMOS Selection 20


The TI5VGA-100MHz, on the other hand, supports VIA's MVP3 chipset and has a maximum CPU bus speed of 100MHz. Please note the correct settings of both the CPU and SDRAM clocks.

In the case your motherboard TI5VGA-100MHz has a processor supporting 100MHz CPU clock (such as AMD K6-2/300) and your DIMM module is PC100 compliant, the SDRAM clock can be set to 100MHz. Otherwise, set the SDRAM clock at 66MHz.

For the locations of the jumpers, refer to Figure 2 on the following page.

The following examples show the conventions used in this chapter

| | |
|---|---------------|
|  | Jumper Open |
|  | Jumper Closed |

| | |
|---|---|
|  | <p>Switch 1 and switch 2 are set to OFF. Switch 3 and switch 4 are set to ON.</p> |
|---|---|





















Figure 2: Jumper Locations of the TI5VGA

4.1 SW1(1-8): CPU Frequency Selector













For Intel Pentium, IDT WinChip 2-3D / C6





| SW1 | CPU Clock | AGP Clock | Multiplier | CPU FREQ. |
|---|-----------|-----------|------------|---|
|  off on on off off off off on | 66MHz | 66MHz | 1.5x | P54C-100 |
|  off on on on off off on off on | 66MHz | 66MHz | 2x | P54C-133 |
|  off on on on on on off on | 66MHz | 66MHz | 2.5x | P54C/P55C-166 |
|  off on on off off on off on | 66MHz | 66MHz | 3x | P54C/P55C-200 WinChip 2-3D / C6-200 |
|  off on on on off off off on | 66MHz | 66MHz | 3.5x | P55C-233 |
|  off off on on off off on on | 75MHz | 75MHz | 3x | WinChip 2-3D / C6-225 |
|  off on on on on off on on | 66MHz | 66MHz | 4x | WinChip 2-3D 266 |

For Cyrix 6x86, 6x86L, 6x86MX CPU

| SW1 | CPU Clock | AGP Clock | Multiplier | CPU FREQ. |
|--|-----------|-----------|------------|---------------------|
|  off on on off on off off on | 66MHz | 66MHz | 2x | P166+ (133MHz) |
|  off off on off on off off on | 75MHz | 75MHz | 2x | P200+ (150MHz) |
|  off on on off on on on off | 66MHz | 66MHz | 2.5x | PR200 (166MHz) |
|  off on on off off on off on | 66MHz | 66MHz | 3x | PR233 (200MHz) |
|  off on on off off off off on | 66MHz | 66MHz | 3.5x | PR266 (233MHz) |
|  off off on off on on on on | 75MHz | 75MHz | 2.5x | PR233 (187.5MHz) |
|  off on off off on on off off | 83MHz | 66MHz | 2.5x | PR266 (208MHz) |
|  off on off off off on off off | 83MHz | 66MHz | 3x | PR300 (250MHz) |
|  off off off on on on off off | 100MHz | 66MHz | 2.5x | PR333 (250MHz) |
|  off off off on off on off off | 100MHz | 66MHz | 3x | PR366 (300MHz) |

For AMD K5, K6, K6-2 CPU

| SW1 | CPU Clock | AGP Clock | Multiplier | CPU FREQ. |
|---|-----------|-----------|------------|-------------------|
|  off on on off off off off on | 66MHz | 66MHz | 1.5x | PR100 |
|  off on on off on off off on | 66MHz | 66MHz | 2x | PR133 |
|  off on on off on on off on | 66MHz | 66MHz | 2.5x | PR166 / K6-166 |
|  off on on off off on off on | 66MHz | 66MHz | 3x | K6-200 |
|  off on on off off off off on | 66MHz | 66MHz | 3.5x | K6-233 |
|  off on on off on off on on | 66MHz | 66MHz | 4x | K6-266 |
|  off on on off on on on on | 66MHz | 66MHz | 4.5x | K6-300 |
|  off off on off on off on off | 100MHz | 66MHz | 3x | K6-2/300 |
|  on off off on off off off off | 95MHz | 63MHz | 3.5x | K6-2/333 |
|  off off off on off off off off | 100MHz | 66MHz | 3.5x | K6-2/350 |
|  off on on off off off on on | 66MHz | 66MHz | 5.5x | K6-2/366 |
|  on off off on on off on off | 95MHz | 64MHz | 4x | K6-2/380 |

| | | | | |
|---|--------|-------|------|----------------------|
|  | 66MHz | 66MHz | 6x | K6-2/400 |
|  | 100MHz | 66MHz | 4x | K6-2/400 K6-3/400 |
|  | 100MHz | 66MHz | 4.5x | K6-2/450 K6-3/450 |
|  | 100MHz | 66MHz | 5x | K6-2/500 K6-3/500 |



4.2 JP1: DRAM Operating Frequency

| JP1 | SDRAM Frequency |
|---------------|-----------------|
| pin 1-2 short | Run CPU Clock |
| pin 2-3 short | Run AGP Clock |

NOTE: Set the SDRAM Frequency to **Run CPU Clock** only when the CPU clock is 100MHz and the DIMM modules are PC-100.







4.3 JP3, SW2(1-4): CPU V_{CORE} Voltage Selector

























For Single Voltage CPU:

| JP3 | SW2 | V _{CORE} / V _{IO} | CPU |
|---|--|-------------------------------------|---|
|  open |  | 3.5V | Intel P54C, Cyrix 6x86, AMD K5, WinChip C6 |

For Dual Voltage CPU:

















Intel P55C, Cyrix 6x86L/MX/MII, AMD K6/K6-2, IDT WinChip 2-3D

| JP3 | SW2 | V _{CORE} | CPU |
|--|---|-------------------|--------------------------|
|  open |  | 3.5V | WinChip 2-3D (0.35μ)* |
|  open |  | 3.4V | |
|  open |  | 3.3V | |

| JP3 | SW2 | V _{CORE} | CPU |
|---|---|-------------------|---|
|  open |  off off on on | 3.2V | K6-233 (0.35μ)* |
|  open |  on on off on | 3.1V | |
|  open |  off on off on | 3.0V | |
|  open |  on off off on | 2.9V | K6-166/200 6x86MX |
|  open |  off off off on | 2.8V | WinChip 2-3D (0.35μ)* P55C 6x86L |
|  open |  on on on off | 2.7V | |
|  open |  off on on off | 2.6V | |
|  open |  on off on off | 2.5V | |
|  open |  off off on off | 2.4V | K6-3/400/450 K6-2/400/450 |
|  open |  on on off off | 2.3V | |
|  open |  off on off off | 2.2V | K6, K6-2/500 (0.25μ)* |
|  open |  on off off off | 2.1V | |

* 0.25μ and 0.35μ refer to manufacturing processes.



CPU V_{CORE} Voltage (1.30V~2.05V)*

| SW2 | V _{CORE} | SW2 | V _{CORE} | SW2 | V _{CORE} | SW2 | V _{CORE} |
|---|-------------------|--|-------------------|--|-------------------|---|-------------------|
|  on on on on | 2.05V |  on on off on | 1.85V |  on on on off | 1.65V |  on on off off | 1.45V |
|  off on on on | 2.0V |  off on off on | 1.80V |  off on on off | 1.60V |  off on off off | 1.40V |
|  on off on on | 1.95V |  on off off on | 1.75V |  on off on off | 1.55V |  on off off off | 1.35V |
|  on off on on | 1.90V |  on off off on | 1.70V |  on off on off | 1.50V |  on off off off | 1.30V |

* For CPU V_{CORE} Voltage 1.30V~2.05V, set JP3 to SHORT

4.4 JP5: Clear CMOS Selection

Use JP5, a 3-pin header, to clear the contents of the CMOS RAM. *Note that the ATX-power connector should be disconnected from the motherboard before clearing CMOS.* Do not clear the CMOS RAM unless it is absolutely necessary.

| JP5 | Function | JP5 | Function |
|--|----------|--|------------|
|  1 2 3 | Normal |  1 2 3 | Clear CMOS |

Chapter 5 Installation

This chapter describes the connectors and interfaces that the TI5VGA provides for creating a working system. Refer to Figure 3 for the location of the connectors.

The following items are covered in this chapter:

| | |
|---|----|
| 5.1 I/O Connectors | 23 |
| 5.2 J1: PS/2 Keyboard and PS/2 Mouse Connectors..... | 23 |
| 5.3 J2, J19: USB Connectors | 24 |
| 5.4 J3, J4 Serial Ports..... | 24 |
| 5.5 J5: Parallel Port Connector | 25 |
| 5.6 J9, J6, J7, J8: Game Port, Mic In/Line In/Line Out..... | 25 |
| 5.7 J10: ATX Power Supply Connector..... | 26 |
| 5.8 J11: CPU Fan Power Connector..... | 26 |
| 5.9 J12: Floppy Drive Connector | 27 |
| 5.10 J13, J14: CD In Connectors | 27 |
| 5.11 IDE1, IDE2: EIDE Connectors | 28 |
| 5.12 J16: AGP Fan Power Connector | 29 |
| 5.13 J17: IrDA Connector..... | 29 |
| 5.14 J18 Wake on LAN Connector | 29 |
| 5.15 J20: Chassis Fan Power Connector | 29 |
| 5.16 J21 Front Bezel Connector..... | 30 |




Figure 3: Connector Location on the TI5VGA

5.1 I/O Connectors

The I/O connectors connect the TI5VGA to the most common peripherals. To attach cables to these connectors, carefully align Pin 1 of the cables to that of the connectors. Refer to Figure 4 for the location and orientation of the connectors.





Figure 4: Orientation of the I/O Connector

5.2 J1: PS/2 Keyboard and PS/2 Mouse Connectors





Below are the pin-out assignments of the connectors.

| Signal Name | Keyboard | Mouse | Signal Name |
|----------------|----------|-------|-------------|
| Keyboard data | 1 | 1 | Mouse data |
| N.C. | 2 | 2 | N.C. |
| GND | 3 | 3 | Ground |
| 5V | 4 | 4 | 5V |
| Keyboard clock | 5 | 5 | Mouse Clock |
| N.C. | 6 | 6 | N.C. |

5.3 J2, J19: USB Connectors


J2 is a standard USB external connector consisting of two stacked ports. J19 is a 10-pin header that supports an optional USB connector that can only be used under Windows 98.



5.4 J3, J4 Serial Ports

The onboard serial ports J3 and J4, are two DB-9 external connectors. The following table shows the pin-out assignments of these connectors.

| Signal Name | Pin # | Pin # | Signal Name |
|--------------------------|-------|-------|----------------------|
| DCD, Data carrier detect | 1 | 6 | DSR, Data set ready |
| RXD, Receive data | 2 | 7 | RTS, Request to send |
| TXD, Transmit data | 3 | 8 | CTS, Clear to send |
| DTR, Data terminal ready | 4 | 9 | RI, Ring indicator |
| GND, ground | 5 | 10 | Not Used |




5.5 J5: Parallel Port Connector

J5 is a DB-25 external connector. The following table describes the pin-out assignments of this connector. See the figure on the previous page.

| Signal Name | Pin # | Pin # | Signal Name |
|----------------------|-------|-------|-------------|
| Line printer strobe | 1 | 14 | AutoFeed |
| PD0, parallel data 0 | 2 | 15 | Error |
| PD1, parallel data 1 | 3 | 16 | Initialize |
| PD2, parallel data 2 | 4 | 17 | Select |
| PD3, parallel data 3 | 5 | 18 | Ground |
| PD4, parallel data 4 | 6 | 19 | Ground |
| PD5, parallel data 5 | 7 | 20 | Ground |
| PD6, parallel data 6 | 8 | 21 | Ground |
| PD7, parallel data 7 | 9 | 22 | Ground |
| ACK, acknowledge | 10 | 23 | Ground |
| Busy | 11 | 24 | Ground |
| Paper empty | 12 | 25 | Ground |
| Select | 13 | N/A | N/A |

5.6 J9, J6, J7, J8: Game Port, Mic In/Line In/Line Out

J9, J6, J7 and J8 are connectors supporting game port, Line Out, Line In, and Microphone respectively.




5.7 J10: ATX Power Supply Connector

J10 is a 20-pin ATX power supply connector. Refer to the following table for the pin out assignments.

| | | | | | |
|----|---|--------------------|--------------|--------------|--------------------|
| 11 | 1 | Signal Name | Pin # | Pin # | Signal Name |
| ○ | □ | 3.3V | 11 | 1 | 3.3V |
| ○ | ○ | -12V | 12 | 2 | 3.3V |
| ○ | ○ | Ground | 13 | 3 | Ground |
| ○ | ○ | PS-ON | 14 | 4 | +5V |
| ○ | ○ | Ground | 15 | 5 | Ground |
| ○ | ○ | Ground | 16 | 6 | +5V |
| ○ | ○ | Ground | 17 | 7 | Ground |
| ○ | ○ | -5V | 18 | 8 | Power good |
| ○ | ○ | +5V | 19 | 9 | 5VSB |
| ○ | ○ | +5V | 20 | 10 | +12V |

5.8 J11: CPU Fan Power Connector


J11 is a 3-pin header for the CPU fan power connector. The fan must be a 12V fan.



| Pin # | Signal Name |
|-------|-------------|
| 1 | Fan sensor |
| 2 | +12V |
| 3 | Ground |

5.9 J12: Floppy Drive Connector



J12 of the T15VGA is a 34-pin header and will support up to 2.88MB floppy drives.



| Signal Name | Pin # | Pin # | Signal Name |
|-------------|-------|-------|-----------------|
| Ground | 1 | 2 | RM/LC |
| Ground | 3 | 4 | No connect |
| Ground | 5 | 6 | No connect |
| Ground | 7 | 8 | Index |
| Ground | 9 | 10 | Motor enable 0 |
| Ground | 11 | 12 | Drive select 1 |
| Ground | 13 | 14 | Drive select 0 |
| Ground | 15 | 16 | Motor enable 1 |
| Ground | 17 | 18 | Direction |
| Ground | 19 | 20 | Step |
| Ground | 21 | 22 | Write data |
| Ground | 23 | 24 | Write gate |
| Ground | 25 | 26 | Track 00 |
| Ground | 27 | 28 | Write protect |
| Ground | 29 | 30 | Read data |
| Ground | 31 | 32 | Side 1 select |
| Ground | 33 | 34 | Diskette change |

5.10 J13, J14: CD In Connectors


J13 and J14 are the CD-in connectors. Below is their pin out assignments.



| Signal Name | Pin # | Pin # | Signal Name |
|-------------|-------|-------|-------------|
| Ground | 1 | 1 | Left |
| Left | 2 | 2 | Ground |
| Ground | 3 | 3 | Ground |
| Right | 4 | 4 | Right |


5.11 IDE1, IDE2: EIDE Connectors

IDE1: Primary IDE Connector



| Signal Name | Pin # | Pin # | Signal Name |
|---------------|-------|-------|---------------|
| Reset IDE | 1 | 2 | Ground |
| Host data 7 | 3 | 4 | Host data 8 |
| Host data 6 | 5 | 6 | Host data 9 |
| Host data 5 | 7 | 8 | Host data 10 |
| Host data 4 | 9 | 10 | Host data 11 |
| Host data 3 | 11 | 12 | Host data 12 |
| Host data 2 | 13 | 14 | Host data 13 |
| Host data 1 | 15 | 16 | Host data 14 |
| Host data 0 | 17 | 18 | Host data 15 |
| Ground | 19 | 20 | Key |
| DRQ0 | 21 | 22 | Ground |
| Host IOW | 23 | 24 | Ground |
| Host IOR | 25 | 26 | Ground |
| IOCHRDY | 27 | 28 | Host ALE |
| DACK0 | 29 | 30 | Ground |
| IRQ14 | 31 | 32 | No connect |
| Address 1 | 33 | 34 | UDMA66 Enable |
| Address 0 | 35 | 36 | Address 2 |
| Chip select 0 | 37 | 38 | Chip select 1 |
| Activity | 39 | 40 | Ground |


IDE2: Secondary IDE Connector



| Signal Name | Pin # | Pin # | Signal Name |
|---------------|-------|-------|---------------|
| Reset IDE | 1 | 2 | Ground |
| Host data 7 | 3 | 4 | Host data 8 |
| Host data 6 | 5 | 6 | Host data 9 |
| Host data 5 | 7 | 8 | Host data 10 |
| Host data 4 | 9 | 10 | Host data 11 |
| Host data 3 | 11 | 12 | Host data 12 |
| Host data 2 | 13 | 14 | Host data 13 |
| Host data 1 | 15 | 16 | Host data 14 |
| Host data 0 | 17 | 18 | Host data 15 |
| Ground | 19 | 20 | Key |
| DRQ0 | 21 | 22 | Ground |
| Host IOW | 23 | 24 | Ground |
| Host IOR | 25 | 26 | Ground |
| IOCHRDY | 27 | 28 | Host ALE |
| DACK1 | 29 | 30 | Ground |
| MIRQ0 | 31 | 32 | No connect |
| Address 1 | 33 | 34 | UDMA66 Enable |
| Address 0 | 35 | 36 | Address 2 |
| Chip select 0 | 37 | 38 | Chip select 1 |
| Activity | 39 | 40 | Ground |

5.12 J16: AGP Fan Power Connector


J16 is a 3-pin header for the AGP fan power connector. The fan must be a 12V fan.



| Pin # | Signal Name |
|-------|-------------|
| 1 | No Connect |
| 2 | +12V |
| 3 | Ground |

5.13 J17: IrDA Connector


This connector is used for an IrDA connector that supports infrared wireless communication with IrDA devices.



| Pin # | Signal Name |
|-------|-------------|
| 1 | +5V |
| 2 | No connect |
| 3 | Ir RX |
| 4 | Ground |
| 5 | Ir TX |

5.14 J18 Wake on LAN Connector


J18 is a 3-pin header for Wake on LAN function on the motherboard.



| Pin # | Signal Name |
|-------|-------------|
| 1 | 5VSB |
| 2 | Ground |
| 3 | Wake on LAN |

5.15 J20: Chassis Fan Power Connector


J20 is a 3-pin header for the chassis fan power connector. The fan must be a 12V fan.



| Pin # | Signal Name |
|-------|-------------|
| 1 | Fan sensor |
| 2 | +12V |
| 3 | Ground |

5.16 J21 Front Bezel Connector

The front bezel of the case has a control panel which provides light indication of the computer activities and switches to change the computer status. J21 is a 20-pin header that provides interfaces for the following functions.



Speaker: Pins 1 - 4

This connector provides an interface to a speaker for audio tone generation. An 8-ohm speaker is recommended.



| J21 Pin # | Signal Name |
|-----------|-------------|
| 1 | Speaker out |
| 2 | No connect |
| 3 | Ground |
| 4 | +5V |

Power LED: Pins 11 - 15


The power LED indicates the status of the main power switch. The keylock switch, when closed, will disable the keyboard function.



| J21 Pin # | Signal Name |
|-----------|-------------|
| 11 | Power LED |
| 12 | No connect |
| 13 | Ground |
| 14 | Keylock |
| 15 | Ground |

CPU Overheat LED: Pins 6 and 16

This connector connects to the CPU Overheat LED that lights up when CPU temperature exceeds the CPU warning temperature set in the BIOS. When this occurs, the system slows down until the temperature falls to a safe level.




| J21 Pin # | Signal Name |
|-----------|-------------|
| 6 | 5V |
| 16 | Ground |

ATX Power ON Switch: Pins 7 and 17

This is an “ATX Power Supply On/Off Switch” that is connected to the power switch on the case. When pressed for more than 4 seconds, the system powers off. When pressed for less than 4 seconds, the system enters the Suspend Mode (depending on BIOS pre-settings).

**Turbo LED Connector: Pins 8 and 18**


There is no turbo/deturbo function on the motherboard. The Turbo LED will always be On when linked to this connector.




| J21 Pin # | Signal Name |
|-----------|-------------|
| 8 | 5V |
| 18 | Ground |

Reset Switch: Pins 9 and 19

The reset switch allows the user to reset the system without turning Off the main power and then On. Orientation is not required when making a connection to this header.

**Hard Disk Drive LED Connector: Pins 10 and 20**

This connector connects to the hard drive activity LED on the control panel. The LED flashes when HDD is in use.



| J21 Pin # | Signal Name |
|-----------|-------------|
| 10 | Ground |
| 20 | 5V |

This page was intentionally left blank.

Chapter 6 BIOS Configuration

This chapter describes the different settings available in the Award BIOS that comes with the TI5VGA motherboard. The topics covered in this chapter are as follows:

| | |
|--|----|
| 6.1 BIOS Introduction..... | 36 |
| 6.2 BIOS Setup | 36 |
| 6.3 Standard CMOS Setup | 38 |
| Date | 38 |
| Time | 39 |
| Primary HDDs / Secondary HDDs..... | 39 |
| Drive A / Drive B | 40 |
| Floppy 3 Mode Support | 40 |
| Video..... | 40 |
| Halt On..... | 40 |
| 6.4 BIOS Features Setup | 41 |
| Virus Warning..... | 41 |
| CPU Internal Cache / External Cache | 41 |
| Quick Power On Self Test..... | 42 |
| Boot Sequence..... | 42 |
| Swap Floppy Drive..... | 42 |
| Boot Up Floppy Seek..... | 42 |
| Boot Up NumLock Status | 42 |
| Gate A20 Option | 42 |
| Memory Parity/ECC Check..... | 42 |
| Typematic Rate Setting | 42 |
| Typematic Rate (Chars/Sec)..... | 43 |
| Typematic Delay (Msec)..... | 43 |
| Security Option | 43 |
| PCI/VGA Palette Snoop..... | 43 |
| OS Select for DRAM > 64MB..... | 43 |
| HDD S.M.A.R.T Capability..... | 43 |
| Video BIOS Shadow | 43 |
| C8000 - CBFFF Shadow/DC000 - DFFFF Shadow..... | 43 |
| Cyrix 6x86/MII CPUID | 43 |
| 6.5 Chipset Features Setup | 44 |
| Bank DRAM Timing..... | 44 |

| | |
|---|----|
| SDRAM Cycle Length | 44 |
| DRAM Read Pipeline..... | 44 |
| Cache Rd+CPU Wt Pipeline | 44 |
| Cache Timing | 44 |
| Video BIOS Cacheable | 44 |
| System BIOS Cacheable..... | 45 |
| Memory Hole at 15MB Addr. | 45 |
| AGP Aperture Size | 45 |
| CPU Host Clock (CPU/PCI) | 45 |
| Auto Detect DIMM/PCI Clk | 45 |
| Spread Spectrum..... | 45 |
| OnChip USB / OnChip USB 2 | 45 |
| USB Keyboard Support..... | 46 |
| OnChip Sound | 46 |
| 6.6 Power Management Setup | 47 |
| ACPI Function..... | 47 |
| Power Management | 47 |
| PM Control by APM | 48 |
| Video Off Method | 48 |
| Modem Use IRQ | 48 |
| Soft-Off by PWRBTN..... | 48 |
| PWRON After PW-Fail..... | 48 |
| HDD Power Down | 48 |
| Doze Mode | 48 |
| Suspend Mode | 48 |
| PM Events | 49 |
| 6.7 PNP/PCI Configuration..... | 50 |
| PNP OS Installed..... | 50 |
| Resources Controlled by..... | 50 |
| Reset Configuration Data | 50 |
| IRQ3/4/5/7/9/10/11/12/14/15, DMA0/1/3/5/6/7 assigned to51 | |
| CPU to PCI Write Buffer | 51 |
| PCI Dynamic Bursting..... | 51 |
| PCI Master 0 WS Write..... | 51 |
| PCI Delay Transaction | 51 |
| PCI#2 Access #1 Retry..... | 51 |
| AGP Master 1 WS Write..... | 51 |
| AGP Master 1 WS Read..... | 51 |
| Assign IRQ for USB/VGA | 51 |

| | |
|---|----|
| 6.8 Load BIOS Defaults | 52 |
| 6.9 Load Setup Defaults | 52 |
| 6.10 CPU Features Setup | 53 |
| Current CPU / System Temp..... | 53 |
| Current CPU Fan Speed / Chassis Fan Speed | 53 |
| VCORE / VIO / +12V / +5V..... | 53 |
| 6.11 Integrated Peripherals | 54 |
| OnChip Primary/Secondary PCI IDE..... | 54 |
| IDE Prefetch Mode | 54 |
| IDE HDD Block Mode | 54 |
| IDE Primary/Secondary Master/Slave PIO | 54 |
| IDE Primary/Secondary Master/Slave UDMA | 55 |
| Init AGP Display First..... | 55 |
| Onboard FDD Controller | 55 |
| Onboard Serial/Parallel Port | 55 |
| UART 2 Mode | 55 |
| Onboard Parallel Mode | 55 |
| Onboard Legacy Audio | 55 |
| 6.12 Supervisor / User Password..... | 56 |
| 6.13 IDE HDD Auto Detection..... | 57 |
| 6.14 Save & Exit Setup | 58 |
| 6.15 Exit Without Saving..... | 58 |

6.1 BIOS Introduction

The Award BIOS (Basic Input/Output System) installed in your computer system's ROM supports Intel/Cyrix/AMD processors in a standard IBM-AT compatible I/O system. The BIOS provides critical low-level support for standard devices such as disk drives, serial and parallel ports. It also adds virus and password protection as well as special support for detailed fine-tuning of the chipset controlling the entire system.

6.2 BIOS Setup

The Award BIOS provides a Setup utility program for specifying the system configurations and settings. The BIOS ROM of the system stores the Setup utility. When you turn on the computer, the Award BIOS is immediately activated. Pressing the key immediately allows you to enter the Setup utility. If you are a little bit late pressing the key, POST(Power On Self Test) will continue with its test routines, thus preventing you from invoking the Setup. If you still wish to enter Setup, restart the system by pressing the "Reset" button or simultaneously pressing the <Ctrl>, <Alt> and <Delete> keys. You can also restart by turning the system Off and back On again. The following message will appear on the screen:

Press to Enter Setup

In general, you press the arrow keys to highlight items, <Enter> to select, the <PgUp> and <PgDn> keys to change entries, <F1> for help and <Esc> to quit.

When you enter the Setup utility, the Main Menu screen will appear on the screen. The Main Menu allows you to select from various setup functions and exit choices.

ROM PCI/ISA BIOS
CMOS SETUP UTILITY
AWARD SOFTWARE, INC.

| | |
|----------------------------|---------------------------|
| STANDARD CMOS SETUP | CPU FEATURE SETUP |
| BIOS FEATURES SETUP | INTEGRATED PERIPHERALS |
| CHIPSET FEATURES SETUP | SUPERVISOR PASSWORD |
| POWER MANAGEMENT SETUP | USER PASSWORD |
| PNP/PCI CONFIGURATION | IDE HDD AUTO DETECTION |
| LOAD BIOS DEFAULTS | SAVE & EXIT SETUP |
| LOAD SETUP DEFAULTS | EXIT WITHOUT SAVING |
| ESC : Quit | ↑ ↓ → ← : Select Item |
| F10 : Save & Exit Setup | (Shift) F2 : Change Color |
| Time, Date, Hard Disk Type | |

The section below the setup items of the Main Menu displays the control keys for this menu. Another section at the bottom of the Main Menu just below the control keys section displays information on the currently highlighted item in the list.

NOTE: After making and saving system changes with Setup, you find that your computer cannot boot, the Award BIOS supports an override to the CMOS settings that resets your system to its default.

We strongly recommend that you avoid making any changes to the chipset defaults. These defaults have been carefully chosen by both Award and your system manufacturer to provide the absolute maximum performance and reliability.

6.3 Standard CMOS Setup

“Standard CMOS Setup” choice allows you to record some basic hardware configurations in your computer system and set the system clock and error handling. If the motherboard is already installed in a working system, you will not need to select this option. You will need to run the Standard CMOS option, however, if you change your system hardware configurations, the onboard battery fails, or the configuration stored in the CMOS memory was lost or damaged.

ROM PCI/ISA BIOS
STANDARD CMOS SETUP
AWARD SOFTWARE, INC.

| Date (mm:dd:yy) : Mon , Aug 19 1996 | | | | | | | | |
|--|----------------|---------------------------|-----------------|------|---------|--------------------------|--------|------|
| Time (hh:mm:ss) : 00 : 00 : 00 | | | | | | | | |
| HARD DISKS | TYPE | SIZE | CYLS | HEAD | PRECOMP | LANDZ | SECTOR | MODE |
| Primary Master | Auto | 0 | 0 | 0 | 0 | 0 | 0 | Auto |
| Primary Slave | Auto | 0 | 0 | 0 | 0 | 0 | 0 | Auto |
| Secondary Master | Auto | 0 | 0 | 0 | 0 | 0 | 0 | Auto |
| Secondary Slave | Auto | 0 | 0 | 0 | 0 | 0 | 0 | Auto |
| Drive A | : 1.44M, 3.5in | | | | | | | |
| Drive B | : None | | | | | | | |
| Floppy 3 Mode Support | : Disabled | | | | | | | |
| Video | : EGA / VGA | | | | | | | |
| Halt On | : All Errors | | | | | | | |
| | | | Base Memory | | | : 640K | | |
| | | | Extended Memory | | | : 15360K | | |
| | | | Other Memory | | | : 384K | | |
| | | | Total Memory | | | : 16384K | | |
| ESC : Quit | | ↑ ↓ → ← : Select | | Item | | PU / PD / + / - : Modify | | |
| F1 : Help | | (Shift) F2 : Change Color | | | | | | |

At the bottom of the menu are the control keys for use on this menu. If you need any help in each item field, you can press the <F1> key. It will display the relevant information to help you. The memory display at the lower right-hand side of the menu is read-only. It will adjust automatically according to the memory changed. The following describes each item of this menu.

Date

The date format is:

Day : Sun to Sat
Month : 1 to 12
Date : 1 to 31
Year : 1994 to 2079

To set the date, highlight the “Date” field and use the PageUp/ PageDown or +/- keys to set the current time.

Time

The time format is: **Hour : 00 to 23**
Minute : 00 to 59
Second : 00 to 59

To set the time, highlight the "Time" field and use the <PgUp>/<PgDn> or +/- keys to set the current time.

Primary HDDs / Secondary HDDs

The onboard PCI IDE connectors provide Primary and Secondary channels for connecting up to four IDE hard disks or other IDE devices. Each channel can support up to two hard disks; the first is the "Master" and the second is the "Slave".

To enter the specifications for a hard disk drive, you must select first a "Type". There are 45 predefined types and 4 user definable types are for Enhanced IDE BIOS. Type 1 to 45 are predefined. Type "User" is user-definable. For the Primary Master/Slave as well as Secondary Master/Slave, you can select "Auto" under the TYPE and MODE fields. This will enable auto detection of your IDE drives and CD-ROM drive during POST.

Press <PgUp>/<PgDn> to select a numbered hard disk type or type the number and press the <Enter> key. The hard disk will not work properly if you enter incorrect information for this field. If your hard disk drive type is not matched or listed, you can use Type User to define your own drive type manually. If you select Type User, related information is asked to be entered to the following items.

CYLS : Number of cylinders
HEAD : Number of read/write heads
PRECOMP : Write precompensation
LANDZ : Landing zone
SECTOR : Number of sectors
SIZE : Automatically adjust according to the configuration
MODE (for IDE HDD only) : Auto
Normal (HD < 528MB)
Large (for MS-DOS only)
LBA (HD > 528MB and supports
Logical Block Addressing)

NOTE: The specifications of your drive must match with the drive table. The hard disk will not work properly if you enter incorrect information in these fields. If your hard disk drive type is not matched or listed, you can use Type User to define your own drive type manually.

Drive A / Drive B

These fields identify the types of floppy disk drive A or drive B that has been installed in the computer. The available specifications are:

360KB 1.2MB 720KB 1.44MB 2.88MB
5.25 in. 5.25 in. 3.5 in. 3.5 in. 3.5 in.

Floppy 3 Mode Support

This is the Japanese standard floppy drive. The standard stores 1.2MB in a 3.5-inch diskette. You have four options to choose:

| | |
|----------|---|
| Disabled | No 3 mode floppy drive installed. (default) |
| Drive A | Installed 3 mode drive at drive A. |
| Drive B | Installed 3 mode drive at drive B. |
| Both | Installed 3 mode drive at drive A and B. |

Video

This field selects the type of video display card installed in your system. You can choose the following video display cards:

| | |
|---------|---|
| EGA/VGA | For EGA, VGA, SEGA, SVGA or PGA monitor adapters. (default) |
| CGA 40 | Power up in 40 column mode. |
| CGA 80 | Power up in 80 column mode. |
| MONO | For Hercules or MDA adapters. |

Halt On

This field determines whether the system will halt if an error is detected during power up.

| | |
|-------------------|---|
| No errors | The system boot will not be halted for any error that may be detected. |
| All errors | Whenever the BIOS detects a non-fatal error, the system will stop and you will be prompted. |
| All, But Keyboard | The system boot will not be halted for a keyboard error; it will stop for all other errors. |
| All, But Diskette | The system boot will not be halted for a disk error; it will stop for all other errors. |
| All, But Disk/Key | The system boot will not be halted for a keyboard or disk error; it will stop for all others. |

6.4 BIOS Features Setup

This section allows you to configure and improve your system and allows you to set up some system features according to your preference.

| ROM / PCI ISA BIOS BIOS FEATURES SETUP AWARD SOFTWARE, INC. | | | |
|---|--------------|--------------------------|-----------------------|
| Virus Warning | : Disabled | Video BIOS Shadow | : Enabled |
| CPU Internal Cache | : Enabled | C8000-CBFFF Shadow | : Disabled |
| External Cache | : Enabled | CC000-CFFFF Shadow | : Disabled |
| Quick Power On Self Test | : Enabled | D0000-D3FFF Shadow | : Disabled |
| Boot Sequence | : A, C, SCSI | D4000-D7FFF Shadow | : Disabled |
| Swap Floppy Drive | : Disabled | D8000-DBFFF Shadow | : Disabled |
| Boot Up Floppy Drive | : Enabled | DC000-DFFF Shadow | : Disabled |
| Boot Up Numlock Status | : On | | |
| Gate A20 Option | : Fast | Cyrix 6x86/MII CPUID | : Enabled |
| Memory Parity/ECC Check | : Disabled | | |
| Typematic Rate Setting | : Disabled | | |
| Typematic Rate (chars/Sec) | : 6 | | |
| Typematic Delay (Msec) | : 250 | | |
| Security Option | : Setup | | |
| PCI /VGA Palette Snoop | : Disabled | | |
| OS Select For DRAM>64MB | : Non-OS2 | | |
| HDD S.M.A.R.T. capability | : Disabled | | |
| | | ESC : Quit | ↑ ↓ → ← : Select Item |
| | | F1 : Help | PU/PD/+/- : Modify |
| | | F5 : Old Values | (Shift) F2 : Color |
| | | F6 : Load BIOS Defaults | |
| | | F7 : Load Setup Defaults | |

Virus Warning

This item protects the boot sector and partition table of your hard disk against accidental modifications. If an attempt is made, the BIOS will halt the system and display a warning message. If this occurs, you can either allow the operation to continue or run an anti-virus program to locate and remove the problem.

NOTE: Many disk diagnostic programs which attempt to access the boot sector table can cause the virus warning. If you will run such a program, disable the Virus Warning feature.

CPU Internal Cache / External Cache

These items allow you to enable (speed up memory access) or disable the cache function. By default, these items are **Enabled**.

Quick Power On Self Test

This choice speeds up the Power On Self Test (POST) after you power up the system. If it is set to *Enabled*, BIOS will skip some items. By default, this choice is *Enabled*.

Boot Sequence

This field determines the drive that the system searches first for an operating system. The options are :

| | | |
|-------------|------------|------------|
| A, C, SCSI | D, A, SCSI | SCSI, C, A |
| C, A, SCSI | E, A, SCSI | C only |
| C, CDROM, A | F, A, SCSI | LS/ZIP, C |
| CDROM, C, A | SCSI, A, C | |

The default value is *A, C, SCSI*.

Swap Floppy Drive

This item allows you to determine whether to enable Swap Floppy Drive or not. When enabled, the BIOS swaps floppy drive assignments so that Drive A becomes Drive B, and Drive B becomes Drive A. By default, this field is set to *Disabled*.

Boot Up Floppy Seek

When enabled, the BIOS will seek whether or not the floppy drive installed has 40 or 80 tracks. 360K type has 40 tracks while 760K, 1.2M and 1.44M all have 80 tracks. By default, this field is set to *Enabled*.

Boot Up NumLock Status

This allows you to activate the NumLock function after you power up the system. By default, the system boots up with *NumLock* On.

Gate A20 Option

This field allows you to select how Gate A20 is worked. The Gate A20 is a device used to address memory above. The default setting is set to *Fast*.

Memory Parity/ECC Check

Set this option to *Enabled*, when the memory installed in your system supports ECC (error correction code) or parity. The default setting is *Disabled*.

Typematic Rate Setting

When disabled, continually holding down a key on your keyboard will generate only one instance. When enabled, you can set the two typematic controls listed next. By default, this field is set to *Disabled*.

Typematic Rate (Chars/Sec)

When the typematic rate is enabled, the system registers repeated keystrokes speeds. You can select speed range from 6 to 30 characters per second. By default, this item is set to **6**.

Typematic Delay (Msec)

When the typematic rate is enabled, this item allows you to set the time interval for displaying the first and second characters. By default, this item is set to **250msec**.

Security Option

This field allows you to limit access to the System and Setup. The default value is **Setup**. When you select **System**, the system prompts for the User Password every time you boot up. In **Setup**, the system boots and prompts for the Supervisor Password only when the Setup utility is called up.

PCI/VGA Palette Snoop

Some non-standard VGA display cards may not show colors properly. This field allows you to set whether MPEG ISA/VESA VGA Cards can work with PCI/VGA or not. When this field is enabled, a PCI/VGA can work with a MPEG ISA/VESA VGA card. When this field is disabled, a PCI/VGA cannot work with a MPEG ISA/VESA Card.

OS Select for DRAM > 64MB

This option allows the system to access greater than 64MB of DRAM memory when used with OS/2 that depends on certain BIOS calls to access memory. The default setting is **NON-OS/2**.

HDD S.M.A.R.T Capability

This option enables and disables the S.M.A.R.T. (Self-Monitoring, Analysis, and Reporting Technology) capability of the hard disks.

Video BIOS Shadow

This item allows you to change the Video BIOS location from ROM to RAM. Video Shadow will increase the video speed.

C8000 - CBFFF Shadow/DC000 - DFFFF Shadow

Shadowing a ROM reduces the memory available between 640KB to 1024KB. These fields allow optional ROM to be copied to RAM or not.

Cyrix 6x86/MII CPUID

This item enables and disables the CPUID detection for Cyrix 6x86/MII CPU.

6.5 Chipset Features Setup

This Setup menu controls the configuration of the motherboard chipset.

| ROM PCI/ISA BIOS CHIPSET FEATURES SETUP AWARD SOFTWARE INC. | | | |
|---|--------------|--------------------------|-----------------------|
| Bank 0/1 DRAM Timing | : SDRAM 10ns | OnChip USB | : Enabled |
| Bank 2/3 DRAM Timing | : SDRAM 10ns | OnChip USB 2 | : Disabled |
| Bank 4/5 DRAM Timing | : SDRAM 10ns | USB Keyboard Support | : Disabled |
| SDRAM Cycle Length | : 3 | | |
| DRAM Read Pipeline | : Enabled | OnChip Sound | : Enabled |
| Cache Rd+CPU Wt Pipeline | : Enabled | | |
| Cache Timing | : Fast | | |
| Video BIOS Cacheable | : Enabled | | |
| System BIOS Cacheable | : Enabled | | |
| Memory Hole At 15MB | : Disabled | | |
| AGP Aperture Size | : 64M | | |
| CPU Host Clock (CPU/PCI) | : Default | | |
| Auto Detect DIMM/PCI Clk | : Disabled | ESC : Quit | ↑ ↓ → ← : Select Item |
| Spread Spectrum | : Disabled | F1 : Help | PU/PD/+/- : Modify |
| | | F5 : Old Values | (Shift) F2 : Color |
| | | F6 : Load BIOS Defaults | |
| | | F7 : Load Setup Defaults | |

Bank DRAM Timing

These fields define the speed of the DRAM memory onboard. Options include *SDRAM 10ns* and *FP/EDO 70ns*.

SDRAM Cycle Length

This field sets the SDRAM cycle length to either 2 or 3. The default setting is 3.

DRAM Read Pipeline

When enabled, this field supports pipelining of DRAM reads. The default setting is *Enabled*.

Cache Rd+CPU Wt Pipeline

When enabled, this item allows pipelining of cache reads and CPU writes. The default setting is *Enabled*.

Cache Timing

This field sets the timing of the cache in the system. The options are *Fast* and *Fastest*. By default, this field is set to *Fast*.

Video BIOS Cacheable

Select *Enabled* allows caching of the video BIOS ROM at C0000h-F7FFFh, resulting in better video performance. However, if any program writes to this memory area, a system error may result.

System BIOS Cacheable

Select Enabled allows caching of the system BIOS ROM at F000h-FFFFh, resulting in better system performance. However, if any program writes to this memory area, a system error may result.

Memory Hole at 15MB Addr.

In order to improve performance, certain space in memory can be reserved for ISA cards. This field allows you to reserve 15MB to 16MB memory address space to ISA expansion cards. This makes memory from 15MB and up unavailable to the system. Expansion cards can only access memory up to 16MB. By default, this field is set to *Disabled*.

AGP Aperture Size

The field sets aperture size of the graphics. The aperture is a portion of the PCI memory address range dedicated for graphics memory address space. Host cycles that hit the aperture range are forwarded to the AGP without any translation. The default setting is *64M*.

CPU Host Clock (CPU/PCI)

Default refers to the default settings for the CPU/PCI clock which are *66/33MHz* and *100/33MHz*, depending on the bus speed of the CPU you have installed. If overclocking causes the system to be unstable, use the defaults. Note that *112/37MHz*, *124/41MHz* and *133/44MHz* settings are only supported if your motherboard has an ICS 9148AF-58 clock generator.

IMPORTANT NOTE: When your system does not boot because the CPU has been changed, turn off the computer by pressing the power button and turn it on again by pressing the **Insert** key and the power button simultaneously. (*Note to press the **Insert** key until an image appears on the screen.*) When the system is turned on, press the **Delete** key to enter BIOS Setup and configure the CPU speed.

Auto Detect DIMM/PCI Clk

When enabled, the system automatically shuts off clocks of unused DIMM/PCI slots. This field is for CE testing use only.

Spread Spectrum

This field sets the value of the spread spectrum. Options are *Disabled*, *0.25% (CNTR)*, and *0.50% (DOWN)*. The default setting is *Disabled*. This field is for CE testing use only.

OnChip USB / OnChip USB 2

This field allows you either to enable or disable the USB function.

USB Keyboard Support

This field has a default setting of *Disabled*.

OnChip Sound

This field allows you either to enable or disable the audio function integrated in the VIA VT82C686A South Bridge chip. By default, this field is set to *Enabled*.

6.6 Power Management Setup

ROM PCI/ISA BIOS (2A59IM29)
POWER MANAGEMENT SETUP
AWARD SOFTWARE, INC.

| | | | |
|---------------------|-------------------|---|-------------|
| ACPI | : Enabled | Primary INTR | : ON |
| Power Management | : User Define | IRQ3 (COM2) | : Primary |
| PM Control by APM | : Yes | IRQ4 (COM1) | : Primary |
| Video Off Option | : Suspend -> Off | IRQ5 (LPT 2) | : Primary |
| Video Off Method | : V/H SYNC +Blank | IRQ6 (Floppy Disk) | : Primary |
| Soft-Off by PWRBTN | : Instant-Off | IRQ7 (LPT 1) | : Primary |
| PWRON After PW-Fail | : Off | IRQ8 (RTC Alarm) | : Disabled |
| ** PM Timers ** | | IRQ9 (IRQ2 Redir) | : Secondary |
| HDD Power Down | : Disabled | IRQ10 (Reserved) | : Secondary |
| Doze Mode | : Disabled | IRQ11 (Reserved) | : Secondary |
| Suspend Mode | : Disabled | IRQ12 (PS/2 Mouse) | : Primary |
| ** PM Events ** | | IRQ13 (Coprocessor) | : Primary |
| VGA | : OFF | IRQ14 (Hard Disk) | : Primary |
| LPT & COM | : LPT / COM | IRQ15 (Reserved) | : Primary |
| HDD & FDD | : ON | ESC : Quit ↑ ↓ → ← : Select Item | |
| PCI Master | : OFF | F1 : Help PU/PD/+/- : Modify | |
| PWR-ON By Modem/LAN | : Disabled | F5 : Old Values (Shift) F2 : Color | |
| RTC Alarm Resume | : Disabled | F6 : Load BIOS Defaults | |
| | | F7 : Load Setup Defaults | |

ACPI Function

This field allows you to enable or disable the ACPI (Advanced Configuration Power Interface) function on the motherboard.

Power Management

This field allows you to select the type of power saving management modes. There are four selections for Power Management.

| | |
|-------------------|--|
| Disabled | No power management. |
| Min. Power Saving | Minimum power management. |
| Max. Power Saving | Maximum power management. Only available for SL CPU. |
| User Define | Each of the ranges are from 1 min. to 1hr. Except for HDD Power Down which ranges from 1 min. to 15 min. (Default) |

NOTE: In order to enable the CPU overheat protection feature, the Power Management field should not be set to Disabled.

PM Control by APM

This field allows you to use the Advanced Power Management device to enhance the Max. Power Saving mode and stop the CPU's internal clock. If the Max. Power Saving is not enabled, this will be preset to NO.

Video Off Method

This field defines the Video Off features. There are three options.

- | | |
|------------------|--|
| V/H SYNC + Blank | Default setting, blank the screen and turn off vertical and horizontal scanning. |
| DPMS | Allows the BIOS to control the video display card if it supports the DPMS feature. |
| Blank Screen | This option only writes blanks to the video buffer. |

Modem Use IRQ

This field defines the IRQ being used by the modem. By default, the IRQ is set to 3.

Soft-Off by PWRBTN

This field defines the power-off mode when using an ATX power supply. The *Instant Off* mode allows powering off immediately upon pressing the power button. In the *Delay 4 Sec* mode, the system powers off when the power button is pressed for more than four seconds or enters the suspend mode when pressed for less than 4 seconds. The default value is *Instant Off*.

PWRON After PW-Fail

In case of power failure, the system can be configured to power on or to remain off when the power returns. These settings are *Former-Sts*, *On* and *Off*. The default setting for this field is *Off*.

HDD Power Down

When enabled, and after the set time of system inactivity, the hard disk drive will be powered down while all other devices remain active.

Doze Mode

When enabled, and after the set time of system inactivity, the CPU clock will run at a slower speed while all other devices still operate at full speed.

Suspend Mode

When enabled, and after the set time of system inactivity, all devices except the CPU will be shut off

PM Events

The VGA, LPT & COM, HDD & FDD, PCI Master, PWR-ON By Modem/LAN, RTC Alarm Resume and Primary INTR section are I/O events which can prevent the system from entering a power saving mode or can awaken the system from such a mode. When an I/O device wants to gain the attention of the operating system, it signals this by causing an IRQ to occur. When the operating system is ready to respond to the request, it interrupts itself and performs the service. The default value is *Off*. When set On, activity will neither prevent the system from going into a power management mode nor awaken it. The IRQ section sets the wake-up call of the system. If activity is detected from any enabled IRQ channels in the left-hand group, the system wakes up from suspended mode.

6.7 PNP/PCI Configuration

This option configures the PCI bus system. All PCI bus systems on the system use INT#, thus all installed PCI cards must be set to this value.

| ROM PCI/ISA BIOS PNP/PCI Configuration AWARD SOFTWARE INC. | | | |
|--|---------------|--------------------------|---------------------|
| PNP OS Installed | : No | CPU to PCI Write Buffer | : Enabled |
| Resources Controlled by | : Manual | PCI Dynamic Bursting | : Enabled |
| Reset Configuration Data | : Disabled | PCI Master 0 WS Write | : Disabled |
| | | PCI Delay Transaction | : Enabled |
| IRQ-3 assigned to | : Legacy ISA | PCI#2 Access #1 Retry | : Disabled |
| IRQ-4 assigned to | : Legacy ISA | AGP Master 1 WS Write | : Enabled |
| IRQ-5 assigned to | : PCI/ISA PnP | AGP Master 1 WS Read | : Enabled |
| IRQ-7 assigned to | : Legacy ISA | | |
| IRQ-9 assigned to | : PCI/ISA PnP | Assign IRQ For USB | : Enabled |
| IRQ-10 assigned to | : PCI/ISA PnP | Assign IRQ For VGA | : Enabled |
| IRQ-11 assigned to | : PCI/ISA PnP | | |
| IRQ-12 assigned to | : PCI/ISA PnP | | |
| IRQ-14 assigned to | : PCI/ISA PnP | | |
| IRQ-15 assigned to | : PCI/ISA PnP | | |
| DMA-0 assigned to | : PCI/ISA PnP | | |
| DMA-1 assigned to | : PCI/ISA PnP | ESC : Quit | ↑ ↓ ← : Select Item |
| DMA-3 assigned to | : PCI/ISA PnP | F1 : Help | PU/PD/+/- : Modify |
| DMA-5 assigned to | : PCI/ISA PnP | F5 : Old Values | (Shift) F2 : Color |
| DMA-6 assigned to | : PCI/ISA PnP | F6 : Load BIOS Defaults | |
| DMA-7 assigned to | : PCI/ISA PnP | F7 : Load Setup Defaults | |

PNP OS Installed

This field allows you to specify if the operating system installed in your system is plug and play aware.

Note: Operating systems such as DOS, OS/2, and Windows 3.x do not use PnP.

Resources Controlled by

This PnP BIOS can configure all of the boot and compatible devices automatically. However, this capability needs you to use a PnP operating system such as Windows 95. The default value is **Manual**.

Reset Configuration Data

This field allows you to determine whether to reset the configuration data or not. The default value is **Disabled**.

IRQ3/4/5/7/9/10/11/12/14/15, DMA0/1/3/5/6/7 assigned to

These fields allow you to determine the IRQ/DMA assigned to the ISA bus and is not available to any PCI slot.

CPU to PCI Write Buffer

When enabled, this option increase the efficiency of the PCI bus to and speed up the execution in the processor. By default, this field is set to *Enabled*.

PCI Dynamic Bursting

When enabled, this option combines several PCI cycles into one. By default, this field is set to *Enabled*.

PCI Master 0 WS Write

When enabled, this option increases the write cycle speed. By default, this field is set to *Disabled*.

PCI Delay Transaction

When enabled, this option delays PCI data transaction. By default, this field is set to *Enabled*.

PCI#2 Access #1 Retry

This item enables PC#2 Access #1 attempts. By default, this field is set to *Disabled*.

AGP Master 1 WS Write

When enabled, writes to the AGP bus are executed with 1 wait states. By default, this field is set to *Enabled*.

AGP Master 1 WS Read


When enabled, reads to the AGP bus are executed with 1 wait states. By default, this field is set to *Enabled*.

Assign IRQ for USB/VGA

These fields allow you to enable or disable the IRQ for USB and VGA. By default, these fields are enabled.

6.8 Load BIOS Defaults


This option allows you to load the troubleshooting default values permanently stored in the BIOS ROM. These default settings are non-optimal and disable all high-performance features.



To load BIOS defaults value to CMOS SRAM, enter “Y”. If not, enter “N”.

6.9 Load Setup Defaults

This option allows you to load the default values to your system configuration. These default settings are optimal and enable all high performance features.



To load SETUP defaults value to CMOS SRAM, enter “Y”. If not, enter “N”.

6.10 CPU Features Setup

This Setup menu controls the configuration pertaining to the CPU and system temperature.

| ROM PCI/ISA BIOS | |
|--|---------------|
| CPU SPEED SETTING | |
| AWARD SOFTWARE INC. | |
| Current CPU Temp. | : 41°C/ 105°F |
| Current System Temp. | : 34°C/ 93°F |
| Current CPU Fan Speed | : 2789 RPM |
| Current Chassis Fan Speed | : 2045 RPM |
| VCORE : 2.06 V | +5 V : 5.27 V |
| VIO : 3.41 V | |
| +12 V : 12.46 V | |
| ESC : Quit ↑ ↓ → ← : Select Item F1 : Help PU/PD/+/- : Modify F5 : Old Values (Shift) F2 : Color F6 : Load BIOS Defaults F7 : Load Setup Defaults | |

Current CPU / System Temp.

These read-only fields reflect the functions of the hardware thermal sensor that monitors the chip blocks and system temperatures to ensure the system is stable.

Current CPU Fan Speed / Chassis Fan Speed

These read-only fields show the current speeds in RPM (revolution per minute) for the CPU fan and chassis fan as monitored by the hardware monitoring IC.

VCORE / VIO / +12V / +5V

These read-only fields show the current voltages in the voltage regulators and power supply as monitored by the hardware monitoring IC.

6.11 Integrated Peripherals

This option sets your hard disk configuration, mode and port.

| ROM PCI/ISA BIOS INTEGRATED PERIPHERALS AWARD SOFTWARE INC. | | | |
|---|------------|--------------------------|---------------------|
| OnChip IDE First Channel | : Enabled | Onboard Parallel Port | : 378H/IRQ7 |
| OnChip IDE Second Channel | : Enabled | Onboard Parallel Mode | : Normal |
| IDE Prefetch Mode | : Disabled | | |
| IDE HDD Block Mode | : Enabled | | |
| IDE Primary Master PIO | : Auto | Onboard Legacy Audio | : Enabled |
| IDE Primary Slave PIO | : Auto | Sound Blaster | : Enabled |
| IDE Secondary Master PIO | : Auto | SB I/O Base Address | : 220H |
| IDE Secondary Slave PIO | : Auto | SB IRQ Select | : IRQ 5 |
| IDE Primary Master UDMA | : Auto | SB DMA Select | : DMA 1 |
| IDE Primary Slave UDMA | : Auto | MPU-401 | : Enabled |
| IDE Secondary Master UDMA | : Auto | MPU-401 I/O Address | : 330-333H |
| IDE Secondary Slave UDMA | : Auto | Game Port (200-207H) | : Enabled |
| Init Display First | : AGP | | |
| Onboard FDD Controller | : Enabled | | |
| Onboard Serial Port 1 | : 3F8/IRQ4 | ESC : Quit | ↑ ↓ ← : Select Item |
| Onboard Serial Port 2 | : 2F8/IRQ3 | F1 : Help | PU/PD/+/- : Modify |
| UART 2 Mode | : Standard | F5 : Old Values | (Shift) F2 : Color |
| | | F6 : Load BIOS Defaults | |
| | | F7 : Load Setup Defaults | |

OnChip Primary/Secondary PCI IDE

These fields allow you either to enable or disable the Primary/Secondary controller. You might choose to disable the controller if you were to add a higher performance or specialized controller.

IDE Prefetch Mode

This field allows your hard disk controller to use prefetch mode to transfer data to increase the performance.

IDE HDD Block Mode

This field allows your hard disk controller to use the fast block mode to transfer data to and from your hard disk drive.

IDE Primary/Secondary Master/Slave PIO

These fields allow your system hard disk controller to work faster. Rather than have the BIOS issue a series of commands that transfer to or from the disk drive, PIO (Programmed Input/Output) allows the BIOS to communicate with the controller and CPU directly.

The system supports five modes, numbered from 0 (default) to 4, which primarily differ in timing. When Auto is selected, the BIOS will select the best available mode.

IDE Primary/Secondary Master/Slave UDMA

This field allows your system to improve disk I/O throughput to 33Mb/sec with the Ultra DMA/33 feature. The options are *Auto* and *Disabled*.

Init AGP Display First

This field allows the system to initialize first the AGP VGA display on the motherboard when system is turned on.

Onboard FDD Controller

This option allows you to select the onboard FDD port.

Onboard Serial/Parallel Port

These fields allow you to select the onboard serial and parallel ports and their addresses. The default values for these ports are:

| | |
|---------------|-----------|
| Serial Port 1 | 3F8/IRQ4 |
| Serial Port 2 | 2F8/IRQ3 |
| Parallel Port | 378H/IRQ7 |

UART 2 Mode

This field determines the UART 2 mode in your computer. The options are *Standard*, *HPSIR* and *ASKIR*.

Onboard Parallel Mode

This field allows you to determine parallel port mode function.

| | |
|-----|----------------------------|
| SPP | Standard Printer Port |
| EPP | Enhanced Parallel Port |
| ECP | Extended Capabilities Port |


Onboard Legacy Audio

When this field is enabled, other options of the on board audio in this setup can be configured. These options included Sound Blaster, SB I/O Base Address, SB IRQ Select, SB DMA Select, MPU-401, MPU-401 I/O Address, FM Port (388-38BH) and Game Port.

6.12 Supervisor / User Password

These two options set the system password. *Supervisor Password* sets a password that will be used to protect the system and Setup utility. *User Password* sets a password that will be used exclusively on the system. To specify a password, highlight the type you want and press <Enter>. The **Enter Password:** message prompts on the screen. Type the password, up to eight characters in length, and press <Enter>. The system confirms your password by asking you to type it again. After setting a password, the screen automatically returns to the main screen.

To disable a password, just press the <Enter> key when you are prompted to enter the password. A message will confirm the password to be disabled. Once the password is disabled, the system will boot and you can enter Setup freely.



6.13 IDE HDD Auto Detection

This option detects the parameters of an IDE hard disk drive, and automatically enters them into the Standard CMOS Setup screen.


ROM PCI/ISA BIOS
STANDARD CMOS SETUP
AWARD SOFTWARE, INC.

| HARD DISKS | TYPE | SIZE | CYLS | HEAD | PRECOMP | LANDZ | SECTOR | MODE |
|--|------|------|------|------|---------|-------|--------|--------|
| Primary Master: | | | | | | | | |
| Select Primary Master Option (N=SKIP) : N | | | | | | | | |
| OPTIONS | TYPE | SIZE | CYLS | HEAD | PRECOMP | LANDZ | SECTOR | MODE |
| 1 (Y) | 0 | 0 | 0 | 0 | 0 | 0 | 0 | NORMAL |
| | | | | | | | | |
| | | | | | | | | |
| NOTE: Some OSes (like SCO-UNIX) must use "NORMAL" for installation | | | | | | | | |
| ESC: SKIP | | | | | | | | |

Up to four IDE drives can be detected, with parameters for each appearing in sequence inside a box. To accept the displayed entries, press the "Y" key; to skip to the next drive, press the "N" key. If you accept the values, the parameters will appear listed beside the drive letter on the screen.


6.14 Save & Exit Setup

This option allows you to determine whether to accept the modifications or not. If you type “Y”, you will quit the setup utility and save all changes into the CMOS memory. If you type “N”, you will return to Setup utility.



6.15 Exit Without Saving

Select this option to exit the Setup utility without saving the changes you have made in this session. Typing “Y” will quit the Setup utility without saving the modifications. Typing “N” will return you to Setup utility.




Chapter 7 VIA Drivers and DirectX Installation

This chapter describes the installation procedure for the drivers including VIA 4-in-1 driver, VXD driver, IDE Bus Master driver, audio driver, and DirectX.

NOTE: *If you are using Windows 95, please install USB supplement to OSR2 from the original Windows 95 CD or download it from Microsoft's web site after you have installed Windows 95 (even before you have started to install the drivers mentioned in this chapter.)*


7.1 Windows 95 4-in-1 Driver Installation

1. Insert the driver CD disc to the CD-ROM drive. The CD-ROM autoruns and displays the selection for Intel drivers and VIA drivers. Click on **VIA M/B Drivers** and the following window will appear. Click **VIA 4 IN 1 Drivers**.




2. Click **Next**. to continue the installation process, and then click **Yes** to agree with the license agreement.


3. Click **Next** to install all the drivers shown below.




4. Click **Next** to install the (Ultra) DMA for IDE driver.



5. Click on the **Enable/Disable (Ultra) DMA** checkbox, and click **Next** to enable (Ultra) DMA.




6. To install **VIA Service Pack**, click **Next**.




7. Click **Next** to accept the listed folder name or select from the existing folders list, then click **Next**.



8. Click **Next** to install the VIA AGP driver.




9. Click **Next** to install the VIA Chipset Functions' Registry.



10. When Setup has finished copying files to your computer, you must restart Windows or your computer before you can use the program. Remove any disks from their drives, and then click **Finish** to complete setup.

7.2 Windows 95 Audio Driver Installation

1. Insert the driver CD disc to the CD-ROM drive. The CD-ROM autoruns and displays the selections available. Click on **VIA M/B Drivers** and the following window appears. Click **VIA 686A PCI Multimedia Audio Driver**.



2. The next screen will ask you to remove the Audio Device from the Device Manager. If you have already removed the audio device, click **Yes** to continue the audio driver installation. (If you have not, click **No** and exit the installation process and remove the audio device before installing the audio drivers.)


3. To continue with the VIA PCI Audio Driver Installation, click **Next** to agree with the license agreement.

4. When the **Select Components** window appears, click **Next** to install the audio driver.

5. After the necessary files are copied, click **Finish** for the computer the restart and changes to take effect.

7.3 Windows 98 4-in-1 Driver Installation

1. Insert the driver CD disc to the CD-ROM drive. The CD-ROM autoruns and displays the selection for Intel drivers and VIA drivers. Click on **VIA M/B Drivers** and the following window will appear. Click **VIA 4 IN 1 Drivers**.



2. When the **Welcome** screen appears, click **Next** to continue with the Setup program.
3. To accept the VIA Service Pack license agreement, click **Yes**.

4. Click **Next** for the setup program to install the drivers for Bus Master PCI IDE, AGP VxD, VIA Chipset Functions' Registry and IRQ Routing Miniport Drivers.



5. Click **Next** to install (Ultra) DMA for IDE driver.

6. Click on the **Enable/Disable (Ultra) DMA** checkbox, and then click **Next** to continue the installation process.

7. When the **Choose Destination Location** window appears, click **Next** to install **VIA Service Pack** in the folder name shown.

8. When the **Select Program Folder** window appears, click **Next** for Setup to add the program icons to the **VIADMATool** program folder. You may, however, type a new folder name or select one from the existing Folders list.



9. When the **VIA_GART AGP Driver 3.55** window appears, click **Next** to install **VIA AGP VxD in turbo mode**.


10. When the **VIA Chipset Functions' Registry** window appears, click **Next** to install the VIA Chipset Functions' Registry.

11. When the **IRQ Routing Driver 1.30** window appears, click **Next** to install the VIA IRQ Routing Miniport Driver.


12. When Setup has finished copying files to your computer, click **Finish** to restart your computer and for changes to take effect.

7.4 Windows 98/95 DirectX Installation


1. Insert the driver CD disc to the CD-ROM drive. The CD-ROM autoruns and displays the selections available. Click on **Tools** and the following window will appear. Click **DirectX 6.1 Core**.




2. Click **Yes** to install Microsoft DirectX 6.1 Runtime.



3. Click **Yes** to continue.




4. When DirectX setup is completed, click **OK**.



7.5 Windows 98 Audio Driver Installation

1. Insert the driver CD disc to the CD-ROM drive. The CD-ROM autoruns and displays the selections available. Click on **VIA M/B Drivers** and the following window appears. Click **VIA 686A PCI Multimedia Audio Driver**.



2. When the **Welcome** screen appears, click **Next** to proceed with the audio driver installation.


3. The **Select Components** window will appear. Click **Next** to install the audio driver.

4. After the necessary files are copied, click **Finish** for the computer the restart.


5. When Windows has restarted, a message will appear prompting you to insert the Windows 98 CDROM. Insert the Windows 98 CDROM and click **OK**.

7.6 Windows 98SE 4-in-1 Driver Installation

1. Insert the driver CD disc to the CD-ROM drive. The CD-ROM autoruns and displays the selection for Intel drivers and VIA drivers. Click on **VIA M/B Drivers** and the following window will appear. Click **VIA 4 IN 1 Drivers**.




2. When the **Welcome** screen appears, click **Next** to continue with the Setup program.
3. To accept the VIA Service Pack license agreement, click **Yes**.
4. Click **Next** for the setup program to install the AGP VxD Driver. *Please note that there are no check box for the Bus Master PCI IDE drivers, VIA Chipset Functions' Registry and IRQ Routing Miniport Drivers (unlike Windows 98 and Windows 95), because these drivers are already supported by Windows 98SE.*



5. When the **VIA_GART AGP Driver 3.55** window appears, click **Next** to install **VIA AGP VxD in turbo mode**.
6. When Setup has finished copying files to your computer, click **Finish** to restart your computer and for changes to take effect.

7.7 Windows 98SE Audio Driver Installation

1. Insert the driver CD disc to the CD-ROM drive. The CD-ROM autoruns and displays the selections available. Click on **VIA M/B Drivers** and the following window appears. Click **VIA 686A PCI Multimedia Audio Driver**.



2. When the **Welcome** screen appears, click **Next** to proceed with the audio driver installation.

3. The **Select Components** window will appear. Click **Next** to install the audio driver.


4. After the necessary files are copied, click **Finish**.

5. When Windows has restarted, a message will appear prompting you to insert the Windows 98 CDROM. Insert the Windows 98 CDROM and click **OK**. After the necessary files are copied, restart your computer for changes to take effect.

7.8 Windows NT 4.0 Audio Driver Installation

IMPORTANT: You should install the Windows NT 4.0 Service Pack 4 or higher first before installing the VIA 686A PCI multimedia audio device drivers. If you don't have Windows NT 4.0 Service Pack 4 or higher, please contact your software vendor or download it from Microsoft's web site.


1. Insert the driver CD disc to the CD-ROM drive. The CD-ROM autoruns and displays the selections available. Click on **VIA M/B Drivers** and the following window appears. Click **VIA 686A PCI Multimedia Audio Driver**.





2. When the **Welcome** screen appears, click **Next** to proceed with the audio driver installation.



3. The **Select Components** window will appear. Click **Next** to install the audio driver.

4. When the **Information** window appears, click **OK**. Please choose “**Add...**” from the next window and add the following device: VIA PCI Audio Controller and VIA MIDI External Port.




5. After the VIA PCI Audio Controller and VIA MIDI External Port devices are added, you will be asked whether to install the driver for the Microsoft Sidewinder 3D Pro Joystick. Click **Yes**. You will be prompted to press “**Add...**” from the next window and select “**Microsoft Side winder 3D Pro Joystick**” to install the joystick’s driver. Refer to the following figures.






6. Upon adding the **Microsoft Side winder 3D Pro Joystick**, insert the Windows NT CD-ROM or the disk with the updated sidewndr.dll driver.



7. When the **Microsoft SideWinder Joystick Configuration** window appears, click **OK** to accept the default configuration. Then, restart the computer for changes to take effect.



This page was intentionally left blank.


Chapter 8 System Monitor Installation

This chapter shows the installation procedure of the System Monitor Utility. The software comes in the CD with the motherboard and is used in conjunction with the onboard hardware monitoring function.


System Monitor is a software utility that oversees the general performance of systems, covering areas like system temperature, system voltage, CPU and system fan rotational speeds. If conditions become adverse, that is, when voltages are erratic or CPU temperature exceeds the safe limits, an alarm will be sounded; thereby preventing system crashing and ensuring overall stability.

Please follow the procedure below on how to install System Monitor.


1. Insert the driver CD disc to the CD-ROM drive. The CD-ROM autoruns and displays the selections available. Click on **Tools** and the following window appears. Click **SYSTEM MONITOR**, then **YES** to proceed with the installation.




2. When the **Welcome** screen appears, click **Next** to continue with the Setup program.




3. Choose the destination location where System Monitor will be installed. Click **Next** to continue Setup.



4. Click **Next** to agree with the settings shown and to begin copying files.



5. Click **Yes** to restart your computer to be able to use the program.



Appendix

A. Additions & Errata

This section is allotted for future page inserts containing any additional information or correction that the users should know.

Important Notes on VIA VxD AGP Driver

1. The user's manual states that in installing VIA_GART AGP Driver, the turbo mode (default) should be selected. However, when system becomes unstable due to this selection, reinstall the VIA_GART AGP Driver and select the **normal mode**. Please refer to the chapter on VIA Drivers Installation Guide.
2. Under Windows 98 Second Edition, it is not necessary to install the VIA VxD AGP Driver. However, in case the system is not functioning properly, install the VIA VxD AGP Driver.